

SPLIT-TYPE AIR CONDITIONERS

September 2024

No.OCH773 REVISED EDITION-C

SERVICE MANUAL

R32

PUZ-M100YKA2R1.TH

PUZ-M125YKA2R1.TH

PUZ-M140YKA2R1.TH

PUZ-M100YKA2-ETR1.TH

PUZ-M125YKA2-ETR1.TH

PUZ-M140YKA2-ETR1.TH

Outdoor unit [Model Name] PUZ-M100VKA2 PUZ-M100VKA2-ET

[Service Ref.] PUZ-M100VKA2-ER PUZ-M125VKA2 PUZ-M125VKA2.TH PUZ-M125VKA2-ET PUZ-M125VKA2-ER PUZ-M140VKA2 PUZ-M140VKA2.TH PUZ-M140VKA2-ET PUZ-M140VKA2-ER PUZ-M100YKA2 PUZ-M100YKA2.TH

PUZ-M100YKA2-ET PUZ-M100YKA2-ER PUZ-M125YKA2 PUZ-M125YKA2-ET PUZ-M125YKA2-ER PUZ-M140YKA2 PUZ-M140YKA2-ET PUZ-M140YKA2-ER

PUZ-M100VKA2.TH PUZ-M100VKA2-ET.TH PUZ-M100VKA2-ER.TH

PUZ-M125VKA2-ET.TH PUZ-M125VKA2-ER.TH

PUZ-M140VKA2-ET.TH PUZ-M140VKA2-ER.TH

PUZ-M100YKA2-ET.TH PUZ-M100YKA2-ER.TH

PUZ-M125YKA2.TH PUZ-M125YKA2-ET.TH PUZ-M125YKA2-ER.TH


PUZ-M140YKA2.TH PUZ-M140YKA2-ET.TH PUZ-M140YKA2-ER.TH Revision:

· Connectable indoor units have been added in REVISED EDITION-C.

OCH773B is void.

Note:

· This service manual describes technical data of the outdoor units only.



CONTENTS

1. REFERENCE MANUAL ·····2
2. SAFETY PRECAUTION ······2
3. SPECIFICATIONS 13
4. DATA······ 14
5. OUTLINES AND DIMENSIONS 17
6. WIRING DIAGRAM 18
7. WIRING SPECIFICATIONS 22
8. REFRIGERANT SYSTEM DIAGRAM ··· 27
9. TROUBLESHOOTING 29
10. FUNCTION SETTING 77
11. MONITORING THE OPERATION DATA
BY THE REMOTE CONTROLLER ······ 78
12. EASY MAINTENANCE FUNCTION ····· 86
13. DISASSEMBLY PROCEDURE ····· 88
14. REMOTE CONTROLLER · · · · · 95

PARTS CATALOG (OCB773)



1

REFERENCE MANUAL

INDOOR UNIT SERVICE MANUAL

Model Name	Service Ref.	Service Manual No. Parts Catalog No.
PLA-M50/60/71/100/125/140EA2 PLA-M50/60/71/100/125/140EA2-ET PLA-M50/60/71/100/125/140EA2-ER	PLA-M50/60/71/100/125/140EA2.UK PLA-M50/60/71/100/125/140EA2-ET.UK PLA-M50/60/71/100/125/140EA2-ER.UK	OCH783 OCB783
PKA-M50LA(L)2 PKA-M50LA(L)2-ET PKA-M50LA(L)2-ER	PKA-M50LA(L)2.TH PKA-M50LA(L)2-ET.TH PKA-M50LA(L)2-ER.TH	TCH068 TCB068
PKA-M60/71/100KA(L)2 PKA-M60/71/100KA(L)2-ET PKA-M60/71/100KA(L)2-ER	PKA-M60/71/100KA(L)2(R1).TH PKA-M60/71/100KA(L)2-ET(R1).TH PKA-M60/71/100KA(L)2-ER.TH	TCH069 TCB069
PCA-M50/60/71/100/125/140KA2 PCA-M50/60/71/100/125/140KA2-ET PCA-M50/60/71/100/125/140KA2-ER	PCA-M50/60/71/100/125/140KA2 PCA-M50/60/71/100/125/140KA2-ET PCA-M50/60/71/100/125/140KA2-ER	OCH752 OCB752
PSA-M71/100/125/140KA PSA-M71/100/125/140KA-ET PSA-M71/100/125/140KA-ER	PSA-M71/100/125/140KA PSA-M71/100/125/140KA-ET PSA-M71/100/125/140KA-ER	OCH724 OCB724
PEAD-M50/60/71/100/125/140JA(L)2 PEAD-M50/60/71/100/125/140JA2-ET	PEAD-M50/60/71/100/125/140JA(L)2.UK PEAD-M50/60/71/100/125/140JA2-ET.UK PEAD-M50/60/71/100/125/140JA2-ER.UK	BWE021440
PEAD-M50/60/71/100/125/140JA2-ER	PEAD-M50/60/71/100/125/140JA(L)2.TH	BWE022250

2

SAFETY PRECAUTION

MEANINGS OF SYMBOLS DISPLAYED ON THE UNIT

	WARNING (Risk of fire)	This mark is for R32 refrigerant only. Refrigerant type is written on nameplate of outdoor unit. In case that refrigerant type is R32, this unit uses a flammable refrigerant. If refrigerant leaks and comes in contact with fire or heating part, it will create harmful gas and there is risk of fire.		
	Read the OPERATION MANUAL carefully before operation.			
	Service personnel are required to carefully read the OPERATION MANUAL and INSTALLATION MANUAL before operation.			
i	Further information is available in the OPERATION MANUAL, INSTALLATION MANUAL, and the like.			

2-1. ALWAYS OBSERVE FOR SAFETY

Before obtaining access to terminal, all supply circuits must be disconnected.

2-2. CAUTIONS RELATED TO NEW REFRIGERANT

Cautions for units utilizing refrigerant R32

Preparation before the repair service

- · Prepare the proper tools.
- · Prepare the proper protectors.
- · Provide adequate ventilation.
- After stopping the operation of the air conditioner, turn off the power-supply breaker.
- Discharge the condenser before the work involving the electric parts.

Use new refrigerant pipes.

In case of using the existing pipes for R22, be careful with the following.

- · Be sure to clean the pipes and make sure that the insides of the pipes are clean.
- Change flare nut to the one provided with this product. Use a newly flared pipe.
- · Avoid using thin pipes.

Precautions during the repair service

- Do not perform the work involving the electric parts with wet hands.
- Do not pour water into the electric parts.
- · Do not touch the refrigerant.
- Do not touch the hot or cold areas in the refrigerating cycle.
- When the repair or the inspection of the circuit needs to be done without turning off the power, exercise great caution not to touch the live parts.
- When opening or closing the valve below freezing temperatures, refrigerant may spurt out from the gap between the valve stem and the valve body, resulting in injuries.

Use a vacuum pump with a reverse flow check valve.

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil, etc.

Make sure that the inside and outside of refrigerant piping is clean and it has no contaminants such as sulfur, oxides, dirt, shaving particles, etc., which are hazard to refrigerant cycle.

In addition, use pipes with specified thickness.

Contamination inside refrigerant piping can cause deterioration of refrigerant oil, etc.

Use the following tools specifically designed for use with R32 refrigerant.

The following tools are necessary to use R32 refrigerant.

Tools for R32		
Gauge manifold	Flare tool	
Charge hose	Size adjustment gauge	
Gas leak detector	Vacuum pump adaptor	
Torque wrench	Electronic refrigerant charging scale	

Store the piping indoors, and keep both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

The refrigerant oil applied to flare and flange connections must be ester oil, ether oil or alkylbenzene oil in a small amount.

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil, etc.

Use the specified refrigerant only.

Handle tools with care.

compressor.

Never use any refrigerant other than that specified.

If dirt, dust or moisture enters into refrigerant cycle, that

can cause deterioration of refrigerant oil or malfunction of

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of. Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

Do not use refrigerant other than R32.

If other refrigerant (R22, etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil, etc.

Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.

[1] Warning for service

- (1) Do not alter the unit.
- (2) For installation and relocation work, follow the instructions in the Installation Manual and use tools and pipe components specifically made for use with refrigerant specified in the outdoor unit installation manual.
- (3) Ask a dealer or an authorized technician to install, relocate and repair the unit. For appliances not accessible to the general public.
- (4) Refrigerant pipes connection shall be accessible for maintenance purposes.
- (5) If the air conditioner is installed in a small room or closed room, measures must be taken to prevent the refrigerant concentration in the room from exceeding the safety limit in the event of refrigerant leakage. Should the refrigerant leak and cause the concentration limit to be exceeded, hazards due to lack of oxygen in the room may result.
- (6) Keep gas-burning appliances, electric heaters, and other fire sources (ignition sources) away from the location where installation, repair, and other air conditioner work will be performed.
 - If refrigerant comes into contact with a flame, poisonous gases will be released.
- (7) When installing or relocating, or servicing the air conditioner, use only the specified refrigerant (R32) to charge the refrigerant lines.
 - Do not mix it with any other refrigerant and do not allow air to remain in the lines.
 - If air is mixed with the refrigerant, then it can be the cause of abnormal high pressure in the refrigerant line, and may result in an explosion and other hazards.
- (8) After installation has been completed, check for refrigerant leaks. If refrigerant leaks into the room and comes into contact with the flame of a heater or portable cooking range, poisonous gases will be released.
- (9) Do not use low temperature solder alloy in case of brazing the refrigerant pipes.
- (10) When performing brazing work, be sure to ventilate the room sufficiently. Make sure that there are no hazardous or flammable materials nearby.
 - When performing the work in a closed room, small room, or similar location, make sure that there are no refrigerant leaks before performing the work.
 - If refrigerant leaks and accumulates, it may ignite or poisonous gases may be released.
- (11) Do not install the unit in places where refrigerant may build-up or places with poor ventilation such as a semi-basement or a sunken place in outdoor: Refrigerant is heavier than air, and inclined to fall away from the leak source.
- (12) Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- (13) The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- (14) Do not pierce or burn.
- (15) Be aware that refrigerants may not contain an odour.
- (16) Pipe-work shall be protected from physical damage.
- (17) The installation of pipe-work shall be kept to a minimum.
- (18) Compliance with national gas regulations shall be observed.
- (19) Keep any required ventilation openings clear of obstruction.
- (20) Servicing shall be performed only as recommended by the manufacturer.
- (21) The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- (22) Maintenance, service and repair operations shall be performed by authorized technician with required qualification.
- (23) Be sure to have appropriate ventilation in order to prevent ignition. Furthermore, be sure to carry out fire prevention measures that there are no dangerous or flammable objects in the surrounding area.


[2] Cautions for service


- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) When performing service, install a filter drier simultaneously. Be sure to use a filter drier for new refrigerant.

[3] Additional refrigerant charge

When charging directly from cylinder

R32 is a single refrigerant and its composition does not change. Therefore, both liquid charging and gas charging are possible. Liquid charging of refrigerant all at once from the low pressure side may cause the compressor malfunction. Accordingly, make sure that charging is gradual.





[4] Cautions for unit using R32 refrigerant

Basic work procedures are the same as those for conventional units using refrigerant R410A. However, pay careful attention to the following points.

(1) Information on servicing

(1-1) Checks on the Area

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized.

For repair to the refrigerating systems, (1-3) to (1-7) shall be completed prior to conducting work on the systems.

(1-2) Work Procedure

Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed.

(1-3) General Work Area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided. The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.

(1-4) Checking for Presence of Refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

(1-5) Presence of Fire Extinguisher

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand.

Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

(1-6) No Ignition Sources

No person carrying out work in relation to a refrigeration system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

(1-7) Ventilated Area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

(1-8) Checks on the Refrigeration Equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.

The following checks shall be applied to installations using flammable refrigerants:

- The charge size is in accordance with the room size within which the refrigerant containing parts are installed.
- · The ventilation machinery and outlets are operating adequately and are not obstructed.
- Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected.
- Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance
 which may corrode refrigerant containing components, unless the components are constructed of materials which are
 inherently resistant to being corroded or are suitably protected against being corroded.

(1-9) Checks on Electrical Devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include that:

- · capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- · no live electrical components and wiring are exposed while charging, recovering or evacuating the system;
- · there is continuity of earth bonding
- (2) Repairs to Sealed Components
- (2-1) During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- (2-2) Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc. Ensure that the apparatus is mounted securely.

Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres.

Replacement parts shall be in accordance with the manufacturer's specifications.

5

(3) Repair to intrinsically Safe Components

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

(4) Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

(5) Detection of Flammable Refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

(6) Leak Detection Methods

Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25% maximum) is confirmed.

Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

If a leak is suspected, all naked flames shall be removed/extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. For appliances containing flammable refrigerants, oxygen free nitrogen (OFN) shall then be evacuated through the system both before and during the brazing process.

(7) Removal and Evacuation

When breaking into the refrigerant circuit to make repairs – or for any other purpose conventional procedures shall be used. However, for flammable refrigerants it is important that best practice is followed since flammability is a consideration. The following procedure shall be adhered to:

- · remove refrigerant
- · evacuate the circuit with inert gas
- evacuate
- · evacuate again with inert gas
- · open the circuit by cutting or brazing.

The refrigerant charge shall be recovered into the correct recovery cylinders. For appliances containing flammable refrigerants, the system shall be "flushed" with OFN to render the unit safe. This process may need to be repeated several times.

Compressed air or oxygen shall not be used for evacuating refrigerant systems.

For appliances containing flammable refrigerants, flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. This operation is absolutely vital if brazing operations on the pipe-work are to take place.

Ensure that the outlet for the vacuum pump is not close to any ignition sources and that ventilation is available.

(8) Charging Procedures

In addition to conventional charging procedures, the following requirements shall be followed:

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- · Cylinders shall be kept upright.
- Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
- · Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the refrigeration system.

Prior to recharging the system, it shall be pressure-tested with the appropriate evacuating gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

(9) Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

a) Become familiar with the equipment and its operation.

- b) Isolate system electrically.
- c) Before attempting the procedure, ensure that:
 - · mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - · all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

(10) Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

(11) Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely. When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge are available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders. If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

[5] Service tools


Use the below service tools as exclusive tools for R32 refrigerant.

No.	Tool name	Specifications
①	Gauge manifold	· Only for R32
		· Use the existing fitting specifications. (UNF1/2)
		· Use high-tension side pressure of 5.3 MPaG or over.
2	Charge hose	· Only for R32
		· Use pressure performance of 5.09 MPaG or over.
3	Electronic weighing scale	_
4	Gas leak detector	· Use the detector for R134A, R407C, R410A or R32.
(5)	Adaptor for reverse flow check	· Attach on vacuum pump.
6	Refrigerant charge base	_
7	Refrigerant cylinder	· Only for R32
		· Cylinder with syphon
8	Refrigerant recovery equipment	_

2-3. PRECAUTIONS WHEN REUSING EXISTING R22/R410A REFRIGERANT PIPES

(1) Flowchart

- Refer to the flowchart below to determine if the existing pipes can be used and if it is necessary to use a filter dryer.
- If the diameter of the existing pipes is different from the specified diameter, refer to technical data materials to confirm if the pipes can be used.



(2) Cautions for refrigerant piping work

New refrigerant R32 is adopted for replacement inverter series. Although the refrigerant piping work for R32 is same as for R22, exclusive tools are necessary so as not to mix with different kind of refrigerant. Furthermore as the working pressure of R32 is 1.6 times higher than that of R22, their sizes of flared sections and flare nuts are different.

① Thickness of pipes


Because the working pressure of R32 is higher compared to R22, be sure to use refrigerant piping with thickness shown below. (Never use pipes of 0.7 mm or below.)

Diagram below: Piping diameter and thickness

Nominal	Outside	Thickne	SS (mm)
dimensions(inch)	diameter (mm)	R32/R410a	R22
1/4	6.35	0.8	8.0
3/8	9.52	0.8	8.0
1/2	12.70	0.8	8.0
5/8	15.88	1.0	1.0
3/4	19.05	-	1.0

2 Dimensions of flare cutting and flare nut

The component molecules in HFC refrigerant are smaller compared to conventional refrigerants. In addition to that, R32 is a refrigerant, which has higher risk of leakage because its working pressure is higher than that of other refrigerants. Therefore, to enhance airtightness and strength, flare cutting dimension of copper pipe for R32 has been specified separately from the dimensions for other refrigerants as shown below. The dimension B of flare nut for R32 also has partly been changed to increase strength as shown below. Set copper pipe correctly referring to copper pipe flaring dimensions for R32 below. For 1/2 and 5/8 inch pipes, the dimension B changes. Use torque wrench corresponding to each dimension.







Flare cutting dimensions

Nominal		Dimension A (.04)(mm	
dimensions (inch)	Outside diameter (mm)	R32/R410A	R22
1/4	6.35	9.1	9.0
3/8	9.52	13.2	13.0
1/2	12.70	16.6	16.2
5/8	15.88	19.7	19.4
3/4	19.05	_	23.3

Flare nut dimensions

Nominal	0.1:1	Dimensio	n B (mm)
dimensions (inch)	Outside diameter (mm)	R32/R410A	R22
1/4	6.35	17.0	17.0
3/8	9.52	22.0	22.0
1/2	12.70	26.0	24.0
5/8	15.88	29.0	27.0
3/4	19.05	_	36.0

3 Tools for R32 (The following table shows whether conventional tools can be used or not.)


Tools and materials	Use	R32 tools	Can R22 tools be used?	Can R407C tools be used?	Can R410A tools be used?
Gauge manifold	Air evacuate, refrigerant	Tool exclusive for R32	×	×	0
Charge hose	charge and operation check	Tool exclusive for R32	×	×	0
Gas leak detector	Gas leak check	Tool for HFC refrigerant	×	0	0
Refrigerant recovery equipment	Refrigerant recovery	Tool exclusive for R32	×	×	0
Refrigerant cylinder	Refrigerant charge	Tool exclusive for R32	×	×	X
Safety charger	Prevent compressor malfunction when charging refrigerant by spraying liquid refrigerant	Tool exclusive for R32	×	×	0
Charge valve	Prevent gas from blowing out when detaching charge hose	Tool exclusive for R32	×	×	0
Vacuum pump	Vacuum drying and air evacuate	Tools for other refrigerants can be used if equipped with adapter for reverse flow check	△(Usable if equipped with adapter for reverse flow)	△(Usable if equipped with adapter for reverse flow)	△(Usable if equipped with adapter for reverse flow)
Flare tool	Flaring work of piping	Tools for other refrigerants can be used by adjusting flaring dimension	△(Usable by adjusting flaring dimension)	△(Usable by adjusting flaring dimension)	△(Usable by adjusting flaring dimension)
Bender	Bend the pipes	Tools for other refrigerants can be used	0	0	0
Pipe cutter	Cut the pipes	Tools for other refrigerants can be used	0	0	0
Welder and nitrogen gas cylinder	Weld the pipes	Tools for other refrigerants can be used	0	0	0
Refrigerant charging scale	Refrigerant charge	Tools for other refrigerants can be used	0	0	0
Vacuum gauge or thermistor vacuum gauge and vacuum valve	Check the degree of vacuum. (Vacuum valve prevents back flow of oil and refrigerant to thermistor vacuum gauge)	Tools for other refrigerants can be used	0	0	0
Charging cylinder	Refrigerant charge	Tool exclusive for R32	X	_	X

imes : Prepare a new tool. (Use the new tool as the tool exclusive for R32.)

 $[\]triangle$: Tools for other refrigerants can be used under certain conditions.

Tools for other refrigerants can be used.

2-4. Choosing the outdoor unit installation location



R32 is heavier than air—as well as other refrigerants—so tends to accumulate at the base (in the vicinity of the floor). If R32 accumulates around base, it may reach a flammable concentration in case room is small. To avoid ignition, maintaining a safe work environment is required by ensuring appropriate ventilation. If a refrigerant leak is confirmed in a room or an area where there is insufficient ventilation, refrain from using of flames until the work environment can be improved by ensuring appropriate ventilation.

Install outdoor units in a place where at least one of the four sides is open, and in a sufficiently large space without depressions.

Do not install the outdoor unit at the inside of building such as a basement or machinery room where the refrigerant stagnates.

2-5. Minimum installation area


If you unavoidably install a unit in a space where all four sides are blocked or there are depressions, confirm that one of these situations (A, B or C) is satisfied.

Note: These countermeasures are for keeping safety not for specification guarantee.


A) Secure sufficient installation space (minimum installation area A min).


Install in a space with an installation area of A min or more, corresponding to refrigerant quantity M (factory-charged refrigerant + locally added refrigerant).

M [kg]	A min [m²]
1.0	12
1.5	17
2.0	23
2.5	28
3.0	34
3.5	39
4.0	45
4.5	50
5.0	56
5.5	62
6.0	67
6.5	73
7.0	78
7.5	84
8.0	89
8.5	95
9.0	100
9.5	106



B) Install in a space with a depression height of ≤ 0.125 [m]






C) Create an appropriate ventilation open area.

Make sure that the width of the open area is 0.9 [m] or more and the height of the open area is 0.15 [m] or more. However, the height from the bottom of the installation space to the bottom edge of the open area should be 0.125 [m] or less.

Open area should be 75% or more opening.



■ Indoor units

Install in a room with a floor area of A min or more, corresponding to refrigerant quantity M (factory-charged refrigerant + locally added refrigerant).

* For the factory-charged refrigerant amount, refer to the spec nameplate or installation manual.

For the amount to be added locally, refer to the installation manual.

Install the indoor unit so that the height from the floor to the bottom of the indoor unit is h0; for wall mounted: 1.8 m or more;

for ceiling suspended, cassette and ceiling concealed: 2.2 m or more.


* There are restrictions in installation height for each model, so read the installation manual for the particular unit.

Case 1: for wall mounted, ceiling suspended, cassette and concealed

M [kg]	A min [m²]		
1.0	4		
1.5	6		
2.0	8		
2.5	10		
3.0	12		
3.5	14		
4.0	16		
4.5	20		
5.0	24		h0 ≥ 1.8 [m]
5.5	29		
6.0	35		
6.5	41		
7.0	47		
7.5	54		Wall mounted
8.0	62		
8.5	69		
9.0	78		
9.5	87		
			\uparrow
1	·		
		LO	10 2 00 5-1
h0 ≥ 2.2 [m]		h0 ≥ 2.2 [m]	h0 ≥ 2.2 [m]
	,		\downarrow
Coiling avens : -1 - 1		Cassetta	
Ceiling suspended		Cassette	Ceiling concealed

Case 2: for floor standing (PSA-M)

M [kg]	A min [m²]
< 1.84	No requirements
1.84	6
2.0	6
2.5	7
3.0	9
3.5	10
4.0	11
4.5	13
5.0	14
5.5	15
6.0	17
6.5	18
7.0	20
7.5	21
8.0	22
8.5	24
9.0	25
9.5	26



Floor standing (PSA-M)

SPECIFICATIONS

		Service	e Ref		А2.ТН А2-ЕТ.ТН А2-ЕR.ТН	А2.ТН А2-ЕТ.ТН А2-ЕК.ТН	А2.ТН А2-ЕТ.ТН А2-ЕК.ТН	А2.ТН А2-ЕТ.ТН А2-ЕК.ТН А2-К1.ТН А2-ЕТК1.ТН	А2.ТН А2-ЕТ.ТН А2-ЕК.ТН А2-К1.ТН А2-ЕТК1.ТН	А2.ТН А2-ЕТ.ТН А2-ЕК.ТН А2-ЕТ.ТН А2-ЕТК1.ТН			
					PUZ-M100VKA2.TH PUZ-M100VKA2-ET.TH PUZ-M100VKA2-ER.TH	PUZ-M125VKA2.TH PUZ-M125VKA2-ET.TH PUZ-M125VKA2-ER.TH	PUZ-M140VKA2.TH PUZ-M140VKA2-ET.TH PUZ-M140VKA2-ER.TH	PUZ-M100YKA2.TH PUZ-M100YKA2-ET.TH PUZ-M100YKA2-ER.TH PUZ-M100YKA2R1.TH PUZ-M100YKA2R1.TH	PUZ-M125YKA2.TH PUZ-M125YKA2-ET.TH PUZ-M125YKA2-ER.TH PUZ-M125YKA2R1.TH PUZ-M125YKA2.ETR1.TH	PUZ-M140YKA2.TH PUZ-M140YKA2-ET.TH PUZ-M140YKA2-ER.TH PUZ-M140YKA2R1.TH PUZ-M140YKA2-ETR1.TH			
	Pow	er supply ase, voltage,	cvcle)		1-pl	nase, 230 V, 50) Hz	3 - pl	nase, 400 V, 50) Hz			
	()	Max. curre		Α	20	26.5	30		11.5				
	Exte	ernal finish					Munsell 3	BY 7.8/1.1					
		rigerant conf	trol					nsion Valve					
	-	npressor						netic					
		Model			SVB220FBGMT	MVB33FBVMC	MVB33FBVMC	SVB220FBAMT	MVB33FBVMC	MVB33FBVMC			
		Motor outp	ut	kW	1.5	2.5	2.5	1.5	2.5	2.5			
		Starter type	9		Direct input								
		Protection				Shell thermistor							
					H.P. switch								
	Hea	t exchanger	-		Plate fin coil								
	Fan	Fan (drive)	x No.		Propeller fan x 1								
		Fan motor ou	tput kW		0.200								
		Air volume			79	86	86	79	86	86			
	Nois	se level	Cooling	SPL(dB)	51	54	55	51	54	55			
		Heating		SPL(dB)	54	56	57	54	56	57			
			Cooling	PWL(dB)	70	72	73	70	72	73			
	Dim	ensions	W	mm(inch)			1,050 (4	11-5/16)					
			D	mm(inch)			330+40 (1	3+1-3/16)					
			Н	mm(inch)			981 (3	88-5/8)					
	Wei	ght		kg	76	84	84	78	85	85			
	Refr	rigerant					R						
		Charge		kg	3.1	3.6	3.6	3.1	3.6	3.6			
		Oil (Model)		CC	700 (FW68S)	1100	1100	700 (FW68S)	1100	1100			
						(FW68S)	(FW68S)		(FW68S)	(FW68S)			
	Pipe	size O.D	Liquid	mm(inch)			9.52	(3/8)					
l g	'		Gas	mm(inch)				3 (5/8)					
교	Conn	nection	Indoor sid			Flared							
F	meth		Outdoor s					red					
REFRIGERANT PIPING	Betw	veen the or & Outdoor	Height difference	m			Maxim	um 30					
			Piping length	m	Maximum 55	Maxim	num 65	Maximum 55	Maxim	num 65			

4

DATA

4-1. REFILLING REFRIGERANT CHARGE (R32: kg)

Service Ref.	Piping length (one way)									Initial		
Service Rei.	5 m	10 m	15 m	20 m	25 m	30 m	40 m	50 m	55 m	60 m	65 m	charged
PUZ-M100VKA2(-ET/-ER).TH	3.1	3.1	3.1	3.1	3.1	3.1	3.5	3.9	4.1	-	-	3.1
PUZ-M125VKA2(-ET/-ER).TH PUZ-M140VKA2(-ET/-ER).TH	3.6	3.6	3.6	3.6	3.6	3.6	4.0	4.4	4.6	4.8	5.0	3.6
PUZ-M100YKA2(-ET/-ER).TH PUZ-M100YKA2(-ET)R1.TH	3.1	3.1	3.1	3.1	3.1	3.1	3.5	3.9	4.1	-	-	3.1
PUZ-M125YKA2(-ET/-ER).TH PUZ-M125YKA2(-ET)R1.TH	3.6	3.6	3.6	3.6	3.6	3.6	4.0	4.4	4.6	4.8	5.0	3.6
PUZ-M140YKA2(-ET/-ER).TH PUZ-M140YKA2(-ET)R1.TH	ა.ნ	3.0	3.0	3.0	3.0	3.0	4.0	4.4	4.0	4.0	5.0	3.0


Additional charge is required for pipes longer than 30 m.


4-2. COMPRESSOR TECHNICAL DATA


(Winding temperature at 20°C)


Service Ref.		PUZ-M100VKA2(-ET/-ER).TH	PUZ-M100YKA2(-ET/-ER).TH PUZ-M100YKA2(-ET)R1.TH	PUZ-M125/140VKA2(-ET/-ER).TH PUZ-M125/140YKA2(-ET/-ER).TH PUZ-M125/140YKA2(-ET)R1.TH
Compressor m	nodel	SVB220FBGMT	SVB220FBAMT	MVB33FBVMC
Winding	U-V	0.95	1.64	0.88
resistance U-W (Ω) W-V		0.95	1.64	0.88
		0.95	1.64	0.88

4-3. NOISE CRITERION CURVES










4-4. STANDARD OPERATION DATA


Represe	ntative matching	g		PLA-M100EA2	2(-ET/-ER).UK	PLA-M125EA2	2(-ET/-ER).UK	PLA-M140EA2(-ET/-ER).UK	
Mode				COOLING	HEATING	COOLING	HEATING	COOLING	HEATING
Total	Capacity W		W	9.5	11.2	12.1	13.5	13.4	15.0
	input		kW	2.71	3.01	4.01	3.63	4.96	4.39
Electrical	Indoor			PLA-M100EA2	2(-ET/-ER).UK	PLA-M125EA2	2(-ET/-ER).UK	PLA-M140EA	2(-ET/-ER).UK
circuit	Phase, Hz			1,	50	1,	50	1,	50
	Voltage		V	23	30	23	30	23	30
	Current		Α	0.46	0.44	0.66	0.64	0.66	0.64
	Outdoor			PUZ-M100VKA	2(-ET/-ER).TH	PUZ-M125VKA	2(-ET/-ER).TH	PUZ-M140VKA	2(-ET/-ER).TH
				PUZ-M100YKA		PUZ-M125YKA			(2(-ET/-ER).TH
				PUZ-M100YK	A2(-ET)R1.TH	PUZ-M125YK	A2(-ET)R1.TH	PUZ-M140YK	A2(-ET)R1.TH
	Phase, Hz			1, 50	3, 50	1, 50	3, 50	1, 50	3, 50
	Voltage		V	230	400	230	400	230	400
	Current		Α	11.7/4.2	13.0/4.7	17.4/6.3	15.6/5.6	21.5/7.8	19.0/6.9
Refrigerant	Discharge pres	sure	MPa	2.93	2.70	3.12	2.62	3.28	2.79
circuit	Suction pressu	re	MPa	0.96	0.70	0.89	0.69	0.84	0.66
	Discharge temper	Discharge temperature °C		90.2	88.7	89.4	81.7	91	88.7
	Condensing tempe	rature	°C	38.0	44.7	39.8	43.5	40.3	45.9
	Suction tempera	ture	°C	14.1	1.3	7.9	0.0	5.6	-0.9
	Ref. pipe lengtl	h	m	7.	5	7.	5	7	.5
Indoor	Intake air	DB	°C	27	20	27	20	27	20
side	temperature	WB	°C	19	14	19	14	19	14
	Discharge air temperature	DB	°C	13.6	40.1	11.9	41.7	11.3	44.5
Outdoor	Intake air	DB	°C	35	7	35	7	35	7
side	temperature	WB	°C	24	6	24	6	24	6
SHF				0.77	_	0.72		0.72	_
BF				0.16	_	0.10	_	0.10	_

The unit of pressure has been changed to MPa based on international SI system. The conversion factor is: 1 (MPa) = $10.2 \, (kgf/cm^2)$

OUTLINES AND DIMENSIONS




PUZ-M100VKA2(-ET/-ER).TH



*2. SW6-1 to 3: Function switch


Never splice the power cable or the indoor-outdoor connection cable, otherwise it may result in a smoke, a fire or communication failure.

PUZ-M125VKA2(-ET/-ER).TH PUZ-M140VKA2(-ET/-ER).TH




Never splice the power cable or the indoor-outdoor connection cable, otherwise it may result in a smoke, a fire or communication failure.

PUZ-M100YKA2(-ET/-ER).TH PUZ-M125YKA2(-ET/-ER).TH PUZ-M140YKA2(-ET/-ER).TH



PUZ-M100YKA2(-ET)R1.TH PUZ-M125YKA2(-ET)R1.TH PUZ-M140YKA2(-ET)R1.TH





WIRING SPECIFICATIONS

7-1. FIELD ELECTRICAL WIRING (power wiring specifications)

				• .	
Outdoor m	nodel name		PUZ-M100/125VKA2	PUZ-M140VKA2	PUZ-M100/125/140YKA2
Outdoor ur	nit power supply		~/N (1-phase), 50 Hz, 230 V	~/N (1-phase), 50 Hz, 230 V	3N~ (3-phase 4-wires), 50 Hz, 400 V
Outdoor un	nit input capacity Main switch (Breaker)	*1	32 A	40 A	16 A
e e	Outdoor unit power supply	*5	3 × Min 6	3 × Min 6	5 × Min 1.5
Wire size	Indoor unit-Outdoor unit		3 × 1.5 (Polar)	3 × 1.5 (Polar)	3 × 1.5 (Polar)
Wiring Wi No. x siz (mm²)	Indoor unit-Outdoor unit earth	*2	1 × Min 1.5	1 × Min. 1.5	1 × Min 1.5
≥z	Remote controller-Indoor unit	*3	2 × 0.3 (Non-polar)	2 × 0.3 (Non-polar)	2 × 0.3 (Non-polar)
rating	Outdoor unit L-N (1-phase) Outdoor unit L1-N, L2-N, L3-N (3-phase)	*4	230 V AC	230 V AC	230 V AC
±=	Indoor unit-Outdoor unit S1-S2	*4	230 V AC	230 V AC	230 V AC
Circuit	Indoor unit-Outdoor unit S2-S3	*4	28 V DC	28 V DC	28 V DC
	Remote controller-Indoor unit	*4	12 V DC	12 V DC	12 V DC

^{*1.} A breaker with at least 3.0 mm contact separation in each pole shall be provided. Use earth leakage breaker (NV)

Make sure that the current leakage breaker is one compatible with higher harmonics.

Always use a current leakage breaker that is compatible with higher harmonics as this unit is equipped with an inverter The use of an inadequate breaker can cause the incorrect operation of inverter.

*2. Max. 45 m

If 2.5 mm2 used. Max. 50 m

12.5 mm² used and S3 separated, Max. 80 m
 Use one cable for S1 and S2 and another for S3 as shown in the picture.
 Max. 50 m Total Max. for PEY. Wiring size 3 × 1.5 (Polar).

*3. The 10 m wire is attached in the remote controller accessory

*4. The figures are NOT always against the ground.


\$3 terminal has DC 28 V against \$2 terminal. However between \$3 and \$1, these terminals are NOT electrically insulated by the transformer or other device.

*5. In multi-phase appliances, the color of the neutral conductor of the supply cord, if any, shall be blue.

⚠ Caution: Be sure to install N-Line. Without N-Line, it could cause damage to the unit.

Notes: 1. Wiring size must comply with the applicable local and national code

- 2. Power supply cables and Indoor/Outdoor unit connecting cables shall not be lighter than polychloroprene sheathed flexible cable. (Design 60245 IEC 57)
- 3. Install an earth line longer than power cables.




⚠ Warning:


In case of A-control wiring, there is high voltage potential on the S3 terminal caused by electrical circuit design that has no electrical insulation between power line and communication signal line. Therefore, please turn off the main power supply when servicing. And do not touch the S1, S2, S3 terminals when the power is energized. If isolator should be used between indoor unit and outdoor unit, please use 3-pole type.

Never splice the power cable or the indoor-outdoor unit connection cable, otherwise it may result in a smoke, a fire or communication failure.


1:1 system **Electrical wiring**



Synchronized twin and triple system Electrical wiring Synchronized twin



· Synchronized triple




7-2. SEPARATE INDOOR UNIT/ OUTDOOR UNIT POWER SUPPLIES

The following connection patterns are available.

The outdoor unit power supply patterns vary on models.

1:1 System

The optional indoor power supply terminal kit is required.




- Outdoor unit power supply
- ® Earth leakage breaker
- © Wiring circuit breaker or isolating switch
- @ Outdoor unit
- (E) Indoor unit/outdoor unit connecting cords
- © Remote controller
- @ Indoor unit
- (I) Option
- Indoor unit power supply

Affix a label B that is included with the manuals near each wiring diagram for the indoor and outdoor units.

Simultaneous twin/triple system

<For models without heater>

The optional indoor power supply terminal kit is required




- Outdoor unit power supply
- ® Earth leakage breaker
- @ Wiring circuit breaker or isolating switch
- Outdoor unit
- (E) Indoor unit/outdoor unit connecting cables
- @ Remote controller
- @ Indoor unit
- (H) Option
- Indoor unit power supply
- (i) Indoor unit earth

Affix a label B that is included with the manuals near each wiring diagram for the indoor and outdoor units.

If the indoor and outdoor units have separate power supplies, refer to the table below. If the optional indoor power supply terminal kit is used, change the indoor unit electrical box wiring referring to the figure in the right and the DIP switch settings of the outdoor unit control board.

	Indoor unit specifications
Indoor power supply terminal kit (option)	Required
Indoor unit electrical box connector connection change	Required
Label affixed near each wiring diagram for the indoor and outdoor units	Required
Outdoor unit DIP switch settings (when using separate indoor unit/outdoor unit power supplies only)	ON 3 OFF 1 2 (SW8) Set the SW8-3 to ON.

There are 3 types of labels (labels A, B, and C). Affix the appropriate labels to the units according to the wiring method.



Separate indoor unit/outdoor unit power supplies

Indoor	r model name	50–140	
Indoor	r unit power supply	~/N (1-phase), 50 Hz, 230 V	
Indoor	runit input capacity	*1	16 A
Main s	switch (Breaker)	ı	10 A
SZ.	Indoor unit power supply		3×Min 1.5
P. S. C.	Indoor unit power supply earth		1 × Min 1.5
Wire No.xs (mm²)	Indoor unit-Outdoor unit	*2	2 × Min 0.3
S = S	Indoor unit-Outdoor unit earth		_
3	Remote controller-Indoor unit	*3	2 × 0.3 (Non-polar)
	Indoor unit L-N	*4	230 V AC
Sirouit	Indoor unit-Outdoor unit S1-S2	*4	_
Indoor unit-Outdoor unit S1-S2 Indoor unit-Outdoor unit S2-S3		*4	28 V DC
	Remote controller-Indoor unit	*4	12 V DC
	1 20 11 10 10	42 2 1 1	

^{*1.} A breaker with at least 3 mm contact separation in each pole shall be provided. Use earth leakage breaker (NV).

- Notes: 1. Wiring size must comply with the applicable local and national code.
 - 2. Power supply cables and indoor unit/outdoor unit connecting cables shall not be lighter than polychloroprene sheathed flexible cable. (Design 60245 IEC 57)
 - 3. Install an earth line longer than power cables.

The breaker shall be provided to ensure disconnection of all active phase conductor of the supply.

^{*2.} Max. 120 m

^{*3.} Max. 500 m (Max. 200 m when 2 remote controllers are used)

^{*4.} The figures are NOT always against the ground.

7-3. INDOOR - OUTDOOR CONNECTING CABLE

The cable shall not be lighter than design 60245 IEC or 60227 IEC.

Outdoor power cumply	Wire No. × Size (mm²)				
Outdoor power supply	Max. 45 m	Max. 50 m			
Indoor unit-Outdoor unit	3 × 1.5 (polar)	3 × 2.5 (polar)			
Indoor unit-Outdoor unit earth	1 × Min. 1.5	1 × Min. 2.5			

Note: The Max. cable length may vary depending on the condition of installation, humidity or materials, etc.

Indoor/Outdoor separate power supply	Wire No. × Size (mm²) Max. 120 m			
Indoor unit-Outdoor unit	2 × Min. 0.3			
Indoor unit-Outdoor unit earth	_			


Note: The optional indoor power supply terminal kit is necessary.

Be sure to connect the indoor-outdoor connecting cables directly to the units (no intermediate connections). Intermediate connections can lead to communication errors if water enters the cables and causes insufficient insulation to ground or a poor electrical contact at the intermediate connection point.

7-4. M-NET WIRING METHOD

(Points to note)

- (1) Outside the unit, transmission wires should stay away from electric wires in order to prevent electromagnetic noise from making an influence on the signal communication. Place them at intervals of more than 5 cm. Do not put them in the same conduit tube.
- (2) Terminal block (TB7) for transmission wires should never be connected to 220–240 V power supply. If it is connected, electronic parts on M-NET P.C. board may burn out.
- (3) Use 2-core × 1.25 mm² shield wire (CVVS, CPEVS) for the transmission wire. Transmission signals may not be sent or received normally if different types of transmission wires are put together in the same multi-conductor cable. Never do this because this may cause a malfunction.




It would be acceptable if M-NET wire (non-polar, 2-cores) is arranged in addition to the wiring for A-control.

(4) Earth only one of any appliances through M-NET transmission wire (shield wire). Communication error may occur due to the influence of electromagnetic noise.

"Ed" error will appear on the LED display of outdoor unit.

"0403" error will appear on the centralized remote controller.




If there are more than 2 earthing spots on the shield wire, noise may enter into the shield wire because the earth wire and shield wire form 1 circuit and the electric potential difference occurs due to the impedance difference among earthing spots. In case of single spot earthing, noise does not enter into the shield wire because the earth wire and shield wire do not form 1 circuit.

To avoid communication errors caused by noise, make sure to observe the single spot earthing method described in the installation manual.

M-NET wiring


- (1) Use 2-core × 1.25 mm² shield wire for electric wires. (Excluding the case connecting to system controller.)
- (2) Connect the wire to the M-NET terminal block. Connect one core of the transmission wire (non-polar) to A terminal and the other to B. Peel the shield wire, twist the shield part to a string and connect it to S terminal.
- (3) In the system which several outdoor units are being connected, the terminal (A, B, S) on M-NET terminal block should be individually wired to the other outdoor unit's terminal, i.e. A to A, B to B and S to S. In this case, choose one of those outdoor units and drive a screw to fix an earth wire on the plate as shown on the right figure.



7-4-1. M-NET address setting


In A-control models, M-NET address and refrigerant address should be set only for the outdoor unit. Similar to CITY MULTI system, there is no need to set the address of outdoor unit and remote controller. To construct a central control system, the setting of M-NET address should be conducted only upon the outdoor unit. The setting range should be 1 to 50 (the same as that of the indoor unit in CITY MULTI system), and the address number should be consecutively set in a same group.

Address number can be set by using rotary switches (SW11 for 1st digit and SW12 for 2nd digit), which is located on the M-NET board of outdoor unit. (Initial setting: all addresses are set to "0".)




7-4-2. Refrigerant address setting

In the case of multiple grouping system (multiple refrigerant circuits in 1 group), indoor units should be connected by remote controller wiring (TB5) and the refrigerant address needs to be set. Leave the refrigerant addresses to "00" if the group setting is not conducted. Set the refrigerant address by using DIP SW1-3 to -6 on the outdoor controller board. [Initial setting: all switches are OFF. (All refrigerant addresses are "00".)]




7-4-3. Regulations in address settings

In the case of multiple grouping system, M-NET and refrigerant address settings should be done as explained in the above section. Set the lowest number in the group for the outdoor unit whose refrigerant address is "00" as its M-NET address.




Note: Refrigerant addresses can be overlapped if they are in the different group.



Note:

In group B, M-NET address of the outdoor unit whose refrigerant address is "00" is not set to the minimum in the group. As "3" is right for this situation, the setting is wrong. Taking group A as a good sample, set the minimum M-NET address in the group for the outdoor unit whose refrigerant address is "00".

Unit: mm (inch)



8-1. REFRIGERANT COLLECTING (PUMP DOWN)

When relocating or disposing of the indoor/outdoor unit, pump down the system following the procedure below so that no refrigerant is released into the atmosphere.

- ① Turn off the power supply (circuit breaker).
- @ Connect the low pressure valve on the gauge manifold to the charge plug (low pressure side) on the outdoor unit.
- 3 Close the liquid stop valve completely.
- Supply power (circuit breaker).
 - When power is supplied, make sure that "Centrally controlled" is not displayed on the remote controller. If "Centrally controlled" is displayed, the refrigerant collecting (pump down) cannot be completed normally.
 - Startup of the indoor-outdoor communication takes about 3 minutes after the power (circuit breaker) is turned on. Start the pump-down operation 3 to 4 minutes after the power (circuit breaker) is turned on.
- ⑤ Perform the refrigerant collecting operation (cooling test run).
 - Push the pump-down SWP switch (push-button type) on the control board of the outdoor unit. The compressor and ventilators (indoor and outdoor units) start operating (refrigerant collecting operation begins). (LED1 and LED2 on the control board of the outdoor unit are lit.)
 - Only push the pump-down SWP switch if the unit is stopped. However, even if the unit is stopped and the pump-down SWP switch is pushed less than 3 minutes after the compressor stops, the refrigerant collecting operation cannot be performed. Wait until the compressor has been stopped for 3 minutes and then push the pump-down SWP switch again.
- (approx. 0.5 to 0 kgf/cm²) and quickly stop the air conditioner.
 - Because the unit automatically stops in about 3 minutes when the refrigerant collecting operation is completed (LED1 off, LED2 lit), be sure to quickly close the gas stop valve. However, if LED1 is lit, LED2 is off, and the unit is stopped, open the liquid stop valve completely, close the valve completely after 3 minutes or more have passed, and then repeat step ⑤. (Open the gas stop valve completely.)
 - If the refrigerant collecting operation has been completed normally (LED1 off, LED2 lit), the unit will remain stopped until the
 power supply is turned off.
 - Note that when the extension piping is very long with a large refrigerant amount, it may not be possible to perform a pump-down operation. In this case, use refrigerant recovery equipment to collect all of the refrigerant in the system.
- Turn off the power supply (circuit breaker), remove the gauge manifold, and then disconnect the refrigerant pipes.

⚠ Warning:

When pumping down the refrigerant, stop the compressor before disconnecting the refrigerant pipes.

- If the refrigerant pipes are disconnected while the compressor is operating and the stop valve is open, the pressure in the refrigeration cycle could become extremely high if air is drawn in, causing the pipes to burst, personal injury, etc.
- Do not perform pump down work when there is a gas leak. The intake of air or other gases causes abnormally high pressure in the refrigeration cycle, which may cause explosion or injury.

8-2. START AND FINISH OF TEST RUN

- · Operation from the indoor unit
- Execute the test run using the installation manual for the indoor unit.
- · Operation from the outdoor unit
- By using the DIP switch SW4 on the control board of outdoor unit, test run can be started and finished, and its operation mode (cooling) can be set up.
- ① Turn on SW4-1 to start test run.
- ② Turn off SW4-1 to finish the test run.
- There may be a faint knocking sound around the machine room after power is supplied, but this is no problem with product because the linear expansion valve is just moving to adjust opening pulse.
- There may be a knocking sound around the machine room for several seconds after compressor starts operating, but this
 is no problem with product because the check valve itself, generates the sound because pressure difference is small in the
 refrigerant circuit.

TROUBLESHOOTING

9-1. TROUBLESHOOTING

<Check code display by self-diagnosis and actions to be taken for service (summary)>

Present and past check codes are logged, and they can be displayed on the wired remote controller and control board of outdoor unit. Actions to be taken for service, which depends on whether or not the trouble is reoccurring in the field, are summarized in the table below. Check the contents below before investigating details.

Unit conditions at service	Check code	Actions to be taken for service (summary)
The trouble is reoccurring.	Displayed	Judge the problem and take a corrective action according to "9-3. SELF-DIAGNOSIS ACTION TABLE".
	Not displayed	Conduct troubleshooting and ascertain the cause of the trouble according to "9-4. TROUBLESHOOTING OF PROBLEMS".
The trouble is not reoccurring.	Logged	 ①Consider the temporary defects such as the work of protection devices in the refrigerant circuit including compressor, poor connection of wiring, noise, etc. Re-check the symptom, and check the installation environment, refrigerant amount, weather when the trouble occurred, matters related to wiring, etc. ②Reset check code logs and restart the unit after finishing service. ③There is no abnormality in electrical component, controller board, remote controller, etc.
	Not logged	 ①Re-check the abnormal symptom. ②Conduct troubleshooting and ascertain the cause of the trouble according to "9-4. TROUBLESHOOTING OF PROBLEMS". ③Continue to operate unit for the time being if the cause is not ascertained. ④There is no abnormality concerning of parts such as electrical component, controller board, remote controller, etc.

9-2. CHECKPOINT UNDER TEST RUN

9-2-1. Before test run

- After installation of indoor and outdoor units, piping work and electric wiring work, re-check that there is no refrigerant leakage, loosened connections and incorrect polarity.
- Measure impedance between the ground and the power supply terminal block (L, N) on the outdoor unit by 500 V Megger and check that it is 1.0 MΩ or over.
- * Do not use 500 V Megger to indoor/outdoor connecting wire terminal block (S1, S2, S3) and remote controller terminal block (1, 2). This may cause malfunction.
- · Make sure that test run switch (SW4) is set to OFF before turning on power supply.
- Turn on power supply 12 hours before test run in order to protect compressor.
- For specific models which require higher ceiling settings or auto-recovery feature from power failure, make proper changes of settings referring to the description of "10. FUNCTION SETTING".

Make sure to read operation manual before test run. (Especially items to secure safety.)

9-2-2. TEST RUN

Refer to "14-4. TEST RUN" for operation procedure.

9-2-3. ERROR INFORMATION

Refer to "14-2. ERROR INFORMATION" when an error occurs.


9-2-4. ERROR HISTORY


Refer to "14-6. ERROR HISTORY" to check the errors occurred in the past.

9-2-5. SELF-DIAGNOSIS

Refer to "14-7. SELF-DIAGNOSIS" to search for the error history.

Refer to the following tables for details on the check codes. [Output pattern A]





[Output pattern A] Errors detected by indoor unit

[Output pattern A] Entri a detected by indoor drift					
Wireless remote controller Wired remote controller					
Beeper sounds/OPERATION INDICATOR lamp blinks (Number of times)	Check code	Symptom	Remarks		
1	P1	Intake sensor error			
2	P2	Pipe (TH2) sensor error			
	P9	Pipe (TH5) sensor error			
3	E6, E7	Indoor/outdoor unit communication error			
4	P4	Drain sensor error/Float switch connector (CN4F) open			
5	P5	Drain pump error			
	PA	Forced compressor stop(due to water leakage abnormality)			
6	P6	Freezing/Overheating protection operation	As for indoor unit, refer		
7	EE	Combination error between indoor and outdoor units	to indoor unit's service		
8	P8	Pipe temperature error	manual.		
9	E4, E5	Remote controller signal receiving error			
10	_	-			
11	Pb	Indoor unit fan motor error	1		
12 Fb (FB)*		Indoor unit control system error (memory error, etc.)			
14 PL		Abnormality of refrigerant circuit			
- E0, E		Remote controller transmission error			
-	E1, E2	Remote controller control board error			

[Output pattern B] Errors detected by unit other than indoor unit (outdoor unit, etc.)

[Output pattern b] Errors detected by drift other trial indoor drift (outdoor drift, etc.)						
Wireless remote controller	Wired remote controller					
Beeper sounds/OPERATION INDICATOR lamp blinks (Number of times)	Check code	Symptom				
1	E9	Indoor/outdoor unit communication error (Transmitting error) (Outdoor unit)				
2	UP	Compressor overcurrent interruption				
3	U3, U4	Open/short of outdoor unit thermistors				
4	UF	Compressor overcurrent interruption (When compressor locked)				
5 U2		Abnormal high discharging temperature/49C operated/ insufficient refrigerant				
6	U1, Ud (UD)*	Abnormal high pressure (63H operated)/Overheating protection operation				
7	U5	Abnormal temperature of heat sink				
8	U8	Outdoor unit fan protection stop				
9	U6	Compressor overcurrent interruption/Abnormal of power module				
10	U7	Abnormality of superheat due to low discharge temperature				
11 U9, UH		Abnormality such as overvoltage or undervoltage and abnormal synchronous signal to main circuit/ Current sensor error				
12	-	-				
13	-	-				
14	Others	Other errors (Refer to the technical manual for the outdoor unit.)				

^{1.} If the beeper does not sound again after the initial 2 beeps to confirm the self-check start signal was received and the OPERATION INDICATOR lamp does not come on, there are no error records.

2. If the beeper sounds 3 times continuously "beep, beep, beep (0.4 + 0.4 + 0.4 seconds)" after the initial 2 beeps to confirm the self-check start signal was received, the specified refrigerant address is incorrect.

^{*} The check code in the parenthesis indicates PAR-3xMAA ("x" represents 0 or later) model

9-3. SELF-DIAGNOSIS ACTION TABLE

<Abnormalities detected when the power is ON>

		No voltage is supplied to terminal block (TB1) of outdoor unit. a) Power supply breaker is turned off. b) Contact failure or disconnection of power supply terminal c) Open phase (L, L2 or N phase) Electric power is not supplied to power supply terminal of outdoor power circuit board. a) Contact failure of power supply terminal b) Open phase on the outdoor	,
		turned off. b) Contact failure or disconnection of power supply terminal c) Open phase (L, L2 or N phase) ② Electric power is not supplied to power supply terminal of outdoor power circuit board. a) Contact failure of power supply terminal b) Open phase on the outdoor	 b) Connection of power supply terminal block. (TB1) c) Connection of power supply terminal block. (TB1) ② Check following items. a) Connection of power supply terminal block.
		phase) ② Electric power is not supplied to power supply terminal of outdoor power circuit board. a) Contact failure of power supply terminal b) Open phase on the outdoor	block. (TB1) ② Check following items. a) Connection of power supply terminal block.
		to power supply terminal of out- door power circuit board. a) Contact failure of power supply terminal b) Open phase on the outdoor	a) Connection of power supply terminal block.
		power circuit board (Disconnection of terminal on outdoor power circuit board)	(TB1) b) Connection of terminal on outdoor power circuit board.
		Electric power is not supplied to outdoor controller circuit board. a) Disconnection of connector (CNDC)	③ Check connection of the connector (CNDC) on the outdoor controller circuit board. Refer to "9-8. TEST POINT DIAGRAM".
		Disconnection of reactor (DCL or ACL)	Check connection of reactor. (DCL or ACL) Refer to "6. WIRING DIAGRAM".
None	_	(5) Disconnection of outdoor power circuit board (PUZ-M·VKA2)/ outdoor noise filter circuit board (PUZ-M·YKA2) or parts failure in outdoor power circuit board (PUZ-M·VKA2)/outdoor noise filter circuit board (PUZ-M·YKA2)	 a) Check connection of outdoor power circuit board (PUZ-M·VKA2)/outdoor noise filter circuit board (PUZ-M·YKA2). b) Replace outdoor power circuit board (PUZ-M·VKA2)/outdoor noise filter circuit board (PUZ-M·YKA2). Refer to "9-8. TEST POINT DIAGRAM".
		Defective outdoor power circuit board	Replace outdoor power circuit board.
		Open of rush current protect resistor (RS) (PUZ-M·YKA2)	 Replace rush current protect resistor (RS) * Power circuit board might be short-circuit. Check the power circuit board. (Refer to "9-8. TEST POINT DIAGRAM")
		Defective outdoor controller circuit board	Replace controller board (When items above are checked but the units cannot be repaired.)
for 3 minutes cont ply. 63H: High pressu	connector circuit is open tinuously after power sup-	of 63H connector on outdoor controller circuit board ② Disconnection or contact failure of 63H	Check connection of 63H connector on outdoor controller circuit board. Refer to "9-8. TEST POINT DIAGRAM". Check the 63H side of connecting wire.
(5201)		 ③ 63H is working due to defective parts. ④ Defective outdoor controller circuit board 	(3) Check continuity by multimeter. Replace the parts if the parts are defective. (4) Replace outdoor controller circuit board.

Note: Refer to indoor unit section for code P and code E.

OCH773C 31

Check code	Abnormal points and detection method	Cause	Judgment and action
EA (6844)	Miswiring of indoor/outdoor unit connecting wire 1. Outdoor controller circuit board can automatically check the number of connected indoor units. Abnormal if the number cannot be checked automatically due to miswiring of indoor/outdoor unit connecting wire and etc. after power is turned on for 4 minutes. 2. Abnormal if outdoor controller circuit board recognizes excessive number of indoor units.	Contact failure or miswiring of indoor/outdoor unit connecting wire Diameter or length of indoor/outdoor unit connecting wire is out of specified capacity. Excessive number of indoor units are connected to 1 outdoor unit. (4 units or more) Defective transmitting receiving circuit of outdoor controller circuit board Defective transmitting receiving circuit of indoor controller board Defective indoor power board	 ① Check disconnection or looseness or polarity of indoor/outdoor unit connecting wire of indoor and outdoor units. ② Check diameter and length of indoor/outdoor unit connecting wire. Total wiring length: 80 m (including wiring connecting each indoor unit and between indoor and outdoor unit) Also check if the connection order of flat cable is S1, S2, S3. ③ Check the number of indoor units that are connected to one outdoor unit. (If EA is detected)
		2 or more outdoor units have refrigerant address "0" . (In case of group control) Noise has entered into power supply or indoor / outdoor unit connecting wire.	Turn the power off once, and on again to check. Replace outdoor controller circuit board, indoor controller board or indoor power board if abnormality occurs again. Check if refrigerant addresses (SW1-3 to SW1-6 on outdoor controller circuit board) are evolvening in case of graph centrol.
Eb (6845)	Miswiring of indoor/outdoor unit connecting wire (reverse wiring or disconnection) Outdoor controller circuit board can automatically set the unit number of indoor units. Abnormal if the indoor unit number cannot be set within 4 minutes after power on because of Miswiring (reverse wiring or disconnection) of indoor/outdoor unit connecting wire.	Contact failure or miswiring of indoor/outdoor unit connecting wire Diameter or length of indoor/outdoor unit connecting wire is out of specified capacity. Defective transmitting receiving circuit of outdoor controller circuit board Defective transmitting receiving circuit of indoor controller board Defective indoor power board Defective indoor power board 2 or more outdoor units have refrigerant address "0". (In case of group control) Noise has entered into power supply or indoor/outdoor unit connecting wire.	are overlapping in case of group control system. (a) Check transmission path, and remove the cause. The descriptions above, ①—(a), are common for EA, Eb and EC.
EC (6846)	Startup time over The unit cannot finish startup process within 4 minutes after power on.	Contact failure of indoor/ outdoor unit connecting wire Diameter or length of indoor/ outdoor unit connecting wire is out of specified capacity. 2 or more outdoor units have refrigerant address "0". (In case of group control) Noise has entered into power supply or indoor/outdoor unit connecting wire.	

OCH773C 32

<Abnormalities detected while unit is operating>

Check code	Abnormal points and detection method	Cause	Judgment and action
U1 (1302)	High pressure (High pressure switch 63H operated) Abnormal if high pressure switch 63H (4.15MPa) operated during compressor operation.	Short cycle of indoor unit Clogged filter of indoor unit Decreased airflow caused by dirt of indoor fan Dirt of indoor heat exchanger Locked indoor fan motor Malfunction of indoor fan motor Defective operation of stop valve (Not full open) Clogged or broken pipe Locked outdoor fan motor Malfunction of outdoor fan motor Malfunction of outdoor fan motor Short cycle of outdoor unit Dirt of outdoor heat exchanger Decreased airflow caused by defective inspection of outside temperature thermistor (It detects lower temperature than actual temperature.)	①—⑥ Check indoor unit and repair defect. ② Check if stop valve is fully open. ③ Check piping and repair defect. ⑤—② Check outdoor unit and repair defect. ③ Check the detected temperature of outside temperature thermistor on LED display. (SW2 on A-Control Service Tool: Refer to "9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS".) ⑥—⑥ Turn the power off and check F5 is displayed when the power is turned again. When F5 is displayed, refer to "Judgment and action" for F5. ⑦ Check linear expansion valve. Refer to "9-5. HOW TO CHECK THE PARTS".
U2 (TH4: 1102) (TH33: 1132)	High discharging temperature High comp. surface temperature 1. Abnormal if discharge thermistor (TH4) exceeds 115°C or 110°C continuously for 5 minutes. Abnormal if condenser/evaporator temperature thermistor (TH5) exceeds 40°C during defrosting and discharge thermistor (TH4) exceeds 110°C. 2. Abnormal if discharge superheat (TH4 - TH5) increases. All the conditions are detected simultaneously for 10 minutes continuously after 6 minutes past from compressor startup (including the thermostat indication or recovery from defrosting). • During compressor operation (in Cooling only) • When discharge superheat is less than 80°C in Cooling. • When condensing temp of TH6 is more than -40°C. (In Cooling only.) 3. Abnormal if comp. surface temperature thermistor (TH33) exceeds 115°C or 110°C continuously for 5 minutes.	Overheated compressor operation caused by shortage of refrigerant Defective operation of stop valve Defective thermistor Defective outdoor controller board Defective action of linear expansion valve	Otheck intake superheat. Check leakage of refrigerant. Charge additional refrigerant. Check if stop valve is fully open. Turn the power off and check if U3 is displayed when the power is on again. When U3 is displayed, refer to "Judgement and action" for U3. Check linear expansion valve. Refer to "9-5. HOW TO CHECK THE PARTS".
U3 (TH4: 5104) (TH33: 5132)	Open/short circuit of discharge thermistor (TH4) / comp. surface thermistor (TH33) Abnormal if open (TH4: -20°C or less, TH33: -20°C or less) or short (217°C or more) is detected during compressor operation. (Detection is inoperative for 10 minutes of compressor starting process.)	Disconnection or contact failure of connector (TH4/TH33) on the outdoor controller circuit board Defective thermistor Defective outdoor controller circuit board	 ① Check connection of connector (TH4/TH33) on the outdoor controller circuit board. Check breaking of the lead wire for thermistor (TH4/TH33). Refer to "9-8. TEST POINT DIAGRAM". ② Check resistance value of thermistor (TH4/TH33) or temperature by microprocessor. (Thermistor/TH4/TH33: Refer to "9-5. HOW TO CHECK THE PARTS".) (SW2 on A-Control Service Tool: Refer to "9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS".) ③ Replace outdoor controller board.

OCH773C 33

Check code	Abnormal points and detection method	Cause	Judgment and action	
Open/short of outdoor unit thermistors (TH3, TH6, TH7, and TH8) Abnormal if open or short is detected during compressor operation. Open detection of thermistor TH3 and TH6 is inoperative for 10 seconds to 10 minutes after compressor started. Note: Check which unit has abnormality in its thermistor by switching the mode of SW2. (PAC-SK52ST) (Refer to "9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS".)		Disconnection or contact failure of connectors Outdoor controller circuit board: TH3, TH6/TH7 Outdoor power circuit board: CN6 Defective thermistor Defective outdoor controller circuit board	 Check connection of connector (TH3, TH6/TH7) on the outdoor controller circuit board. Check connection of connector (CN6) on the outdoor power circuit board. Check breaking of the lead wire for thermistor TH3, TH6, TH7, and TH8). Refer to "9-8. TEST POINT DIAGRAM". Check resistance value of thermistor (TH3, TH6, TH7, and TH8) or check temperature by microprocessor. (Thermistor/TH3, TH6, TH7, and TH8: Refer to "9-5. HOW TO CHECK THE PARTS".) (SW2 on A-Control Service Tool: Refer to "9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS") Replace outdoor controller circuit board. Note: Emergency operation is available in case of abnormalities of TH3, TH6 and TH7. Refer to "9-7. EMERGENCY OPERATION". 	
		ermistors	Open detection Short detection	
		Name stor <liquid></liquid>	-48°C or below 90°C or above	
		<2-phase pipe>	-48°C or below 90°C or above	
		or <ambient></ambient>	-48°C or below 90°C or above	
	TH8 Thermist	or <heatsink></heatsink>	-27°C or below 102°C or above	
	Temperature of heatsink Abnormal if heatsink thermistor (TH8) detects temperature indicated below. PUZ-M100VKA2	The outdoor fan motor is locked. Failure of outdoor fan motor Airflow path is clogged. Rise of ambient temperature	①② Check outdoor fan. ③ Check airflow path for cooling. ④ Check if there is something which causes temperature rise around outdoor unit. (Upper limit of ambient temperature is 46°C.) Turn off power, and on again to check if U5 is displayed within 30 minutes. If U4 is displayed instead of U5, follow the	
U5 (4230)		Defective thermistor Defective input circuit of outdoor power circuit board Failure of outdoor fan drive circuit	action to be taken for U4. (a) Check resistance value of thermistor (TH8) or temperature by microprocessor. (Thermistor/TH8: Refer to "9-5. HOW TO CHECK THE PARTS".) (SW2 on A-Control Service Tool: Refer to "9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS".) (a) Replace outdoor power circuit board. (b) Replace outdoor controller circuit board.	
U6 (4250)	Power module Check abnormality by driving power module in case overcurrent is detected. (UF or UP error condition)	Outdoor stop valve is closed. Decrease of power supply voltage Looseness, disconnection or reverse of compressor wiring connection Defective compressor Defective outdoor power circuit board	Open stop valve. Check facility of power supply. Correct the wiring (U-V-W phase) to compressor. Refer to "9-8. TEST POINT DIAGRAM (Outdoor power circuit board)". Check compressor referring to "9-5. HOW TO CHECK THE PARTS". Replace outdoor power circuit board.	
U7 (1520)	Too low superheat due to low discharge temperature Abnormal if discharge superheat is continuously detected less than or equal to -15°C for 3 minutes even though linear expansion valve has minimum open pulse after compressor starts operating for 10 minutes.	Disconnection or loose connection of Discharge thermistor (TH4) Defective holder of Discharge thermistor Disconnection or loose connection of linear expansion valve's coil Disconnection or loose connection of linear expansion valve's connection of linear expansion valve's connector Defective linear expansion valve	Check the installation conditions of discharge thermistor (TH4). Check the coil of linear expansion valve. Refer to "9-6.HOW TO CHECK THE COMPONENT". Check the connection or contact of LEV-A and LEV-B on outdoor controller circuit board. Check linear expansion valve. Refer to "9-5. HOW TO CHECK THE PARTS"	
U8 (4400)	Outdoor fan motor Abnormal if rotational frequency of the fan motor is not detected during DC fan motor operation. Fan motor rotational frequency is abnormal if; • 100 rpm or below detected continuously for 15 seconds at 20°C or more outside air temperature. • 50 rpm or below or 1500 rpm or more detected continuously for 1 minute.		① Check or replace the DC fan motor. ② Check the voltage of the outdoor circuit controller board during operation. ③ Replace the outdoor circuit controller board. (when the failure is still indicated even after performing the action ① above.)	

Abnorm	al point and detection method	Cause	Judgment and action	
Detailed codes				
01	Overvoltage error Increase in DC bus voltage to PUZ-M·VKA2: 430 V PUZ-M·YKA2: 760 V	Abnormal increase in power source voltage Disconnection of compressor wiring Defective outdoor power circuit board Compressor has a ground fault.	Check the field facility for the power supply. Correct the wiring (U-V-W phase) to compressor. Refer to "9-8. TEST POINT DIAGRAM (Outdoor power circuit board)". Replace outdoor power circuit board. Check compressor for electrical insulation. Replace compressor.	
02	Undervoltage error Instantaneous decrease in DC bus voltage to PUZ-M·VKA2: 200 V PUZ-M·YKA2: 350 V	Decrease in power source voltage, instantaneous stop. Defective converter drive circuit in outdoor power circuit board (PUZ-M·VKA2) Defective 52C drive circuit in outdoor power circuit board Disconnection or loose connection of rush current protect resistor RS (PUZ-M·YKA2) Defective rush current protect resistor RS (PUZ-M·YKA2) Disconnection or loose connection of CN2 on the outdoor power circuit board /controller circuit board (PUZ-M·VKA2) Power circuit failure on DC supply for 15 V DC output on outdoor controller circuit board (PUZ-M·VKA2)	Check the field facility for the power supply. Replace outdoor power circuit board. (PUZ-M·VKA2) Replace outdoor power circuit board. Check RS wiring. (PUZ-M·YKA2) Replace RS. (PUZ-M·YKA2) Check CN2 wiring. (PUZ-M·VKA2)	
04	Input current sensor error/ L1-phase open error • Decrease in input current through outdoor unit to 0.1 A only if operation frequency is more than or equal to 40 Hz or compressor current is more than or equal to 6 A.	Disconnection or loose connection between TB1 and outdoor noise filter circuit board (PUZ-M·YKA2) Disconnection or loose connection of CN5 on the outdoor power circuit board/CNCT on the outdoor noise filter board (PUZ-M·YKA2) Defective ACCT (AC current trans) on the outdoor noise filter circuit board (PUZ-M·YKA2) Defective input current detection circuit in outdoor power circuit board Defective outdoor controller circuit board	Check the field facility for the power supply. (PUZ-M·YKA2) Check the wiring between TB1 and outdoor noise filter circuit board. (PUZ-M·YKA2) Check CN5/CNCT wiring. (PUZ-M·YKA2) Replace outdoor noise filter circuit board. (PUZ-M·YKA2) Replace outdoor power circuit board. Replace outdoor controller circuit board.	
08	Abnormal power synchronous signal • No input of power synchronous signal to power circuit board • Power synchronous signal of 44 Hz or less, or 65 Hz or more is detected on power circuit board.	Distortion of power source voltage, noise superimposition. Disconnection or loose connection of earth wiring Disconnection or loose connection of CN2 on the outdoor power circuit board /controller circuit board Defective power synchronous signal circuit in outdoor controller circuit board Defective power synchronous signal circuit in outdoor power circuit board	Check the field facility for the power supply. Check earth wiring. Check CN2 wiring. Replace outdoor controller circuit board Replace outdoor power circuit board.	
	Detailed codes 01 02	Overvoltage error Increase in DC bus voltage to PUZ-M-VKA2: 430 V PUZ-M-YKA2: 760 V Undervoltage error Instantaneous decrease in DC bus voltage to PUZ-M-VKA2: 200 V PUZ-M-YKA2: 350 V Input current sensor error/ L1-phase open error Decrease in input current through outdoor unit to 0.1 A only if operation frequency is more than or equal to 40 Hz or compressor current is more than or equal to 6 A. Abnormal power synchronous signal No input of power synchronous signal to power circuit board Power synchronous signal of 44 Hz or less, or 65 Hz or more is detected on power or increase in more is detected on power or increase in DC bus voltage to Puz-M-VKA2: 350 V Abnormal power synchronous is ignal or 44 Hz or less, or 65 Hz or more is detected on power or increase in DC bus voltage to Puz-M-VKA2: 350 V	Detailed Codes To find out the detail history (latest) about U9 error, turn ON SW2-1, 2-2 at Refer to "9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS". Overvoltage error Increase in DC bus voltage to PUZ-M-YKA2: 430 V PUZ-M-YKA2: 430 V PUZ-M-YKA2: 760 V Instantaneous decrease in DC bus voltage to PUZ-M-YKA2: 200 V PUZ-M-YKA2: 200 V PUZ-M-YKA2: 200 V PUZ-M-YKA2: 350 V Defective converter drive circuit in outdoor power circuit board on or loose connection of rush current protect resistor RS (PUZ-M-YKA2) Defective suddoor power circuit board (PUZ-M-YKA2) Defective suddoor power or loose connection of rush current protect resistor RS (PUZ-M-YKA2) Defective suddoor power circuit board on rolose connection of rush current protect resistor RS (PUZ-M-YKA2) Defective ush current protect resistor RS (PUZ-M-YKA2) Defective include rush outdoor power circuit board on rolose connection of CN2 on the outdoor power circuit board on rolose connection of CN2 on the outdoor power circuit board (PUZ-M-YKA2) Power circuit board (PUZ-M-YKA2) Disconnection or loose connection between TB1 and outdoor noise filter circuit board (PUZ-M-YKA2) Disconnection or loose connection of CN5 on the outdoor power circuit board (PUZ-M-YKA2) Defective ACCT (AC current trans) on the outdoor noise filter circuit board (PUZ-M-YKA2) Defective outdoor power circuit board (PUZ-M-YKA2) Defective outdoor power circuit board (PUZ-M-YKA2) Defective outdoor noise filter circuit board (PUZ-M-YKA2) Defective outdoor nois	

From the previous page.

Check code	Abnormal point and detection method		Cause	Judgment and action
U9 (4220)	Detailed codes 10	PFC error (Overvoltage/ Undervoltage/Overcurrent) • PFC detected any of the following: a) Increase in DC bus voltage to 460 V b) Decrease in PFC control voltage to 12 V DC or lower c) Increase in input current (PUZ-M·VKA2 only) PFC/IGBT error (Undervoltage) • When Compressor is running, DC bus voltage stays at 310V or lower for consecutive 10 seconds. (PUZ-M·VKA2 only)	Abnormal increase in power source voltage Decrease in power source voltage, instantaneous stop. Disconnection of compressor wiring Misconnection of reactor (DCL) Defective outdoor power circuit board Defective Reactor (DCL) Disconnection or loose connection of CN2 on the outdoor power circuit board Incorrect switch settings on the outdoor controller circuit board for model select Defective outdoor power circuit board Defective outdoor controller circuit board Defective outdoor controller circuit board	 Check the field facility for the power supply Correct the wiring (U.V.W phase) to compressor. Refer to "9-8. TEST POINT DIAGRAM". Correct the wiring of reactor (DCL) Replace outdoor power circuit board. Replace Reactor (DCL). Check CN2 wiring. ① Correction of a model select Replace outdoor power circuit board. Replace outdoor controller circuit board.
Ud (UD)* (1504)	Abnormal if outdoor pipe thermistor (TH3) detects 70°Cor more during compressor operation.		Defective outdoor fan (fan motor) or short cycle of outdoor unit during cooling operation Defective outdoor pipe thermistor (TH3) Defective outdoor controller board	Check outdoor unit air passage. ② Turn the power off and on again to check the check code. If U4 is displayed, follow the U4 processing direction. *The check code in the parenthesis indicates PAR-3xMAA ("x" represents 0 or later) model.
UF (4100)	Compressor overcurrent interruption (When compressor locked) Abnormal if overcurrent of DC bus or compressor is detected within 30 seconds after compressor starts operating.		Stop valve is closed. Decrease of power supply voltage Looseness, disconnection or reverse of compressor wiring connection Defective compressor Defective outdoor power board Dip switch setting difference of outdoor controller circuit board.	Open stop valve. Check facility of power supply. Correct the wiring (U-V-W phase) to compressor. Refer to "9-8. TEST POINT DIAGRAM (Outdoor power circuit board)". Check compressor. Refer to "9-5. HOW TO CHECK THE PARTS". Replace outdoor power circuit board. Check the DIP switch setting of outdoor controller circuit board. Refer to "Model Select" section at (1) Function of switches" in "9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS".
UH (5300)	Current sensor error • Abnormal if 38 A of incurrent is detected or 34A or more of input current is detected for 10seconds continuously.		Defective circuit of current sensor on outdoor power circuit board Decrease of power supply voltage	Replace outdoor power circuit board. Check the facility of power supply.
UL (1300)	Abnormal if the following conditions are detected for continuously 3 minutes. Note that it applies when the compressor accumulated operating time is under 30 minutes, and 7 minutes has passed after the compressor operation. TH33 - TH4 ≧ 20 °C and TH33 > 80 °C Thermistors: TH33: Comp. Surface temperature TH4: Discharge temperature TH5: Indoor 2-phase pipe temperature TH7: Ambient temperature		Stop valve of outdoor unit is closed during operation. Leakage or shortage of refrigerant Malfunction of linear expansion valve Clogging with foreign objects in refrigerant circuit Note: Clogging occurs in the parts which become below freezing point when water enters in refrigerant circuit.	Check stop valve. ② Check intake superheat. Check leakage of refrigerant. Check additional refrigerant. ③ Check linear expansion valve. Refer to "9-5. HOW TO CHECK THE PARTS". ④ After recovering refrigerant, remove water from entire refrigerant circuit under vacuum more than 1 hour.

Check code	Abnormal points and detection method	Cause	Judgment and action
UP (4210)	Compressor overcurrent interruption Abnormal if overcurrent DC bus or compressor is detected after compressor starts operating for 30 seconds.	Stop valve of outdoor unit is closed. Decrease of power supply voltage Looseness, disconnection or reverse of compressor wiring connection Defective fan of indoor/outdoor units Short cycle of indoor/outdoor units Defective input circuit of outdoor controller board Defective compressor Defective outdoor power circuit board Dip switch setting difference of outdoor controller circuit board	 ① Open stop valve. ② Check facility of power supply. ③ Correct the wiring (U-V-W phase) to compressor. Refer to "9-8. TEST POINT DIAGRAM (Outdoor power circuit board)". ④ Check indoor/outdoor fan. ⑤ Solve short cycle. ⑥ Replace outdoor controller circuit board. ⑦ Check compressor. Refer to "9-5. HOW TO CHECK THE PARTS". ● Before the replacement of the outdoor controller circuit board, disconnect the wiring to compressor from the outdoor power circuit board and check the output voltage among phases, U, V, W, during test run. No defect on board if voltage among phases (U-V, V-W and W-U) is same. Make sure to perform the voltage check with same performing frequency. ⑥ Replace outdoor power circuit board ⑨ Check the dip switch setting of outdoor controller circuit board
E0 or E4	Remote controller transmission error (E0)/signal receiving error (E4) ① Abnormal if main or sub remote controller cannot receive normally any transmission from indoor unit of refrigerant address "0" for 3 minutes. (Check code: E0) ② Abnormal if sub remote controller could not receive any signal for 2 minutes. (Check code: E0) ① Abnormal if indoor controller board cannot receive normally any data from remote controller board or from other indoor controller board for 3 minutes. (Check code: E4) ② Indoor controller board cannot receive any signal from remote controller for 2 minutes. (Check code: E4)	① Contact failure at transmission wire of remote controller ② All remote controllers are set as "sub" remote controller. In this case, E0 is displayed on remote controller, and E4 is displayed at LED (LED1, LED2) on the outdoor controller circuit board. ③ Miswiring of remote controller	 ① Check disconnection or looseness of indoor unit or transmission wire of remote controller. ② Set one of the remote controllers "main" if there is no problem with the action above. ③ Check wiring of remote controller. • Total wiring length: Max. 500 m (Do not use cable × 3 or more.) • The number of connecting indoor units: Max. 16 units • The number of connecting remote controller: Max. 2 units When it is not the above-mentioned problem of ①-③ ④ Diagnose remote controllers. a) When "RC OK" is displayed, remote controllers have no problem. Turn the power off, and on again to check. If abnormality occurs again, replace indoor controller board. b) When "RC NG" is displayed, replace remote controller. c) When "RC E3" or "ERC 00-66" is displayed, noise may be causing abnormality. Note:
E1 or E2	Remote controller control board ① Abnormal if data cannot be normally read from the nonvolatile memory of the remote controller control board. (Check code: E1) ② Abnormal if the clock function of remote controller cannot be normally operated. (Check code: E2)	① Defective remote controller	① Replace remote controller.

OCH773C 37

Check code	Abnormal points and detection method	Cause	Judgment and action
E3 or E5	Remote controller transmission error (E3)/signal receiving error (E5) ① Abnormal if remote controller could not find blank of transmission path for 6 seconds and could not transmit. (Check code: E3) ② Remote controller receives transmitted data at the same time, compares the data, and when detecting it, judges different data to be abnormal 30 continuous times. (Check code: E3) ① Abnormal if indoor controller board could not find blank of transmission path. (Check code: E5) ② Indoor controller board receives transmitted data at the same time, compares the data, and when detecting it, judges different data to be abnormal 30 continuous times. (Check code: E5)	Temote controller are set as "main." (In case of 2 remote controllers) Remote controller is connected with 2 indoor units or more. Repetition of refrigerant address Defective transmitting receiving circuit of remote controller Defective transmitting receiving circuit of indoor controller board Noise has entered into transmission wire of remote controller.	Set a remote controller to main, and the other to sub. Remote controller is connected with only one indoor unit. The address changes to a separate setting. Biagnose remote controller. When "RC OK" is displayed, remote controllers have no problem. Turn the power off, and on again to check. When becoming abnormal again, replace indoor controller board. When "RC NG" is displayed, replace remote controller. When "RC E3" or "ERC 00-66" is displayed, noise may be causing abnormality.
E6 (6840)	Indoor/outdoor unit communication error (Signal receiving error) Abnormal if indoor controller board could not receive any signal normally for 6 minutes after turning the power on. Abnormal if indoor controller board could not receive any signal normally for 3 minutes. Consider the unit as abnormal under the following condition. When 2 or more indoor units are connected to an outdoor unit, indoor controller board could not receive a signal for 3 minutes from outdoor controller circuit board, a signal which allows outdoor controller circuit board to transmit signals.	Contact failure, short circuit or miswiring (reverse wiring) of indoor/outdoor unit connecting wire Defective transmitting receiving circuit of outdoor controller circuit board. Defective transmitting receiving circuit of indoor controller board. Noise has entered into indoor/outdoor unit connecting wire. Defective fan motor Disconnection of 52C relay (PUZ-M·VKA2)	Check LED display on outdoor controller circuit board. (Connect A-Control service tool (PAC-SK52ST)) Refer to EA~EC item if LED displays EA~AC. ① Check disconnecting or looseness of indoor / outdoor unit connecting wire of indoor unit or outdoor unit. Check all the units in case of twin/triple/ quadruple indoor unit system. ②—④ Turn the power off, and on again to check. If abnormality occurs again, replace indoor controller board or outdoor controller circuit board. Other indoor controller board may have defect in case of twin/triple/quadruple indoor unit system. ⑤ Turn the power off, and detach fan motor from connector (CNF1, 2). Then turn the power on again. If abnormality is not displayed, replace fan motor. If abnormality is displayed, replace outdoor controller circuit board. ⑥ Connect 52C relay properly to CN52C (PUZ-M-VKA2)
	Indoor/outdoor unit communication error (Transmitting error) Abnormal if "1" receiving is detected 30 times continuously though indoor controller board has transmitted "0".	Defective transmitting receiving circuit of indoor controller board Noise has entered into power supply. Noise has entered into outdoor control wire.	①—③ Turn the power off, and on again to check. If abnormality occurs again, replace indoor controller board.
E8 (6840)	Indoor/outdoor unit communication error (Signal receiving error) (Outdoor unit) Abnormal if outdoor controller circuit board could not receive anything normally for 3 minutes.	Contact failure of indoor/ outdoor unit connecting wire Defective communication circuit of outdoor controller circuit board Defective communication circuit of indoor controller board Noise has entered into indoor/ outdoor unit connecting wire.	Check disconnection or looseness of indoor/ outdoor unit connecting wire of indoor or outdoor units. Turn the power off, and on again to check. Replace indoor controller board or outdoor controller circuit board if abnormality is displayed again.
E9 (6841)	Indoor/outdoor unit communication error (Transmitting error) (Outdoor unit) ① Abnormal if "0" receiving is detected 30 times continuously though outdoor controller circuit board has transmitted "1". ② Abnormal if outdoor controller circuit board could not find blank of transmission path for 3 minutes.	Indoor/ outdoor unit connecting wire has contact failure. Defective communication circuit of outdoor controller circuit board Noise has entered power supply. Noise has entered indoor/ outdoor unit connecting wire.	Check disconnection or looseness of indoor/ outdoor unit connecting wire. Turn the power off, and on again to check. Replace outdoor controller circuit board if abnormality is displayed again.

38

Check code	Abnormal points and detection method	Cause	Judgment and action	
EE	Abnormal if a connection of indoor unit and outdoor unit which uses different refrigerant is detected.	Unauthorized connection of indoor unit and outdoor unit Connections other than below combination are not authorized; Outdoor unit: Models with R32 refrigerant Indoor unit: Floor standing type indoor unit (PSA-KA)	Alter the connection referring to the combination as shown in the "cause" column.	
EF (6607 or 6608)	Non defined check code This code is displayed when non defined check code is received.	Noise has entered transmission wire of remote controller. Noise has entered indoor/ outdoor unit connecting wire. Outdoor unit is not a series of power-inverter.	 Turn the power off, and on again to check Replace indoor controller board or outdoo controller circuit board if abnormality is displayed again. Replace outdoor unit with power-inverter typoutdoor unit. 	
Ed (0403)	Serial communication error Abnormal if serial communication between outdoor controller circuit board and outdoor power circuit board is defective.	Breaking of wire or contact failure of connector CN2 between the outdoor controller circuit board and the outdoor power circuit board Breaking of wire or contact failure of connector CN4 between the outdoor controller circuit board and the outdoor power circuit board Defective communication circuit of outdoor power circuit board Defective communication circuit of outdoor controller circuit board outdoor power circuit board	Check connection of each connector CN2 and CN4 between the outdoor controller circuit board and the outdoor power circuit board. Replace outdoor power circuit board. Replace outdoor controller circuit board.	
	Abnormal if communication between outdoor controller circuit board and M-NET board is not available.	Breaking of wire or contact failure of connector between outdoor controller circuit board and M-NET board Contact failure of M-NET board power supply line Noise has entered into M-NET transmission wire.	Check disconnection, looseness, or breaking of connection wire between outdoor controller circuit board (CNMNT) and M-NET board (CN5). Check disconnection, looseness, or breaking of connection wire between outdoor controller circuit board (CNMNT) and M-NET board (CND). Check M-NET transmission wiring method.	
P8	Pipe temperature Detected as abnormal when the pipe temperature is not in the cooling range 3 minutes after compressor start and 6 minutes after the liquid or condenser/ evaporator pipe is out of cooling range. Note 1) It takes at least 9 minutes to detect. Note 2) Abnormality P8 is not detected in drying mode. Cooling range: Indoor pipe temperature (TH2 or TH5) − intake temperature (TH1) ≤ −3°C TH: Lower temperature between liquid pipe temperature and condenser/evaporator temperature	Slight temperature difference between indoor room temperature and pipe quid or condenser/evaporator> temperature thermistor Shortage of refrigerant Disconnected holder of pipe quid or condenser/evaporator> thermistor Defective refrigerant circuit Reverse connection of extension pipe (on plural units connection) Reverse wiring of indoor/outdoor unit connecting wire (on plural units connection) Defective detection of indoor room temperature and pipe <condenser evaporator=""> temperature thermistor Stop valve is not opened completely.</condenser>	①—④ Check pipe < liquid or condenser/ evaporator> temperature with room temperature display on remote controller and outdoor controller circuit board. Pipe < liquid or condenser / evaporator> temperature display is indicated by setting SW2 of outdoor controller circuit board as follows. Conduct temperature check with outdoor controller circuit board after connecting 'A-Control Service Tool (PAC-SK52ST)'. Temperature display of indoor liquid pipe Indoor 1 Temperature display of indoor liquid pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2 Temperature display of indoor condenser/ evaporator pipe Indoor 2	

Check code	Abnormal points and detection method	Cause	Judgment and action
PL	Abnormal refrigerant circuit During Cooling or Auto Cooling operation, when the following are regarded as failures when detected for one second. a)The compressor continues to run for 30 or more seconds. b)The liquid pipe temperature or the condenser/evaporator temperature is 75°C or more. These detected errors will not be cancelled until the power source is reset.	Disconnection of or leakage in refrigerant pipes Air into refrigerant piping Abnormal operation (no rotation) of indoor fan Defective fan motor Defective indoor control board Defective refrigerant circuit (clogging)	O Check refrigerant pipes for disconnection or leakage. After the recovery of refrigerant, vacuum dry the whole refrigerant circuit. Refer to "9-5. HOW TO CHECK THE PARTS". Oheck refrigerant circuit for operation. To avoid entry of moisture or air into refrigerant circuit which could cause abnormal high pressure, evacuate air in refrigerant circuit or replace refrigerant.

<M-NET communication error>

	Note: "Indoor unit" in the text indicates M-NET board in ou		
Check code	Abnormal points and detection method	Cause	Judgment and action
A0 (6600)	Address duplicate definition This error is displayed when transmission from the units of same address is detected. Note: The address and attribute displayed at remote controller indicate the controller that detected abnormality.	There are 2 or more same address of controller of outdoor unit, indoor unit, FRESH MASTER, or LOSSNAY. Noise has entered into transmission signal and signal was transformed.	Search the unit with same address as abnormality occurred. If the same address is found, shut the power supply of outdoor unit and indoor unit and FRESH MASTER or LOSSNAY at the same time for 2 minutes or more after the address is corrected, and turn the power on again. Check transmission waveform or noise on transmission wire.
A2 (6602)	Hardware error of transmission processor Transmission processor intended to transmit "0", but "1" appeared on transmission wire. Note: The address and attribute display at remote controller indicate the controller that detected abnormality.	① Error is detected if waveform is transformed when wiring works of transmission wire of outdoor unit, indoor unit, FRESH MASTER or LOSSNAY are done, or polarity is changed with the power on and transmission data collide each other. ② Defective transmitting receiving circuit of transmission processor ③ Transmission data is changed by the noise on transmission.	If the works of transmission wire is done with the power on, shut off the power supply of outdoor unit and indoor unit and FRESH MASTER or LOSSNAY at the same time for 2 minutes or more, and turn the power on again.
A3 (6603)	BUS BUSY 1. Overtime error by collision damage Abnormal if transmitting is not possible for 8-10 minutes continuously because of collision of transmission. 2. Data could not reach transmission wire for 8-10 minutes continuously because of noise or etc. Note: The address and attribute displayed at remote controller indicate the controller that detected abnormality.	① Transmission processor could not transmit signal because short cycle voltage of noise and the like have entered into transmission wire continuously. ② Transmission quantity has increased and transmission is not possible because there was wiring mistake of terminal block for transmission wire (TB3) and terminal block for central control (TB7) in outdoor unit. ③ Transmission are mixed with others and occupation rate on transmission wire rose because of defective repeater (a function to connector or disconnect transmission of control and central control system) of outdoor unit, then abnormality is detected.	Check if transmission wire of indoor unit, FRESH MASTER, LOSSNAY, or remote controller is not connected to terminal block for central control (TB7) of outdoor unit. Check if transmission wire of indoor unit, FRESH MASTER or LOSSNAY is not connected to terminal block for transmission wire of outdoor unit. Check if terminal block for transmission wire (TB3) and terminal block for central control (TB7) is not connected. Check transmission waveform or noise on transmission wire.
A6 (6606)	Communication error with communication processor Defective communication between unit processor and transmission processor Note: The address and attribute display at remote controller indicate the controller that detected abnormality.	① Data of transmission processor or unit processor is not transmitted normally because of accidental trouble such as noise or thunder surge. ② Address forwarding from unit processor is not transmitted normally because of defective transmission processor hardware.	Turn off the power supply of outdoor unit, indoor unit and FRESH MASTER or LOSSNAY at the same time for 2 minutes or more, and turn the power on again. System returns normally if abnormality was accidental malfunction. If the same abnormality occurs again, abnormality-generated controller may be defective.

40

heck code	Abnormal points and detection method	Cause	Judgment and action
heck code	NO ACK signal 1. Transmitting side controller detects abnormal if a message was transmitted but there is no reply (ACK) that a message was received. Transmitting side detects abnormality every 30 seconds, 6 times continuously. Note: The address and attribute displayed at remote controller indicate the controller that did not reply (ACK).	Cause Common factor that has no relation with abnormality source The unit of former address does not exist as address switch has changed while the unit was energized. Extinction of transmission wire voltage and signal is caused by over-range transmission wire. Maximum distance200m Remote controller line-(12m) Extinction of transmission wire voltage and signal is caused by type-unmatched transmission wire. Type With shield wire- CVVS, CPEVS With normal wire (no shield)- VCTF, VCTFK, CVV CVS, WR, VVF, VCT Diameter1.25mm² or more Extinction of transmission wire voltage and signal is caused by over-numbered units. Accidental malfunction of abnormality-detected controller (noise, thunder surge) Defective of abnormality-generated controller	Judgment and action Always try the following when the error "A7" occurs. ① Turn off the power supply of outdoor unit, indoor unit and FRESH MASTER or LOSSNAY at the same time for 2 minutes or more, and turn the power on again. If malfunction was accidental, the unit returns to normal. ② Check address switch of abnormality-generated address. ③ Check disconnection or looseness of abnormality-generated or abnormality-detected transmission wire (terminal block and connector) ④ Check if tolerance range of transmission wire is not exceeded. ⑤ Check if type of transmission wire is correct or not. If the cause of trouble is not any of ①—⑤ above, repair the defect, then turn off the power supply of outdoor unit, indoor unit and FRESH MASTER or LOSSNAY at the same time for 2 minutes or more, and turn the power on again. If the cause of trouble is not any of ①—⑥ above in single refrigerant system (one outdoor unit), controller of displayed address or attribute is defective. If the cause of trouble is not any of ①—⑥
A7 (6607)	If displayed address or attribute is outdoor unit, indoor unit detects abnormality when indoor unit transmits signal to outdoor unit and there was no reply (ACK).	Contact failure of transmission wire of outdoor unit or indoor unit Disconnection of transmission connector (CN2M) of outdoor unit Defective transmitting receiving circuit of outdoor unit or indoor unit Disconnection of the connectors on the circuit board	above in different refrigerant system (2 or more outdoor units), judge with (a). (a) If address of abnormality source is the address that should not exist, there is the unit that memorizes nonexistent address information. Delete useless address information with manual setting function of remote controller. Only the system FRESH MASTER or LOSSNAY are connected to, or the system
	If displayed address or attribute is indoor unit, remote controller detects abnormality when remote controller transmits signal to indoor unit and there was no reply (ACK).	During group operation with indoor unit of multi- refrigerant system, if remote controller transmits signal to indoor unit while outdoor unit power supply of one refrigerant system is turned off or within 2 minutes of restart, abnormality is detected. Contact failure of transmission wire of remote controller or indoor unit Disconnection of transmission connector (CN2M) of indoor unit Defective transmitting receiving circuit of indoor unit or remote controller	that is equipped with group setting of different refrigerant system. If the cause of trouble is not any of ①—⑥ above, replace the controller board of displayed address or attribute. If the unit does not return normally, multicontroller board of outdoor unit may be defective (repeater circuit). Replace multi-controller board one by one to check if the unit returns normally.

From the previous page.

Check code	Abnormal points and detection method	Cause	Judgment and action
	If displayed address or attribute is remote controller, indoor unit detects abnormality when indoor unit transmits signal to remote controller and there was no reply (ACK).	During group operation with indoor unit of multi- refrigerant system, if indoor unit transmit signal to remote controller while outdoor unit power supply of one refrigerant system is turned off or within 2 minutes of restart, abnormality is detected. Contact failure of transmission wire of remote controller or indoor unit Disconnection of transmission connector (CN2M) of indoor unit Defective transmitting receiving circuit of indoor unit or remote controller	Same as mentioned in "A7" of the previous page.
A7 (6607)	5. If displayed address or attribute is FRESH MASTER, indoor unit detects abnormality when indoor unit transmits signal to FRESH MASTER and there was no reply (ACK).	During sequential operation of indoor unit and FRESH MASTER of other refrigerant system, if indoor unit transmits signal to FRESH MASTER while outdoor unit power supply of same refrigerant system with FRESH MASTER is turned off or within 2 minutes of restart, abnormality is detected. Contact failure of transmission wire of indoor unit or FRESH MASTER Disconnection of transmission connector (CN2M) of indoor unit or FRESH MASTER Defective transmitting receiving circuit of indoor unit or FRESH MASTER	
	6. If displayed address or attribute is LOSSNAY, indoor unit detects abnormality when indoor unit transmits signal to LOSSNAY and there was no reply (ACK).	If the power supply of LOSSNAY is off, indoor unit detects abnormality when it transmits signal to LOSSNAY. During sequential operation of indoor unit and LOSSNAY of other refrigerant system, if indoor unit transmits signal to LOSSNAY while outdoor unit power supply of same refrigerant system with LOSSNAY is turned off or within 2 minutes of restart, abnormality is detected. Contact failure of transmission wire of indoor unit of LOSSNAY Disconnection of transmission connector (CN2M) of indoor unit Defective transmitting receiving circuit of indoor unit or LOSSNAY	
	If displayed address or attribute is non-existent.	① The unit of former address does not exist as address switch has changed while the unit was energized. ② Abnormality is detected when indoor unit transmits signal because the address of FRESH MASTER and LOSSNAY are changed after sequential operation of FRESH MASTER and LOSSNAY by remote controller.	

Check code	Abnormal points and detection method	Cause	Judgment and action
A8 (6608)	M-NET NO RESPONSE Abnormal if a message was transmitted and there were reply (ACK) that message was received, but response command does not return. Transmitting side detects abnormality every 30 seconds, 6 times continuously. Note: The address and attribute displayed at remote controller indicate the controller that did not reply (ACK).	Transmitting condition is repeated fault because of noise and the like. Extinction of transmission wire voltage and signal is caused by over-range transmission wire. Maximum distance 200m Remote controller line (12m) Extinction of transmission wire voltage and signal is caused by type-unmatched transmission wire. Type With shield wire- CVVS, CPEVS With normal wire (no shield)- VCTF, VCTFK, CVV CVS, VVR, VVF, VCT Diameter 1.25mm² or more Accidental malfunction of abnormality-generated controller	Check transmission waveform or noise on transmission wire. Turn off the power supply of outdoor unit and indoor unit and FRESH MASTER or LOSSNAY at the same time for 2 minutes or more, and turn the power on again. If malfunction was accidental, the unit returns to normal. If the same abnormality occurs again, controller of displayed address and attribute may be defective.

9-4. TROUBLESHOOTING OF PROBLEMS


Phenomena	Factor	Countermeasure
Remote controller display does not work.	 12 V DC is not supplied to remote controller. 12–15 V DC is supplied to remote controller, however, no display is indicated. "Please Wait" is not displayed. "Please Wait" is displayed. 	 ①Check LED2 on indoor controller board. (1) When LED2 is lit. Check the remote controller wiring for breaking or contact failure. (2) When LED2 is blinking. Check short circuit of remote controller wiring. (3) When LED2 is not lit. Refer to phenomena No.3 below. ②Check the following. Failure of remote controller if "Please Wait" is not displayed Refer to phenomena No.2 below if "Please Wait" is displayed.
"Please Wait" display is remained on the remote controller.	At longest 2 minutes after the power supply "Please Wait" is displayed to startup. Communication error between the remote controller and indoor unit Communication error between the indoor and outdoor unit	indoor controller board. (1) When LED3 is not blinking. Check indoor/outdoor connecting wire for Miswiring. (Reverse wiring of S1 and S2, or break of S3 wiring.) (2) When LED3 is blinking. Indoor/outdoor connecting wire is normal.
	Outdoor unit protection device connector is open.	Check LED display on outdoor controller circuit board. Refer to "9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS" Check protection device connector (63H) for contact failure. Refer to "9-8. TEST POINT DIAGRAM".
When pressing the remote controller operation switch, the OPERATION display is appeared but it will be turned off soon.	① After cancelling to select function from the remote controller, the remote controller operation switch will be not accepted for approx. 30 seconds.	① Normal operation

OCH773C 43

Phenomena	Factor	Countermeasure
Even controlling by the wireless remote controller, no beep is heard and the unit does not start operating. Operation display is indicated on wireless remote controller.	The pair number settings of the wireless remote controller and indoor controller board are mismatched.	① Check the pair number settings.
When operating by the wireless remote controller, beep sound is heard, however, unit does not start operating.	 ① No operation for 2 minutes at most after the power supply ON. ② Local remote controller operation is prohibited. • Remote controlling adaptor is connected to CN32 on the indoor controller board. • Local remote controller operation is prohibited by centralized controller etc. since it is connected to MELANS. ③ Phenomena of No.2. 	Normal operation Normal operation Check the phenomena No.2.
Remote controller display works normally and the unit performs cooling operation, however, the capacity cannot be fully obtained. (The air does not cool well.)	① Refrigerant shortage ② Filter clogging	If refrigerant leaks, discharging temperature rises and LEV opening increases. Inspect leakage by checking the temperature and opening. Check pipe connections for gas leakage. Open intake grille and check the filter.
	③ Heat exchanger clogging	Clean the filter by removing dirt or dust on it. ③ • If the filter is clogged, indoor pipe temperature rises and discharging pressure increases. Check if heat exchanger is clogged by inspecting discharging pressure. • Clean the heat exchanger.
	Air duct short cycle	Remove the blockage.
7. ① For 3 minutes after temperature adjuster turns off, the compressor will not start operating even if temperature adjuster is turned on. ② For 3 minutes after temperature adjuster turns on, the compressor will not stop operating even if temperature adjuster is turned off. (Compressor stops operating immediately when turning off by the remote controller.)	①② Normal operation (For protection of compressor)	①② Normal operation

OCH773C 44

Symptoms: "Please Wait" is kept being displayed on the remote controller.




Symptoms: Nothing is displayed on the remote controller ①

LED display of the indoor controller board

LED1: O

LED2: O




Symptoms: Nothing is displayed on the remote controller 2

LED display of the indoor controller board

LED1: -

LED3: or .jo.



Symptoms: Nothing is displayed on the remote controller $\ensuremath{ \mbox{\scriptsize 3}}$

LED display of the indoor controller board

LED1: - or - LED3: -

Diagnosis flow	Cause	Inspection method and troubleshooting
Check the voltage of the terminal block (TB6) of the remote controller. 10 V DC to 16 V DC? NO	→ • Defective remote controller	Replace the remote controller.
Check the status of the LED2 Blinking Check the status of the LED2 after disconnecting the remote controller wire from the terminal block (TB5) of the indoor unit.	Breaking or poor contact of the remote controller wire	Check if there is breaking or poor contact of the remote controller wire. Check the voltage of the terminal block (TB5) connecting the remote controller wire. If it is not between DC 10 V and 16 V DC, the indoor controller board must be defective.
Check the status of the LED2. Blinking	The remote controller wire short-circuits	Check if the remote controller wire is short-circuited.
	Defective indoor controller board	Replace the indoor controller board.

• Before repair <Frequent calls from customers>

Phone Calls From Customers		How to Respond	Note
Unit does not operate at all.	① The operating display of remote controller does not come on.	Check if power is supplied to air conditioner. Nothing appears on the display unless power is supplied.	
	② Unit cannot be restarted for a while after it's stopped.	② Wait around 3 minutes to restart unit. The air conditioner is in a state of being protected by the microprocessor's directive. Once the compressor is stopped, the unit cannot be restarted for 3 minutes. This control is also applied when the unit is turned on and off by remote controller.	
	Check code appears and blinks on the display of remote controller.	Check code will be displayed if any protection devices of the air conditioner are actuated. What is check code?	Refer to "SELF-DIAGNOSIS ACTION TABLE". - Check if servicing is required for the error.
Remote controller	① "Please Wait" is displayed on the screen.	Wait around 2 minutes. An automatic startup test will be conducted for 2 minutes when power is supplied to the air conditioner. "Please Wait" will be kept being displayed while that time.	
	② "IIIII" is displayed on the screen.	② This indicates that it is time to clean the air filters. Clean the air filters. "■ can be cleared from the filter information of the maintenance menu. See the operation manual that came with the product for how to clean the filters.	Display time of """ " depends on the model. Long life filter: 2500 h Standard filter: 100 h
The room cannot be cooled or sufficiently.		Check the set temperature of remote controller. The outdoor unit cannot be operated if the set temperature is not appropriate. The outdoor unit operates in the following condition: When the set temperature is lower than the room temperature.	
		② Check if filters are not dirty and clogged. If filters are clogged, the airflow amount will be reduced and the unit capacity will be lowered. See the instruction manual that came with the product for how to clean the filters.	
		③ Check there is enough space around the air conditioner. If there are any obstacles in the air intake or air outlet of indoor/outdoor units, they block the airflow direction so that the unit capacity will be lowered.	
Sound comes out from the air	① A gas escaping sound is heard sometimes.	 This is not a malfunction. This is the sound when the flow of refrigerant in the air conditioner is switched. 	
	② A cracking sound is heard sometimes.	② This is not a malfunction. This is the sound when internal parts of units expand or contract when the temperature changes.	
	③ A buzzing sound is heard sometimes.	③ This is not a malfunction. This is the sound when the outdoor unit starts operating.	

Pho	one Calls From Customers	How to Respond	Note
Sound comes out from the air conditioner.	A ticking sound is heard from the outdoor unit sometimes.	This is not a malfunction. This is the sound when the fan of the outdoor unit is controlling the airflow amount in order to keep the optimum operating condition.	
	⑤ A sound, similar to water flowing, is heard from the unit.	⑤ This is not a malfunction. This is the sound when the refrigerant is flowing inside the indoor unit.	
Something is wrong with the blower	The fan speed does not match the setting of the remote controller during DRY operation.(No air comes out sometimes during DRY operation.)	This is not a malfunction. During the DRY operation, the blower's ON/OFF is controlled by the microprocessor to prevent overcooling and to ensure efficient dehumidification. The fan speed cannot be set by the remote controller during DRY operation.	
Something is wrong with the airflow direction	① The airflow direction is changed during COOL operation.	① If the up/down vane is set to downward in COOL operation, it will be automatically set to horizontal blow by the microprocessor in order to prevent water from dropping down. "1 h" will be displayed on the remote controller if the up/down vane is set to downward with the fan speed set to be less than "LOW".	
	② The airflow direction does not change.(Up/down vane, left/right louver)	 ② 1) Check if the vane is set to a fixed position. (Check if the vane motor connector is removed.) 2) Check if the air conditioner has a function for switching the air direction. 3) If the air conditioner does not have that function, "Unsupported function" will be displayed on the remote controller when "AIR DIRECTION" or "LOUVER" button is pressed. 	
1	ditioner starts operating even though on the remote controller are not	Oheck if you set ON/OFF timer. The air conditioner starts operating at the time designated if ON timer has been set before.	
		② Check if any operations are ordered by distant control system or the central remote controller. While "Centrally controlled" is displayed on the remote controller, the air conditioner is under the control of external directive.	There might be a case that "Centrally controlled" will not be displayed.
	③ Check if power is recovered from power failure (black out). The units will automatically start operating when power is recovered after power failure (black out) occurs. This function is called "auto recovery feature from power".		
1	the remote controller are not pressed. The air conditioner stops operating at the time		There might be a case that "Centrally controlled" will not be displayed.

Phone Calls From Customers	How to Respond	Note
A white mist is expelled from the indoor unit.	This is not a malfunction. This may occur when the operation is started in the room of high humidity.	
Water or moisture is expelled from the outdoor unit.	When pipes or piping joints are cooled, they sweat and water drips down. Note: Make use of optional parts "Drain Socket" and "Drain pan" if these water needs to be collected and drained out for once.	
The display of wireless remote controller gets dim or does not come on. The indoor unit does not receive a signal from remote controller at a long distance.	Batteries are being exhausted. Replace them and press the reset button of remote controller.	


9-5. HOW TO CHECK THE PARTS

Parts name	Checkpoints						
Thermistor(TH3) <liquid> Thermistor (TH4)</liquid>		Disconnect the connector then measure the resistance with a multimeter. (At the ambient temperature 10°C to 30°C)					
<discharge></discharge>	Normal Abnormal						
Thermistor (TH6)	TH4, TH33	160 kΩ–410 kΩ					
<2-phase pipe> Thermistor (TH7) <ambient> Thermistor (TH8)</ambient>	TH3 TH6 TH7	4.3 kΩ–9.6 kΩ	Open or sh	nort			
<heatsink> Thermistor (TH33) <comp. surface=""></comp.></heatsink>	TH8	39 kΩ–105kΩ					
Fan motor(MF1,MF2)	Refer to the next p	age.					
Solenoid valve coil <4-way valve>	Measure the resist (At the ambient ter						
(21S4)		Abnormal					
		Open or short					
Motor for compressor (MC)	Measure the resistance between the terminals with a multimeter. (Winding temperature 20°C)						
		Abnormal					
W W	Refe	Open or short					
Linear expansion valve (LEV-A/LEV-B)	Disconnect the connector then measure the resistance with a multimeter. (Winding temperature 20°C)						
M GY OG 2		Nor	mal		Abnormal		
OG 2 RD 3 YE 4	Gray-Black	Gray-Red	Gray-Yellow	Gray-Orange	Open or short		
BK 5		Sport of chore					

Check method of DC fan motor (fan motor / outdoor controller circuit board)

- Notes
 - · High voltage is applied to the connector (CNF1) for the fan motor. Take extra care while servicing.
 - · Do not pull out the connector (CNF1) for the motor with the power supply on.
 - (It causes trouble of the outdoor controller circuit board and fan motor.)
- ②Self check

Symptom: The outdoor fan cannot turn around.



9-6. HOW TO CHECK THE COMPONENTS

<Thermistor feature chart>

Low temperature thermistors

- Thermistor <Liquid> (TH3)
- Thermistor <2-phase pipe> (TH6)
- Thermistor < Ambient> (TH7)

Thermistor R0 = 15 $k\Omega \pm 3\%$ B constant = 3480 $\pm 1\%$

Rt =15exp{3480(
$$\frac{1}{273+t}$$
 - $\frac{1}{273}$)}
0°C 15 k Ω 30°C 4.3 k Ω
10°C 9.6 k Ω 40°C 3.0 k Ω
20°C 6.3 k Ω
25°C 5.2 k Ω

Medium temperature thermistor

• Thermistor <Heatsink> (TH8)

Thermistor R50 = 17 $k\Omega \pm 2\%$ B constant = 4150 $\pm 3\%$

Rt = $17 \exp\{4150(\frac{1}{273+t} - \frac{1}{323})\}$

0°C 180 kΩ 25°C 50 kΩ 50°C 17 kΩ 70°C 8 kΩ 90°C 4 kΩ


High temperature thermistors


- Thermistor < Discharge > (TH4)
- Thermistor < Comp. surface > (TH33)


Thermistor R120 = 7.465 k Ω ± 2% B constant = 4057 ± 2%

Rt = 7.465exp{
$$4057(\frac{1}{273+t} - \frac{1}{393})$$
}

20°C	250 kΩ	70°C	34 kΩ
30°C	160 kΩ	80°C	24 kΩ
40°C	104 kΩ	90°C	17.5 kΩ
50°C	70 kΩ	100°C	13.0 kΩ
60°C	48 kΩ	110°C	$9.8 \text{ k}\Omega$








Linear expansion valve

(1) Operation summary of the linear expansion valve

- · Linear expansion valve opens/closes through stepping motor after receiving the pulse signal from the outdoor controller board.
- Valve position can be changed in proportion to the number of pulse signal.
- <Connection between the outdoor controller board and the linear expansion valve>




<Output pulse signal and the valve operation>

Output	Output								
(Phase)	1	2	3	4	5	6	7	8	
ø1	ON	ON	OFF	OFF	OFF	OFF	OFF	ON	
ø2	OFF	ON	ON	ON	OFF	OFF	OFF	OFF	
ø3	OFF	OFF	OFF	ON	ON	ON	OFF	OFF	
ø4	OFF	OFF	OFF	OFF	OFF	ON	ON	ON	

The output pulse shifts in the following order. Opening a valve: $8 \rightarrow 7 \rightarrow 6 \rightarrow 5 \rightarrow 4 \rightarrow 3 \rightarrow 2 \rightarrow 1 \rightarrow 8$ Closing a valve: $1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5 \rightarrow 6 \rightarrow 7 \rightarrow 8 \rightarrow 1$

 When linear expansion valve operation stops, all output phase become OFF.

(2) Linear expansion valve operation



- When the power is turned on, 700 pulse closing valve signal will be sent till it goes to @ point in order to define the valve position. (The pulse signal is being sent for about 20 seconds.)


No sound is heard when the pulse number moves from ® to ® in case coil is burnt out or motor is locked by open-phase.


 Sound can be detected by placing the ear against the screw driver handle while putting the screw driver to the linear expansion valve.

(3) How to attach and detach the coil of linear expansion valve

<Composition>

Linear expansion valve is separable into the main body and the coil as shown in the diagram below.






<How to detach the coil>

Hold the lower part of the main body (shown as A) firmly so that the main body does not move and detach the coil by pulling it upward.


Be sure to detach the coil holding main body firmly. Otherwise pipes can bend due to stress.



<How to attach the coil>

Hold the lower part of the main body (shown as A) firmly so that the main body does not move and attach the coil by inserting it downward into the main body. Then securely attach the coil stopper to main body. (At this time, be careful that stress is not added to lead wire and main body is not wound by lead wire.) If the stopper is not firmly attached to main body, coil may be detached from the main body and that can cause defective operation of linear expansion valve.

To prevent piping stress, be sure to attach the coil holding the main body of linear expansion valve firmly. Otherwise pipe may break.



9-7. EMERGENCY OPERATION

- (1) When the check codes shown below are displayed on outdoor unit or microprocessor for wired remote controller or indoor unit has a failure, but no other problems are found, emergency operation will be available by setting the emergency operation switch (SWE) on indoor controller board to ON and short-circuiting the connector (CN31) on outdoor controller board.
 - •When following abnormalities occur, emergency operation will be available.


Check code	Inspected content
U4	Open/short of outdoor unit thermistor (TH6/TH7/TH8)
E8	Indoor/outdoor unit communication error • Signal receiving error (Outdoor unit)
E9	Indoor/outdoor unit communication error • Transmitting error (Indoor unit)
E0 ~ E7	Communication error other than outdoor unit
Ed	Communication error between outdoor controller board and M-NET board (Serial communication error)

(2) Check the following items and cautions for emergency operation

- ① Make sure that there is no abnormality in outdoor unit other than the above abnormalities. (Emergency operation will not be available when check code other than the above are indicated.)
- ② For emergency operation, it is necessary to set the emergency operation switch (SWE) on indoor controller board. Refer to the electrical wiring diagram of indoor unit for how to set the indoor unit.
- ③ During emergency operation, the air-conditioner will continuously be operated by supplying power and stopping it: It cannot be turned on or off by remote control, and temperature control is not possible.
- ④ Do not perform emergency heating operation for an extended period of time: If the outdoor unit starts defrosting during this period, cold air will blow out from the indoor unit.
- ⑤ Do not perform emergency cooling operation for more than 10 hours: Neglecting this could result in freezing the heat exchanger in indoor unit.

(3) Emergency operation procedure

- ① Turn the main power supply off.
- ② Turn on the emergency operation switch (SWE) on indoor controller board.
- ③ Set the shorting pins of emergency operation connector (CN31) on outdoor controller board to ON.



Turning the main power supply on will start the emergency operation.


(4) Releasing emergency operation

- ① Turn the main power supply off.
- ② Set the emergency operation switch (SWE) on indoor controller board to OFF.
- 3 Set the shorting pins of emergency operation connector (CN31) on outdoor controller board to OFF.

Note:

If shorting pins are not set on emergency operation connector (CN31), the setting remains OFF.


9-8. TEST POINT DIAGRAM Outdoor controller circuit board



Outdoor noise filter circuit board

PUZ-M100YKA2(-ET/-ER).TH PUZ-M125YKA2(-ET/-ER).TH PUZ-M140YKA2(-ET/-ER).TH

> LI1, LI2, LI3, NI POWER SUPPLY LI1-LI2/LI2-LI3/LI3-LI1: 400 VAC input LI1-NI/LI2-NI/LI3-NI: 230 VAC input (Connect to the terminal block (TB1))




59

Outdoor noise filter circuit board

PUZ-M100YKA2(-ET)R1.TH PUZ-M125YKA2(-ET)R1.TH PUZ-M140YKA2(-ET)R1.TH

LI1, LI2, LI3, NI POWER SUPPLY LI1-LI2/LI2-LI3/LI3-LI1: 400 VAC input LI1-NI/LI2-NI/LI3-NI: 230 VAC input (Connect to the terminal block (TB1))



60

Outdoor power circuit board PUZ-M100VKA2(-ET/-ER).TH PUZ-M125VKA2(-ET/-ER).TH PUZ-M140VKA2(-ET/-ER).TH

CN₂

Connect to the outdoor

②-⑤: Zero cross signal

(0-5 VDC)

TB1A, TB2A, TB3A, TB1B, TB2B, TB3B Connect to DCL

for M100V model.

280-380 VDC (①+, ③-) Connect to the outdoor controller circuit

board (CNDC)

3-4: 15 VDC

6-5: 15 VDC

⑦-⑤: 15 VDC

outdoor controller

Brief Check of POWER MODULE

If they are short-circuited, it means that they are broken. Measure the resistance in the following points (connectors, etc.).

1. Check of POWER MODULE Check of DIODE circuit R-P1, S-P1, R-N1, S-N1 ② Check of IGBT circuit P2-L1, P2-L2, P2-L3, N2-L1, N2-L2, N2-L3 3 Check of INVERTER circuit P3-U, P3-V, P3-W, N3-U, N3-V, N3-W Note: The marks \mathbb{R} , \mathbb{S} , $\mathbb{L}1$, $\mathbb{L}2$, $\mathbb{L}3$, $\mathbb{P}1$, $\mathbb{P}2$, $\mathbb{P}3$, $\mathbb{N}1$, $\mathbb{N}2$, $\mathbb{N}3$, \mathbb{U} , \mathbb{V} and \mathbb{W} shown in the diagram are not actually printed on the board. controller circuit board (CN2) CN₆ ①-⑤: Transmitting signal to Thermistor <Heat sink> circuit board (0-5 VDC) CN4 Connect to the outdoor controller circuit board (CN4) *TB2A and TB2B are not mounted on board CNAC1, CNAC2 230 VAC Connect to the outdoor controller circuit board (CNAC) NI, LI Voltage of 230 أمعك VAC is input (10) (Connect to the terminal block (TB1)) BH00J260B HANDL ING

EI, E2, E3, E4 Connect to the earth

Outdoor power circuit board

PUZ-M100YKA2(-ET/-ER).TH PUZ-M125YKA2(-ET/-ER).TH PUZ-M140YKA2(-ET/-ER).TH

Brief Check of POWER MODULE


If they are short-circuited, it means that they are broken. Measure the resistance in the following points (connectors, etc.).

1. Check of DIODE MODULE

L1-P1, L2-P1, L3-P1, L1-N1, L2-N1, L3-N1
2. Check of DIP-IPM

P2-U, P2-V, P2-W, N2-U, N2-V, N2-W

Note: The marks L1, L2, L3, N1, N2, P1, P2, U, V and W shown in the diagram are not actually printed on the board.



Outdoor power circuit board

PUZ-M100YKA2(-ET)R1.TH PUZ-M125YKA2(-ET)R1.TH PUZ-M140YKA2(-ET)R1.TH

Brief Check of POWER MODULE


If they are short-circuited, it means that they are broken. Measure the resistance in the following points (connectors, etc.).


1. Check of DIODE MODULE

 $\cbox{\tt L1-P1},\cbox{\tt L2-P1},\cbox{\tt L3-P1},\cbox{\tt L1-N1},\cbox{\tt L2-N1},\cbox{\tt L3-N1}$ 2. Check of DIP-IPM

P2-U, P2-V, P2-W, N2-U, N2-V, N2-W

Note: The marks L1, L2, L3, N1, N2, P1, P2, U, V and W shown in the diagram are not actually printed on the board.





9-9. FUNCTION OF SWITCHES, CONNECTORS AND JUMPERS

(1) Function of switches

The black square () indicates a switch position.

Type	Switch	No	Function	Action by the s	Action by the switch operation				
switch	1	NO.	Function	ON	OFF	Effective timing			
		1	Manual defrost *1	Start	Normal	When compressor is working in heating operation. *1			
		2	Abnormal history clear	Clear	Normal	off or operating			
		3		ON 1 2 3 4 5 6 0 1 2 3 4 5 6	ON 1 2 3 4 5 6 2 1 2 3 4 5 6				
DIP switch	SW1	4	Refrigerant address setting	ON ON ON 12 3 4 5 6 ON 12 3 4		When no wer awards ON			
SWITCH		5		ON 1 2 3 4 5 6 8 9	ON 1 2 3 4 5 6 10 11	When power supply ON			
		6		ON ON 12 3 4 5 6 12 13	ON 1 2 3 4 5 6 14 ON 1 2 3 4 5 6				
	CWA	1	Test run	Operating	OFF	Under quenencien			
	SW4 2 Test run mode setting Heating		Heating	Cooling	- Under suspension				
Push switch	sw	/P	Pump down	Start	Normal	Under suspension			

- *1 Manual defrost should be done as follows.
 - ① Change the DIP SW1-1 on the outdoor controller board from OFF to ON.
 - ② Manual defrost will start by the above operation ① if all these conditions written below are satisfied.
 - · Heat mode setting
 - 10 minutes have passed since compressor started operating or previous manual defrost is finished.
 - Pipe temperature is less than or equal to 8°C.

Manual defrost will finish if certain conditions have been satisfied.

Manual defrost can be done if above conditions have been satisfied when DIP SW1-1 is changed from OFF to ON. After DIP SW1-1 is changed from OFF to ON, there is no problem if DIP SW1-1 is left ON or changed to OFF again.

This depends on the service conditions.

Type of	Switch	No.	Function	Action by the s	Effective timing		
Switch		NO.	Fullction	ON	OFF	Enecuve unning	
		1	No function	_	_	_	
	SW5	2	Power failure automatic recovery *2	Auto recovery	No auto recovery	When power supply ON	
		3,4,5,6	No function	_	_	_	
		1	Model select *3	Demand function	Low noise mode	Always	
		2	No function	_	_	_	
	SW7 *4	3	Max Hz setting (cooling)	Max Hz (cooling) × 0.8	Normal	Always	
	SVVI	4	Max Hz setting (heating)	Max Hz (heating) × 0.8	Normal	Always	
		5	No function	_	_	_	
		6	Defrost Hz setting	For high humidity	Normal	Always	
		1	No function	_	_	_	
	SW8	2	No function	_	_	_	
		3	No function	_	_	_	
	SW9	1	No function	_	_	_	
		2	Function switch	Valid	Normal	Always	
		3,4	No function	_	_	_	
		1	No function	_	_	_	
Dip switch		2	No function	_	_	_	
		3	Fan motor check mode	ON	OFF	When power supply ON during test run	
		4		MODEL SW6-4, 5, 6, 7, 8*6	3		
	SW6	5		125V OFF 1 2 3 4 5 6 7 8	3		
		6	Model select	140V OFF 1 2 3 4 5 6 7	8		
				100Y OFF 1 2 3 4 5 6 7 8			
		7		125Y OFF 1 2 3 4 5 6 7 8	3		
		8		140Y OFF 1 2 3 4 5 6 7 8	3		

^{*2 &#}x27;Power failure automatic recovery' can be set by either remote controller or this DIP SW. If one of them is set to ON, 'Auto recovery' activates. Please set "Auto recovery" basically by remote controller because not all units have DIP SW.

Please refer to the indoor unit installation manual.

*3 SW7-1, 2 are used for demand control. SW7-1, 2 are effective only at the demand control. (Refer to the next page: Special function (b))

*4 Please do not use SW7-3 to 7-5 usually. Trouble might be caused by the usage condition.

^{*5} SW6-1 to 3: Function switch.

(2) Function of connector

Types	Connector	Function	Action by open	short operation	Effective timing	
	Types	Connector	Fullction	Short	Open	Ellective timing
	Connector	CN31	Emergency operation	Start	Normal	When power supply ON


(3)Special function

(a) Low-level sound priority mode (Local wiring)

By performing the following modification, operation noise of the outdoor unit can be reduced by about 3-4 dB.

The low noise mode will be activated when a commercially available timer or the contact input of an ON/OFF switch is added to the CNDM connector (option) on the control board of the outdoor unit.

- · The ability varies according to the outdoor temperature and conditions, etc.
- ① Complete the circuit as shown when using the external input adapter (PAC-SC36NA-E). (Option)
- @SW7-1 (Outdoor unit control board): OFF
- ③ SW1 ON: Low noise mode SW1 OFF: Normal operation



- X: Relay
- Outdoor unit control board
- ® Max. 10 m
- © Power supply for relay


(b) On demand control (Local wiring)

By performing the following modification, energy consumption can be reduced to 0-100% of the normal consumption.

The demand function will be activated when a commercially available timer or the contact input of an ON/OFF switch is added to the CNDM connector (option) on the control board of the outdoor unit.

- ① Complete the circuit as shown when using the external input adapter (PAC-SC36NA-E). (Option)
- ② By setting SW7-1 on the control board of the outdoor unit, the energy consumption (compared to the normal consumption) can be limited as shown below.

	SW7-1	SW2	SW3	Energy consumption
Demand function		OFF	OFF	100%
	ON	ON	OFF	75%
		ON	ON	50%
		OFF	ON	0% (Stop)



- © External input adapter (PAC-SC36NA-E)
- Outdoor unit control board
- © Max. 10 m
- © Power supply for relay

<Display function of inspection for outdoor unit>

The blinking patterns of both LED1 (green) and LED2 (red) indicate the types of abnormality when it occurs. Types of abnormality can be indicated in details by connecting an optional part 'A-Control Service Tool (PAC-SK52ST)' to connector CNM on outdoor controller board.

[Display]

(1)Normal condition

Unit condition	Outdoor con	troller board	A-Control Service Tool		
Offic Condition	LED1 (Green)	LED2 (Red)	Check code	Indication of the display	
When the power is turned on	Lit Lit			Alternately blinking display	
When unit stops	Lit	Not lit	00, etc.		
When compressor is warming up	Lit	Not lit	08, etc.	Operation mode	
When unit operates	Lit	Lit	C5, etc.	•	

(2)Abnormal condition

Indic	ation			Error	
Outdoor oboa LED1 (Green)		Contents	Check code *1	Inspection method	Detailed reference page
		Connector (63H) is open.	F5	Oheck if connector (63H) on the outdoor controller board is not disconnected. Oheck continuity of pressure switch (63H) by multimeter.	P. 31
2 blinking	1 blinking	Miswiring of indoor/outdoor unit connecting wire, excessive number of indoor units (4 units or more)	_	Check if indoor/outdoor connecting wire is connected correctly. Check if 4 or more indoor units are connected to	P. 32 (EA)
		Miswiring of indoor/outdoor unit connecting wire (reversed wiring or disconnection)	_	outdoor unit. ③Check if noise entered into indoor/outdoor connecting wire or power supply.	P. 32 (Eb)
		Startup time over	_		P. 32 (EC)
	2 blinking	ndoor/outdoor unit communication error (signal receiving error) is letected by in door unit. ①Check if indoor/outdoor connecting wire is connected correctly. ②Check if noise entered into indoor/outdoor	P. 38		
		Indoor/outdoor unit communication error (transmitting error) is detected by indoor unit.	E7	©Check if noise entered into indoor/outdoor controller board.	P. 38
		Indoor/outdoor unit communication error (signal receiving error) is detected by outdoor unit.	eiving error) is - again.		P. 38 (E8)
3		Indoor/outdoor unit communication error (transmitting error) is detected by outdoor unit.	_		P. 30 (E9)
	3 blinking	Remote controller signal receiving error is detected by remote controller.	E0	Check if connecting wire of indoor unit or remote controller is connected correctly. Check if noise entered into transmission wire of	P. 37
		Remote controller transmitting error is detected by remote controller.	E 3	remote controller. ③Re-check error by turning off power, and on again.	P. 38
		Remote controller signal receiving error is detected by indoor unit.	E4		P. 37
		Remote controller transmitting error is detected by indoor unit.	E5		P. 38
	4 blinking	Abnormal if a connection of indoor unit and outdoor unit which uses different refrigerant is detected.	EE	Check if indoor/outdoor unit combination is authorized.	P. 39
		Check code is not defined.	EF	①Check if remote controller is MA remote controller (PAR-21MAA) ②Check if noise entered into transmission wire of remote controller. ③Check if noise entered into indoor/outdoor connecting wire. ④Re-check error by turning off power, and on again.	P. 39
		PL		 ①Check refrigerant pipes for disconnection or leakage. ②After the recovery of refrigerant, vacuum dry the whole refrigerant circuit. ③Refer to "9-5. HOW TO CHECK THE PARTS". ④Check refrigerant circuit for operation. 	P. 40
:	5 blinking	Serial communication error <communication between="" outdoor<br="">controller board and outdoor power board> <communication between="" outdoor<br="">controller board and M-NET P.C. board></communication></communication>	Ed	Check if connector (CN4) on outdoor controller board and outdoor power board is not disconnected. Check if there is poor connection of connector on outdoor controller board (CNMNT and CNVMNT).	P. 39
		Communication error of M-NET system	A0-A8	③Check M-NET communication signal.	P. 40 – P. 43

^{*1} Check code displayed on the remote controller

Continued to the next page

Indication		Error			
boa		Contents	Contents Check code *1 Inspection method		Detailed reference
3 blinking	LED2 (Red) 1 blinking	Abnormality of comp. surface thermistor(TH33) and discharge temperature (TH4)	U2	OCheck if stop valves are open. Check if connectors (TH4, TH33, LEV-A, and LEV-B) on outdoor controller board are not disconnected.	P. 33
		Abnormality of superheat due to low discharge temperature	U7	@Check if unit is filled with specified amount of refrigerant. @Measure resistance values among terminals on indoor valve and outdoor linear expansion valve using a multimeter	P. 34
	2 blinking	Abnormal high pressure (High pressure switch 63H operated.)	U1	Otheck if indoor/outdoor units have a short cycle on their air ducts. Otheck if connector (63H) on outdoor controller board is not disconnected. Otheck if heat exchanger and filter is not dirty. Measure resistance values among terminals on linear expansion valve using a multimeter.	P. 33
	3 blinking	Abnormality of outdoor fan motor rotational speed	U8	OCheck the outdoor fan motor. Ocheck if connector (TH3) on outdoor controller board is disconnected.	P. 34
	4 blinking	Compressor overcurrent breaking (Startup locked)	UF	①Check if stop valves are open. ②Check looseness, disconnection, and reversed	P. 36
		Compressor overcurrent breaking	UP	connection of compressor wiring. ③Measure resistance values among terminals on	P. 37
		Abnormality of current sensor (P.B.)	UH	compressor using a multimeter.	P. 36
		Abnormality of power module	U6	Check if outdoor unit has a short cycle on its air duct.	P. 34
	5 blinking	Open/short of discharge thermistor (TH4) and comp. surface thermistor (TH32)	U3	Check if connectors (TH3,TH4,TH6,TH7 and TH33) on outdoor controller board and connector (CN6) on outdoor power board are disconnected.	P. 33
		Open/short of outdoor thermistors (TH3, TH6, TH7 and TH8)	U4	②Measure resistance value of outdoor thermistors.	P. 34
	6 blinking	Abnormality of heatsink temperature	U5	Check if indoor/outdoor units have a short cycle on their air ducts. Measure resistance value of outdoor thermistor (TH8).	P. 34
	7 blinking	Abnormality of voltage	U9	OCheck looseness, disconnection, and reversed connection of compressor wiring. OMeasure resistance value among terminals on compressor using a multimeter. Ocheck if power supply voltage decreases. Ocheck the wiring of CN52C.	P. 35 – P. 34
4 blinking	1 blinking	Abnormality of room temperature thermistor (TH1)	P1	 ①Check if connectors (CN20, CN21, CN29 and CN44) on indoor controller board are not disconnected. ②Measure resistance value of indoor thermistors. 	*2
		Abnormality of pipe temperature thermistor /Liquid (TH2)	P2		*2
		Abnormality of pipe temperature thermistor/Condenser-Evaporator	P 9		*2
	2 blinking	Abnormality of drain sensor (DS) Float switch (FS) connector open	P4	 ①Check if connector (CN31)(CN4F) on indoor controller board is not disconnected. ②Measure resistance value of indoor thermistors. ③Measure resistance value among terminals on drain pump using a multimeter. ④Check if drain pump works. ⑤Check drain function. 	*2
		Indoor drain overflow protection	P5		*2
		Freezing (cooling)	P6	①Check if indoor unit has a short cycle on its air duct. ②Check if heat exchanger and filter is not dirty. ③Measure resistance value on indoor and outdoor fan motors. ④Check if the inside of refrigerant piping is not clogged.	*2
	4 blinking	Abnormality of pipe temperature	P8	 ①Check if indoor thermistors (TH2 and TH5) are not disconnected from holder. ②Check if stop valve is open. ③Check reversed connection of extension pipe. (on plural units connection) ④Check if indoor/outdoor connecting wire is connected correctly. (on plural units connection) 	*2


^{*1} Check code displayed on the remote controller *2 Refer to the indoor unit's service manual.

<Outdoor unit operation monitor function>

[When optional part 'A-Control Service Tool (PAC-SK52ST)' is connected to outdoor controller board (CNM)]

Digital indicator LED1 displays 2 digit number or code to inform operation condition and the meaning of check code by controlling DIP SW2 on 'A-Control Service Tool'.

Operation indicator SW2: Indicator change of self-diagnosis



	•
Display	Operation Model
0	OFF / FAN
С	COOLING / DRY
Н	HEATING
d	DEFROSTING

② Display during error postponement Postponement code is displayed when compressor stops due to the work of protection device.

Postponement code is displayed while error is being postponed.

Display

The ende alguer totaly earpar				
Display	Warming-up Compressor	Compressor	4 - way valve	Solenoid valve
0	_	_	_	_
1	_	_	_	ON
2	_	_	ON	_
3	_	_	ON	ON
4	_	ON	_	_
5	_	ON	_	ON
6	_	ON	ON	_
7	_	ON	ON	ON
8	ON	_	_	_
А	ON	_	ON	_

(3) When the display blinks

Inspection code is displayed when compressor stops due to the work of protection devices.

		U1	Abnormal high pressure (63H operated)	
		U2	Abnormal high discharging temperature and comp. surface, shortage of refrigerant	
		U3	Open/short circuit of discharge thermistor(TH4) and comp. surface thermistor(TH33)	
		U4	Open/short of outdoor unit thermistors(TH6, TH7 and TH8)	
		U5	Abnormal temperature of heatsink	
		U6	Abnormality of power module	
		U7	Abnormality of superheat due to low discharge temperature	
Disales	Imamaatianit	U8	Abnormality in outdoor fan motor	
Display	Inspection unit	Ud	Overheat protection	
0	Outdoor unit	UF	Compressor overcurrent interruption (When Comp. locked)	
1	Indoor unit 1	UH	Current sensor error	
2	Indoor unit 2	UL	Abnormal low pressure	
3	Indoor unit 3	UP	Compressor overcurrent interruption	
		PL	Abnormality of refrigerant	
4 Indoor unit 4		P1~P8	Abnormality of indoor units	
		A0~A7	Communication error of M-NET system	

Contents to be inspected (During operation)

Display	Contents to be inspected (When power is turned on)
F5	63H connector(yellow) is open.
E8	Indoor/outdoor communication error (Signal receiving error) (Outdoor unit)
E9	Indoor/outdoor communication error (Transmitting error) (Outdoor unit)
EA	Miswiring of indoor/outdoor unit connecting wire, excessive number of indoor units (4 units or more)
Eb	Miswiring of indoor/outdoor unit connecting wire(converse wiring or disconnection)
EC	Startup time over
E0~E7	Communication error except for outdoor unit

The black square (\blacksquare) indicates a switch position.

	I	The black square () indicates a swite	1
SW2 setting	Display detail	Explanation for display	Unit
ON 1 2 3 4 5 6	Discharge temperature (TH4) -20 to 217	-20 to 217 (When the discharge thermistor detects 100°C or more, hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 105°C; 0.5 s 0.5 s 2 s □1 →05 →□□	°C
ON 1 2 3 4 5 6	Output step of outdoor FAN 0 to 16	0 to 16	Step
ON 1 2 3 4 5 6	The number of ON / OFF times of compressor 0 to 9999	0 to 9999 (When the number of times is 100 or more, hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 42500 times (425 ×100 times); 0.5 s 0.5 s 2 s □4 →25 →□□	100 times
ON 1 2 3 4 5 6	Compressor integrating operation times 0 to 9999	0 to 9999 (When it is 100 hours or more, hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 2450 hours (245 ×10 hours); 0.5 s 0.5 s 2 s □2 →45 →□□	10 hours
ON 1 2 3 4 5 6	Compressor operating current 0 to 50	0 to 50 Note: Omit the figures after the decimal fractions.	А
ON 1 2 3 4 5 6	Compressor operating frequency 0 to 255	0 to 9999 (When it is 100 Hz or more, hundreds digit, tens digit and ones digit are displayed by turns. (Example) When 125 Hz; 0.5 s 0.5 s 2 s 12 →50 → □□	0.1 Hz
ON 1 2 3 4 5 6	Error postponement code history (1) of outdoor unit	Postponement code display Blinking: During postponement Lighting: Cancellation of postponement "00" is displayed in case of no postponement.	Code display
ON 1 2 3 4 5 6	Operation mode on error occurring	Operation mode of when operation stops due to error is displayed by setting SW2 like below. (SW2) ON 1 2 3 4 5 6	Code display

The black square (■) indicates a switch position.

SW2 setting	Display detail	Explanation for display	Unit
ON 1 2 3 4 5 6	Discharge temperature (TH4) on error occurring –20 to 217	-20 to 217 (When the temperature is 100°C or more, the hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 130°C; 0.5 s 0.5 s 2 s □1 →30 →□□	°C
ON 1 2 3 4 5 6	Compressor operating current on error occurring 0 to 50	0 to 50	Α
ON 1 2 3 4 5 6	Error history (1) (latest) Alternate display of abnormal unit number and code	When no error history, " 0 " and "" are displayed by turns.	Code display
ON 1 2 3 4 5 6	Error history (2) Alternate display of error unit number and code	When no error history, " 0 " and "" are displayed by turns.	Code display
ON	Thermostat ON time 0 to 999	0 to 999 (When it is 100 minutes or more, the hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 245 minutes; 0.5 s 0.5 s 2 s 2 → 45 → □□	Minute
1 2 3 4 5 6	Test run elapsed time 0 to 120	0 to 120 (When it is 100 minutes or more, the hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 105 minutes; 0.5 s 0.5 s 2 s □1 →05 →□□	Minute

The black square (**II**) indicates a switch position.

SW2 setting	Display detail	Explanation for display	Unit
3VVZ Setting		0 to 4	Offic
ON 1 2 3 4 5 6	The number of connected indoor units	(The number of connected indoor units are displayed.)	Unit
ON 1 2 3 4 5 6	Capacity setting display	Displayed as an outdoor capacity code. Capacity Code M100 20 M125 25 M140 28	Code display
ON 1 2 3 4 5 6	Outdoor unit setting information	The tens digit (Total display for applied setting) Setting details Display details H·P/Cooling only 0: H·P 1: Cooling only 1-phase/3-phase The ones digit Setting details Display details Defrosting switch 0: Normal 1: For high humidity (Example) When heat pump, 3-phase and defrosting (normal) are set up, "20" is displayed.	Code display
ON 1 2 3 4 5 6	Indoor pipe temperature / Liquid (TH2(1)) Indoor 1 - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.)	°C
ON 1 2 3 4 5 6	Indoor pipe temperature / Cond. / Eva. (TH5(1)) Indoor 1 - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.)	°C
ON 1 2 3 4 5 6	Indoor pipe temperature / Liquid (TH2(2)) Indoor 2 - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.)	°C
ON 1 2 3 4 5 6	Indoor pipe temperature / Cond. / Eva. (TH5(2)) Indoor 2 - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.)	°C
ON 1 2 3 4 5 6	Indoor room temperature (TH1) 8 to 39	8 to 39	°C

The black square (■) indicates a switch position.

C/M/O = = 44::= =:	Disales detail	The black square (iii) indicates a switch	
SW2 setting	Display detail	Explanation for display	Unit
ON 1 2 3 4 5 6	Indoor setting temperature 17 to 30	17 to 30	°C
ON 1 2 3 4 5 6	Outdoor 2-phase pipe (TH6) - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.)	°C
ON 1 2 3 4 5 6	Outdoor ambient temperature (TH7) - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.)	°C
ON 1 2 3 4 5 6	Outdoor heatsink temperature (TH8) - 40 to 200	- 40 to 200 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.) (When the thermistor detects 100°C or more, hundreds digit, tens digit and ones digit are displayed by turns.)	°C
ON 1 2 3 4 5 6	Discharge superheat SHd 0 to 255 [SHd = TH4-TH6]	0 to 255 (When the temperature is 100°C or more, hundreds digit, tens digit and ones digit are displayed by turns.)	°C
ON 1 2 3 4 5 6	Number of defrost cycles 0 to FFFE	0 to FFFE (in hexadecimal notation) (When more than FF in hex (255 in decimal), the number is displayed in order of 16³'s and 16²'s, and 16¹'s and 16⁰'s places. (Example) When 5000 cycles; 0.5 s 0.5 s 2 s 9 → C4 → □□	2 cycles
ON 1 2 3 4 5 6	Input current of outdoor unit	0 to 500 (When it is 100 or more, hundreds digit, tens digit and ones digit are displayed by turns.)	0.1 A
ON 1 2 3 4 5 6	LEV-B opening pulse	0 to 480 (When it is 100 pulse or more, hundreds digit, tens digit and ones digit are displayed by turns.)	Pulse
ON 1 2 3 4 5 6	U9 error detail history (latest)	Description Display	Code display

The black square (**II**) indicates a switch position.

		The black square () Indicates a switch	
SW2 setting	Display detail	Explanation for display	Unit
ON 1 2 3 4 5 6	DC bus voltage 0 to 500 (PUZ-M·VKA2) 0 to 1000 (PUZ-M·YKA2)	0 to 500 (PUZ-M·VKA2) 0 to 1000 (PUZ-M·YKA2) (When it is 100 V or more, hundreds digit, tens digit and ones digit are displayed by turns.)	V
ON 1 2 3 4 5 6	Capacity save 0 to 100 When air conditioner is connected to M-NET and capacity save mode is demanded, "0" to "100" is displayed. [When there is no setting of capacity save "100" is displayed.	0 to 100 (When the capacity is 100% hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 100%; 0.5 s 0.5 s 2 s □1 →00 →□□	%
ON 1 2 3 4 5 6	Error postponement code history (2) of outdoor unit	Postponement code display Blinking: During postponement Lighting: Cancellation of postponement "00" is displayed in case of no postponement.	Code display
ON 1 2 3 4 5 6	Error postponement code history (3) of outdoor unit	Postponement code display Blinking: During postponement Lighting: Cancellation of postponement "00" is displayed in case of no postponement.	Code display
ON 1 2 3 4 5 6	Error history (3) (Oldest) Alternate display of abnormal unit number and code.	When no error history, "0" and "" are displayed by turns.	Code display
ON 1 2 3 4 5 6	Error thermistor display [When there is no error thermistor, "-" is displayed.	6: Outdoor 2-phase pipe (TH6) 7: Outdoor ambient temperature (TH7) 8: Outdoor heatsink (TH8)	Code display
ON 1 2 3 4 5 6	Operation frequency on error occurring 0 to 255	0 to 255 (When it is 100 Hz or more, hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 125 Hz; 0.5 s 0.5 s 2 s □1 →25 →□□	Hz
ON 1 2 3 4 5 6	Fan step on error occurring 0 to 16	0 to 16	Step
ON 1 2 3 4 5 6	Indoor room temperature (TH1) on error occurring 8 to 39	8 to 39	°C

The black square (■) indicates a switch position.

014/0 (/:	B: 1 1 1 2	The black square () indicates a switch	
SW2 setting	Display detail	Explanation for display	Unit
ON 1 2 3 4 5 6	Indoor pipe temperature / Liquid (TH2) on error occurring - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "–" and temperature are displayed by turns.) (Example) When -15°C; 0.5 s 0.5 s 2 s -□ →15 →□□	°C
ON 1 2 3 4 5 6	Indoor pipe temperature / Cond./ Eva. (TH5) on error occurring - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "–" and temperature are displayed by turns.) (Example) When -15°C; 0.5 s 0.5 s 2 s -□ →15 →□□	°C
ON 1 2 3 4 5 6	Outdoor 2-phase pipe (TH6) on error occurring - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "–" and temperature are displayed by turns.) (Example) When -15°C; 0.5 s 0.5 s 2 s -□ →15 →□□	°C
1 2 3 4 5 6	Outdoor ambient temperature (TH7) on error occurring - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "–" and temperature are displayed by turns.) (Example) When -15°C; 0.5 s 0.5 s 2 s	°C
ON 1 2 3 4 5 6	Outdoor heatsink temperature (TH8) on error occurring - 40 to 200	- 40 to 200 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.) (When the temperature is 100°C or more, hundreds digit, tens digit and ones digit are displayed by turns.)	°C
ON 1 2 3 4 5 6	Discharge superheat on error occurring SHd 0 to 255 [SHd = TH4 - TH6]	0 to 255 (When the temperature is 100°C or more, hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 150°C; 0.5 s 0.5 s 2 s □1 →50 →□□	°C
ON 1 2 3 4 5 6	Thermo-on time until error stops 0 to 999	0 to 999 (When it is 100 minutes or more, hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 415 minutes; 0.5 s 0.5 s 2 s □4 →15 →□□	Minute

The black square (■) indicates a switch position.

SW2 setting	Display detail	Explanation for display		
ON 1 2 3 4 5 6	Indoor pipe temperature / Liquid (TH2 (3)) Indoor 3 - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.)	°C	
ON 1 2 3 4 5 6	Indoor pipe temperature / Cond./ Eva. (TH5 (3)) Indoor 3 - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.) When there is no indoor unit, "00" is displayed.	°C	
ON 1 2 3 4 5 6	Indoor pipe temperature / Liquid (TH2 (4)) Indoor 4 - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.)	°C	
ON 1 2 3 4 5 6	Indoor pipe temperature / Cond. / Eva (TH5 (4)) Indoor 4 - 39 to 88	- 39 to 88 (When the temperature is 0°C or less, "-" and temperature are displayed by turns.) When there is no indoor unit, "00" is displayed.	°C	
ON1 2 3 4 5 6	Controlling status of compressor operating frequency	The following code will be a help to know the operating status of unit. •The tens digit Display Compressor operating frequency control 1 Primary current control 2 Secondary current control •The ones digit (In this digit, the total number of activated control is displayed.) Display Compressor operating frequency control 1 Preventive control for excessive temperature rise of discharge temperature 2 Preventive control for excessive temperature rise of condensing temperature 4 Frosting preventing control 8 Preventive control for excessive temperature rise of heatsink (Example) The following controls are activated. • Primary current control • Preventive control for excessive temperature rise of condensing temperature • Preventive control for excessive temperature rise of heatsink	Code display	
ON 1 2 3 4 5 6	Comp. surface temperature (TH33) - 52 to 221	- 52 to 221 (When the comp. surface thermistor detects 100 °C or more, hundreds digit, tens digit and ones digit are displayed by turns.) (Example) When 105°C; 0.5 s 0.5 s 2 s □1 →05 →□□	°C	

FUNCTION SETTING

10-1. UNIT FUNCTION SETTING BY THE REMOTE CONTROLLER

Each function can be set as necessary using the remote controller. The setting of function for each unit can only be done by the remote controller. Select function available from the <Table 1>.


<Table 1> Function selections

(1) Functions available when setting the unit number to 00 (Select 00 referring to @ setting the indoor unit number.)

Function	Settings	Mode No.	Setting No.	: Initial setting (when sent from the factory)	Remarks
Power failure	OFF	0.4	1		
automatic recovery	ON	01	2	•	The setting is
Indoor temperature	Average data from each indoor unit		1		applied to all
detection	Data from the indoor unit with remote controller	02	2		the units in the
	Data from main remote controller*		3		same
LOSSNAY	Not supported		1	•	refrigerant
connectivity	Supported (Indoor unit does not intake outdoor air through LOSSNAY)	03	2		system.
	Supported (Indoor unit intakes outdoor air through LOSSNAY)		3		
Power supply	240 V	0.4	1		
voltage	220 V, 230 V	04	2	•	
Frost prevention	2°C (Normal)	4 E	1	•	
temperature	3°C	15	2		
Humidifier control	When the compressor operates, the humidifier also operates.	16	1		
	When the fan operates, the humidifier also operates.	10	2		

^{*}The function is available only when the wired remote controller is used. The functions is not available for floor standing models.

Meaning of "Function setting"



(2) Functions available when setting the unit number to 01-02 or AL (07 in case of wireless remote controller) Refer to the service manual that comes with each indoor unit.

10-2. SELECTING FUNCTIONS USING THE REMOTE CONTROLLER

Refer to "14-3. SERVICE MENU" and "14-5. FUNCTION SETTING" when selecting functions.

11

MONITORING THE OPERATION DATA BY THE REMOTE CONTROLLER

11-1. HOW TO "MONITOR THE OPERATION DATA"

Refer to "14-10. REQUEST CODE" when monitoring the operation data.

11-2. Request code list

Certain indoor/outdoor combinations do not have the request code function; therefore, no request codes are displayed.


Request code	Request content	Description (Display range)	Unit	Remarks
0	Operation state	Referto "11-2-1.Detail Contents in Request Code".	-	
1	Compressor-Operating current (rms)	0 – 50	А	
2	Compressor-Accumulated operating time	0 – 9999	10 hours	
3	Compressor-Number of operation times	0 – 9999	100 times	
4	Discharge temperature (TH4)	3 – 217	°C	
5	Outdoor unit - Liquid pipe temperature	-48 – 90	°C	
6				
7	Outdoor unit-2-phase pipe temperature (TH6)	-39 – 88	°C	
8				
9	Outdoor unit-Ambient temperature (TH7)	-39 – 88	°C	
10	Outdoor unit-Heatsink temperature (TH8)	-40 – 200	°C	
11	Comp. Surface temperature	-20 – 221	°C	
12	Discharge superheat (SHd)	0 – 255	°C	
13				
14				
15				
16	Compressor-Operating frequency	0 – 255	Hz	
17	Compressor-Target operating frequency	0 – 255	Hz	
18	Outdoor unit-Fan output step	0 – 10	Step	
19	Outdoor unit-Fan 1 speed (Only for air conditioners with DC fan motor)	0 – 9999	rpm	
20	Outdoor unit-Fan 2 speed (Only for air conditioners with DC fan motor)	0 – 9999	rpm	"0" is displayed if the air conditioner is a single-fan type.
21				
22	LEV (A) opening	0 – 500	Pulses	
23	LEV (B) opening	0 – 500	Pulses	
24				
25	Primary current	0 – 50	А	
26	DC bus voltage	180 – 370	V	
27				
28				
29	Number of connected indoor units	0 – 4	Units	
30	Indoor unit-Setting temperature	17 – 30	°C	
31	Indoor unit-Intake air temperature <measured by="" thermostat=""></measured>	8 – 39	°C	
32	Indoor unit-Intake air temperature (Unit No. 1) <heat correction="" mode-4-°c=""></heat>	8 – 39	°C	"0"is displayed if the target unit is not present.
33	Indoor unit-Intake air temperature (Unit No. 2) <heat correction="" mode-4-°c=""></heat>	8 – 39	°C	↑
34	Indoor unit-Intake air temperature (Unit No. 3) <heat correction="" mode-4-°c=""></heat>	8 – 39	°C	Ť
35	Indoor unit-Intake air temperature (Unit No. 4) <heat correction="" mode-4-°c=""></heat>	8 – 39	°C	Ť
36				
37	Indoor unit - Liquid pipe temperature (Unit No. 1)	-39 – 88	°C	"0" is displayed if the target unit is not present.
38	Indoor unit - Liquid pipe temperature (Unit No. 2)	-39 – 88	°C	1
39	Indoor unit - Liquid pipe temperature (Unit No. 3)	-39 – 88	°C	1
40	Indoor unit - Liquid pipe temperature (Unit No. 4)	-39 – 88	°C	1
41				
42	Indoor unit-Cond./Eva. pipe temperature (Unit No. 1)	-39 – 88	°C	"0" is displayed if the target unit is not present.
43	Indoor unit-Cond./Eva. pipe temperature (Unit No. 2)	-39 – 88	°C	1
44	Indoor unit-Cond./Eva. pipe temperature (Unit No. 3)	-39 – 88	°C	1
45	Indoor unit-Cond./Eva. pipe temperature (Unit No. 4)	-39 – 88	°C	1
46	, , , , , , , , , , , , , , , , , , , ,			
47				
48	Thermostat ON operating time	0 – 999	Minutes	
40				

Ф				
Request code				
it o	Barrest and the	Description	11-14	Dd
<u>e</u>	Request content	(Display range)	Unit	Remarks
9		(Bispia) range)		
œ				
50	Indoor unit-Control state	Refer to "11-2-1.Detail Contents in Request Code".	_	
51	Outdoor unit-Control state			
		Refer to "11-2-1.Detail Contents in Request Code".	_	
52	Compressor-Frequency control state	Refer to "11-2-1. Detail Contents in Request Code".	_	
53	Outdoor unit-Fan control state	Refer to "11-2-1. Detail Contents in Request Code".	_	
54	Actuator output state	Refer to "11-2-1. Detail Contents in Request Code".	_	
-		Refer to "11-2-1. Detail Contents in Request Code".	_	
55	Error content (U9)	Intelet to 11-2-1. Detail Contents in Nequest Code .	_	
56				
57				
58				
59				
60	Signal transmission demand capacity	0 – 255	%	
61	Contact demand capacity	Refer to "11-2-1. Detail Contents in Request Code".	_	
62	External input state (silent mode, etc.)	Refer to "11-2-1. Detail Contents in Request Code".	_	
	External input state (shellt mode, etc.)	Train to TT 2 1.Datas contents sit request code .		
63				
64				
65				
66				
67				
68				
69				
	Outdoor unit Canacity setting display	Refer to "11-2-1.Detail Contents in Request Code".	_	
70	Outdoor unit-Capacity setting display	Reier to 11-2-1.Detail Contents in Request Code .	_	
71	Outdoor unit-Setting information	Refer to "11-2-1. Detail Contents in Request Code".	_	
72				
73	Outdoor unit-SW1 setting information	Refer to "11-2-1.Detail Contents in Request Code".	_	
-		Refer to "11-2-1. Detail Contents in Request Code".		
74	Outdoor unit-SW2 setting information	Relei to 11-2-1.Detail Contents in Request Code .		
75				
76	Outdoor unit-SW4 setting information	Refer to "11-2-1.Detail Contents in Request Code".	-	
77	_	Refer to "11-2-1. Detail Contents in Request Code".	_	
-	Outdoor unit-SW5 setting information			
78	Outdoor unit-SW6 setting information	Refer to "11-2-1. Detail Contents in Request Code".	-	
79	Outdoor unit-SW7 setting information	Refer to "11-2-1. Detail Contents in Request Code".	_	
80	Outdoor unit-SW8 setting information	Refer to "11-2-1.Detail Contents in Request Code".	_	
81				
	Outdoor unit-SW9 setting information	Refer to "11-2-1.Detail Contents in Request Code".	_	
82	Outdoor unit-SW10 setting information	Refer to "11-2-1.Detail Contents in Request Code".	_	
83				
		"0000": Not connected		
84	M-NET adapter connection (presence/absence)	"0001": Connected	_	
		5501 : Connected		
85				
86				
87				
88				
00	Display of execution of replace wash exercises	"0000": Not washed		
89	Display of execution of replace/wash operation	"0001": Washed	_	
90	Outdoor unit-Microprocessor version information	Examples) Ver 5.01 → "0501"	Ver	
90	Outdoor unit-witcroprocessor version information		vei	
		Auxiliary information (displayed after		
91	Outdoor unit-Microprocessor version information (sub No.)	version information)	_	
	`	Examples) Ver 5.01 A000 → "A000"		
000				
92				
93				
94				
95				
96				
97				
98				
99				
100	Outdoor unit - Error nostnonement history 1 (latest)	Displays postponement code. (" " is	Code	
100	Outdoor unit - Error postponement history 1 (latest)	displayed if no postponement code is present)	Code	
		Displays postponement code. (" " is		
101	Outdoor unit - Error postponement history 2 (previous)		Code	
		displayed if no postponement code is present)		
400	Outdoor unit Error postnonoment history & float had	Displays postponement code. (" " is	Cod-	
102	Outdoor unit - Error postponement history 3 (last but one)	displayed if no postponement code is present)	Code	
		, , , , , , , , , , , , , , , , , , ,		

Request code	Request content	Description (Display range)	Unit	Remarks
_	Error history 1 (latest)	Displays the history. ("" is displayed if no history is present.)	Code	
104	Error history 2 (second to last)	Displays the history. ("" is displayed if no history is present.)	Code	
105	Error history 3 (third to last)	Displays the history. ("" is displayed if no history is present.)	Code	
106	Abnormal thermistor display (TH6/TH7/TH8)	6 : TH6 7 : TH7 8 : TH8 0 : No thermistor error	Sensor number	
107	Operation mode at time of error	Displayed in the same way as request code "0".	_	
108	Compressor-Operating current at time of error	0 – 50	Α	
109	Compressor-Accumulated operating time at time of error	0 – 9999	10 hours	
110	Compressor-Number of operation times at time of error	0 – 9999	100 times	
111	Discharge temperature at time of error	3 – 217	°C	
112	Outdoor unit - Liquid pipe temperature	-40 – 90	°C	
113				
114	Outdoor unit-2-phase pipe temperature (TH6) at time of error	-39 – 88	°C	
115	= F			
116	Outdoor unit-Ambient temperature (TH7) at time of error	-39 – 88	°C	
117	Outdoor unit-Heatsink temperature (TH8) at time of error	-40 – 200	°C	
\vdash	Discharge superheat (SHd) at time of error	0 – 255	°C	
118	Discharge superheat (SHu) at time of error	0 – 255	C	
119	0 0 0 0	0.055		
120	Compressor-Operating frequency at time of error	0 – 255	Hz	
121	Outdoor unit at time of error • Fan output step	0 – 10	Step	
122	Outdoor unit at time of error • Fan 1 speed (Only for air conditioners with DC fan)	0 – 9999	rpm	
123	Outdoor unit at time of error • Fan 2 speed (Only for air conditioners with DC fan)	0 – 9999	rpm	"0"is displayed if the air conditioner is a single- fan type.
124	r an 2 opost (em) for an estimation of man be fairly			in type.
125	LEV (A) opening at time of error	0 – 500	Pulses	
126	LEV (B) opening at time of error	0 – 500	Pulses	
127	ELV (B) opening at time of error	0 - 000	1 discs	
128				
129	Therese to the ON first wife a section of the transfer	0.000	Minutes	
130	Thermostat ON time until operation stops due to error	0 – 999	Minutes	
131				
132	Indoor - Liquid pipe temperature at time of error	-39 – 88	°C	Average value of all indoor units is displayed if the air conditioner consists of 2 or more indoor units (twin, triple, quad).
133	Indoor - Cond/Eva. pipe temperature at time of error	-39 – 88	°C	Average value of all indoor units is displayed if the air conditioner consists of 2 or more indoor units (twin, triple, quad).
134	Indoor at time of error	-39 – 88	°C	
104	$\bullet Intake air temperature {<} Thermostat judge temperature {>}$		0	
135	U9: Error history detailed codes	01 – 20	_	
136				
137				
138				
139				
140				
~				
146				
147				
148				
149	Indeed Actual inteller sinter	20 00	00	
	Indoor - Actual intake air temperature	-39 – 88	°C	
151	Indoor - Liquid pipe temperature	-39 – 88	°C	
152	Indoor - Cond/Eva. pipe temperature	-39 – 88	°C	

Request code	Request content	Description (Display range)	Unit	Remarks
153				
154	Indoor-Fan operating time (After filter is reset)	0 – 9999	1 hour	
155	Indoor-Total operating time (Fan motor ON time)	0 – 9999	10 hours	
156				
157	Indoor fan output value (Sj value)	0 – 255 Fan control data	-	For indoor fan phase control
158	Indoor fan output value (Pulsation ON/OFF)	"00 **" "**" indicates fan control data.	-	For indoor fan pulsation control
159	Indoor fan output value (duty value)	"00 **" "**" indicates fan control data.	_	For indoor DC brushless motor control
160				
161				
162				
163	Indoor unit-Capacity setting information	Refer to "11-2-1.Detail Contents in Request Code".	-	
164	Indoor unit-SW3 information	Undefined	_	
165	Wireless pair No. (indoor control board side) setting	Refer to "11-2-1.Detail Contents in Request Code".	_	
166	Indoor unit-SW5 information	Undefined	_	
167				
~				
189				
190	Indoor unit-Microprocessor version information	Examples) Ver 5.01 → "0501"	Ver	
191	Indoor unit-Microprocessor version information (sub No.)	Auxiliary information (displayed after version information) Examples) Ver 5.01 A000 → "A000"	-	

11-2-1. Detail Contents in Request Code




Example) Request code "004"

Discharge temperature 69°C

Refrigerant address "00"

- A: Maintenance mode display
- B: Refrigerant address
- C: Data display area
- D: Request code display area

[Operation state] (Request code: "0")




Operation mode				
Display	Operation mode			
0	STOP • FAN			
С	COOL • DRY			
Н	HEAT			
d	DEFROST			

Relay output state

Display	Power currently supplied to compressor	Compressor	Four-way valve	Solenoid valve
0	-	-	_	-
1				ON
2			ON	
3			ON	ON
4		ON		
5		ON		ON
6		ON	ON	
7		ON	ON	ON
8	ON			
Α	ON		ON	

[Indoor unit - Control state] (Request code: "50")




Display	State
0	Normal
1	Preparing for heat operation
2	_
3	_
4	Heater is ON.
5	Anti-freeze protection is ON.
6	Overheat protection is ON.
7	Requesting compressor to turn OFF
F	There are no corresponding units.

[Outdoor unit - Control state] (Request code: "51")

D	Data display			State	
0	0	0	0	Normal	
0	0	0	1	Preparing for heat operation	
0	0	0	2	Defrost	

[Compressor - Frequency control state] (Request code: "52")

Data display




Frequency control state ①

Display	Current limit control
0	No current limit
1	Primary current limit control is ON.
2	Secondary current limit control is ON.

Frequency control state ②


Display	Discharge temperature	Condensation temperature	Anti-freeze	Heatsink temperature
Display	overheat prevention	overheat prevention	protection control	overheat prevention
0				
1	Controlled			
2		Controlled		
3	Controlled	Controlled		
4			Controlled	
5	Controlled		Controlled	
6		Controlled	Controlled	
7	Controlled	Controlled	Controlled	
8				Controlled
9	Controlled			Controlled
Α		Controlled		Controlled
b	Controlled	Controlled		Controlled
С			Controlled	Controlled
d	Controlled		Controlled	Controlled
Е		Controlled	Controlled	Controlled
F	Controlled	Controlled	Controlled	Controlled

[Fan control state] (Request code: "53")



Display	Correction value
- (minus)	-1
0	0
1	+1
2	+2

[Actuator output state] (Request code: "54")



Actuator output state (1)


ACIUAIOI OI				Compressor is
Display	SV1	Four-way valve	Compressor	
_				warming up
0				
1	ON			
2		ON		
3	ON	ON		
4			ON	
5	ON		ON	
6		ON	ON	
7	ON	ON	ON	
8				ON
9	ON			ON
Α		ON		ON
b	ON	ON		ON
С			ON	ON
d	ON		ON	ON
Е		ON	ON	ON
F	ON	ON	ON	ON

Actuator output state ②

Display	52C	SV2	SS
0			
1	ON		
2		ON	
3	ON	ON	
4			ON
5	ON		ON
6		ON	ON
7	ON	ON	ON

[Error content (U9)] (Request code: "55") Note: Refer to "9-3. SELF-DIAGNOSIS ACTION TABLE" for more information.

: Detected



Error content ①

LITOI COITE			. Detected	
Display	Overvoltage	Undervoltage	L ₁ -phase	Power synchronizing
Display	error	error	open error	signal error
0				
1	•			
2		•		
3	•	•		
4			•	
5	•		•	
6		•	•	
7	•	•	•	
8				•
9	•			•
Α		•		•
b	•	•		•
С			•	•
d	•		•	•
Е		•	•	•
F	•	•	•	•

3

[Contact demand capacity] (Request code: "61")

Data display 0 0 0 *

Setting content

Setting con	tent
Display	Setting value
0	0%
1	50%
2	75%
3	100%

[External input state] (Request code: "62")

Data display 0 0 0 * Input state

Input state	Input state Input state				
Display	Contact demand	Silent mode	Spare 1	Spare 2	
Display	input	input	input	input	
0					
1	•				
2		•			
3	•	•			
4			•		
5	•		•		
6		•	•		
7	•	•	•		
8				•	
9	•			•	
Α		•		•	
b	•	•		•	
С			•	•	
d	•		•	•	
Е		•	•	•	
F	•	•	•	•	

[Outdoor unit - Capacity setting display] (Request code: "70")

Model	Data display	Capacity
M100	20	100
M125	25	125
M140	28	140

[Outdoor unit - Setting information] (Request code: "71")

Data display 0 0 * * Setting information ①
Setting information ②

Setting information ①

	Cotting information &				
Display De		Defrost mode			
o turiuu		Standard			
		For high humidity			

Setting information ②

outing mornation (
Display	1-phase/	Heat pump/		
Display	3-phase	cooling only		
0	1-phase	Heat pump		
1	1-pilase	Cooling only		
2	3-phase	Heat pump		
3	J-priase	Cooling only		

[Indoor unit - Capacity setting information] (Request code: "163")

Data display



Display	Capacity setting state	Display	Capacity setting state
00		10	42
01		11	
02		12	48
03		13	
04		14	
05		15	
06		16	
07		17	
08		18	
09		19	
0A		1A	
0b		1b	
0C		1C	
0d		1d	
0E		1E	
0F		1F	

[Wireless pair No. (indoor control board side) setting] (Request code: "165")

Data display



Display	Pair No. setting state			
00	No. 0			
01	No. 1 J41 disconnected			
02	No. 2 J42 disconnected			
03	No. 3 J41, J42 disconnected			

EASY MAINTENANCE FUNCTION


12-1. SMOOTH MAINTENANCE

12-1-1. PAR-4xMAA ("x" represents 0 or later)

Refer to "14-9. SMOOTH MAINTENANCE" for operation procedure.

12-1-2. PAR-21MAA

- · Reduces maintenance work drastically.
- Enables you to check operation data of the indoor and outdoor units by remote controller.
 Furthermore, use of maintenance stable-operation control that fixes the operating frequency, allows smooth inspection, even for inverter models.



<Guide for operation condition>

Checkpoints

Enter the temperature differences between (5), (4), (7) and (8) into the graph given below.

Operation state is determined according to the plotted areas on the graph.


For data measurements, set the fan speed to "Hi" before activating maintenance mode.

		Inspection ite	Result					
~ ģ	con-		Breaker	Good		Retigh	tened	
ldd	se c	Terminal block	Outdoor Unit	Good		Retigh	tened	
Power supply	Loose c		Indoor Unit	Good		Retigh	tened	
)We		(Insulation resistance)					M"	
ď		(Voltage)					V	
Com		Accumulated operating time					Time	
		② Number of ON/OFF times					Times	
pres	SOI	③ Current					Α	
	ē	4 Refrigerant/heat exc	changer temperature	COOL	°C	HEAT	°C	
	Temperature	Refrigerant/disch	COOL	°C	HEAT	°C		
5	J De	Air/outside air temperature		COOL	°C	HEAT	°C	
Outdoor Unit	Ę.	(Air/discharge temperature)		COOL	°C	HEAT	°C	
뒱	<u></u>	Appearance		Good		Cleaning	required	
0	eanli- ss	Heat exchanger		Good		Cleaning	required	
	Clea	Sound/vibration		None		Pres	ent	
	<u>e</u>	⑦ Air/intake air temperature		COOL	°C	HEAT	°C	
	rati	lat	(Air/discharge t	temperature)	COOL	°C	HEAT	°C
	Temperature	® Refrigerant/heat ex	changer temperature	COOL	°C	HEAT	°C	
불	e e	Filter operating	time*				Time	
Indoor Unit	Cleanliness	Decorative panel		Good		Cleaning	required	
		Filter		Good		Cleaning required		
	Ē	Fan		Good		Cleaning	required	
	l e	Heat exchanger		Good		Cleaning	required	
	Ľ	Sound/vibration		None		Present		

С	lassification	ltem		Result	
	Inspection	Is "D000" displayed stably on the remote controller?	Stable	Unstable	
Cool	Temperature difference	(⑤ Discharge temperature) – (④ Outdoor heat exchanger temperature)	°C		
		(⑦ Indoor intake air temperature) – (⑧ Indoor heat exchanger temperature)	°C		
	Inspection	Is "D000" displayed stably on the remote controller?	Stable	Unstable	
Heat	Temperature difference	(⑤ Discharge temperature) – (⑧ Indoor heat exchanger temperature)	°C		
		(③ Indoor heat exchanger temperature) – (⑦ Indoor intake air temperature)	°(


- * Fixed Hz operation may not be possible under the following temperature ranges.
- A)In cool mode, outdoor intake air temperature is 40 °C or higher or indoor intake air temperature is 23°C or lower.
- B)In heat mode, outdoor intake air temperature is 20 °C or higher or indoor intake air temperature is 25 °C or lower.
- * If the air conditioner is operated at a temperature range other than the ones above but operation is not stabilized after 30 minutes or more have elapsed, carry out inspection.
- * In heat mode, the operation state may vary due to frost forming on the outdoor heat exchanger.

Cool mode





Heat mode



[⑤ Discharge temperature] – [⑥ Indoor heat exchanger temperature)

Result

Area	Check item	Judgement		
7		Cool	Heat	
Normal	Normal operation state			
Filter inspection	Filter may be clogged. *1			
Inspection A	Performance has dropped. Detailed in-			
	spection is necessary.			
Inspection B	Refrigerant amount is dropping.			
Inspection C	Filter or indoor heat exchanger may be			
	clogged.			

The above judgement is just guide based on Japanese standard conditions.

It may change depending on the indoor and outdoor temperature.

*1 It may be judged as "Filter inspection" due to the outdoor and indoor temperature, even though it is not clogged.

^{*} The filter operating time is the time that has elapsed since the filter was reset.

DISASSEMBLY PROCEDURE

- Indicates the visible parts in the photos/figures.
- ----->: Indicates the invisible parts in the photos/figures.

OPERATING PROCEDURE

1. Removing the service panel and top panel


- (1) Remove 3 service panel fixing screws (5 × 12) and slide the hook on the right downward to remove the service
- (2) Remove screws (2 for front, 3 for rear/5 × 12) of the top panel and remove it.

Photo 1 Top panel fixing screws Top panel Service panel Slide Service panel fixing screws Cover panel (rear) Cover panel Grille fixing Cover panel fixing screws screws (front)

PHOTOS/FIGURES


2. Removing the fan motor (MF1)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1)
- (4) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2)
- (5) Disconnect the connector CNF1 on controller circuit board in electrical parts box. (See Photo 4)
- (6) Loosen a clamp on the side of the motor support. (See Photo 3)
- (7) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3)



3. Removing the electrical parts box


- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the indoor/outdoor connecting wire and power supply wire from the terminal block.
- (4) Disconnect the connector CNF1, LEV-A and LEV-B on the controller circuit board.
 - <Symbols on the board>
 - · CNF1: Fan motor
 - LEV-A and LEV-B: LEV
- (5) Disconnect the pipe-side connections of the following parts.
 - Thermistor <Liquid> (TH3)
 - Thermistor <Discharge>(TH4)
 - Thermistor <2-phase pipe, Ambient>(TH7/6)
 - High pressure switch (63H)
 - Thermistor <Comp. surface> (TH33)
 - 4way valve (21S4)
- (6) Remove a nut from the terminal cover. (See Photo16, 17)
- (7) Remove the terminal cover and disconnect the compressor lead wire.




From the previous page.


OPERATING PROCEDURE

(8) Remove 2 electrical parts box fixing screws (4 × 10) and detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.




PHOTOS/FIGURES







4. Disassembling the electrical parts box (VKA2 type2)

- (1) Disconnect all the connectors on the controller circuit board.
- (2) Remove the screws ①, that fix the plate equipped with the outdoor controller circuit board, and the electrical parts box. (See Photo 8)
- (3) Remove the controller circuit board. (See Photo 8)
- (4) Disconnect the connectors of reactor on the bottom plate of the electrical parts box. (See Photos 9-1 and 9-2)
- (5) Remove 4 (100VKA2) or 2 (125/140VKA2) screws ② on the rear plate of the electrical parts box. (See Photos 9-1 and 9-2)
- (6) Remove the reactor(s). (See Photos 9-1 and 9-2)
- Note: 1. When reassembling the electrical parts box, make sure that the wirings are correct.
 - 2. When exchanging the reactor, make sure to exchange all the 3 reactors.





*This photo is for 100VKA2 type.



From the previous page.

OPERATING PROCEDURE

4. Disassembling the electrical parts box (YKA2 type)

- (1) Disconnect all the connectors on the controller circuit board.
- (2) Remove the screws ①, that fix the plate equipped with the outdoor controller circuit board, and the electrical parts box. (See Photo 10)
- (3) Remove the controller circuit board. (See Photo 10)
- (4) Disconnect all the connectors on the noise filter board. (See Photo 11)
- (5) Remove 9 supports on the noise filter circuit board. (See Photo 11)
- (6) Remove the noise filter circuit board. (See Photo 11)
- (7) Remove the noise filter plate fixing screws. (See Photo 11)
- (8) Disconnect the connectors of reactor on the bottom plate of the electrical parts box. (See Photo 12)
- (9) Remove 4 screws ② on the bottom plate of the electrical parts box. (See Photo 12)
- (10) Remove the reactor. (See Photo 12)


Note: 1. When reassembling the electrical parts box, make sure that the wirings are correct.

Photo 10 Electrical parts box Screws ①

PHOTOS/FIGURES

Noise filter circuit board (C.I.

Controller circuit board (C.B.)







Photo 13





4. Disassembling the electrical parts box (YKA2R1 model)

- (1) Disconnect all the connectors on the controller circuit board.
- (2) Remove the screws ①, that fix the plate equipped with the outdoor controller circuit board, and the electrical parts box. (See Photo 14)
- (3) Remove the controller circuit board. (See Photo 14)
- (4) Disconnect all the connectors on the noise filter board. (See Photo 15)
- (5) Remove 9 supports on the noise filter board. (See Photo 15)
- (6) Remove the noise filter circuit board. (See Photo 15)
- (7) Remove the noise filter plate fixing screws ②. (See Photo 15)
- (8) Remove the power circuit board fixing screws (2 for front/ M4 × 12, 2 for front/M3 × 12). (See Photo 16)
- (9) Remove 5 supports on the power circuit board. (See Photo 16)
- (10) Remove the power circuit board. (See Photo 16)
- (11) Disconnect the connectors of reactor on the bottom plate of the electrical parts box. (See Photo 17)
- (12) Remove 4 screws on the bottom plate of the electrical parts box. (See Photo 17)
- (13) Remove the reactor. (See Photo 17)

Note: When reassembling the electrical parts box, make sure that the wirings are correct.

PHOTOS/FIGURES





Noise filter circuit board (N.F.) Supports

Photo 16

Power circuit board (P.B.) Power circuit board fixing screws Reactor (DCL) Photo 17 Electrical parts box $(M3 \times 12)$ Supports Resistor Power circuit board Screws fixing screws Connectors (M4 × 12) of reactor Thermistor (TH8) Supports

5. Removing the thermistor <2-phase pipe> (TH6)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connector TH7/6 (red), on the controller circuit board in the electrical parts box.
- (4) Loosen the 2 wire clamps on top of the electrical parts box.
- (5) Pull out the thermistor <2-phase pipe> (TH6) from the sensor clip.

Note: When replacing thermistor <2-phase pipe> (TH6), replace it together with thermistor <Ambient> (TH7) since they are combined together.

Refer to procedure No.6 to remove thermistor <Ambient>.

Thermistor Photo 18 <2-phase pipe>(TH6) Electrical parts box Clamp

6. Removing the thermistor <Ambient> (TH7)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connector TH7/6 (red) on the controller circuit board in the electrical parts box.
- (4) Loosen the 2 wire clamps on top of the electrical parts box. (See Photo 18)
- (5) Pull out the thermistor <Ambient> (TH7) from the sensor holder.

Note: When replacing thermistor <Ambient> (TH7), replace it together with thermistor <2- phase pipe> (TH6), since they are combined together. Refer to procedure No.5 to remove thermistor <2-phase pipe>.

7. Removing the thermistor <Liquid> (TH3), thermistor <Discharge> (TH4) and thermistor <Comp. surface> (TH33)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 2 cover panel (front) fixing screws (5 × 12) and remove the cover panel (front). (See Photo 1)
- (4) Remove 4 cover panel (rear) fixing screws (5 × 12) and remove the cover panel (rear). (See Photo 1)
- (5) Remove 4 right side panel fixing screws (5 × 12) in the rear of the unit and remove the right side panel (See Photo 24)
- (6) Disconnect the connectors, TH3 (white), TH4 (white) and TH33 (black) on the controller circuit board in the electrical parts box.
- (7) Loosen the fastener for the lead wire under the electrical parts box. (See Photo 20)
- (8) Pull out the thermistor <Liquid> (TH3) from thermistor clip.
- (9) Pull out the thermistor < Discharge> (TH4) from the thermistor holder. (See Photo 22)

[Removing the thermistor < Comp. surface> (TH33)]

- (10) Remove the sound proof cover (upper) for compressor. (See Photo 22)
- (11) Pull out the thermistor <Comp. surface> (TH33) from the holder of the compressor shell. (See Photo 23)

PHOTOS/FIGURES

Thermistor < Ambient > (TH7) Photo 19




Photo 20




Photo 21




Photo 22 (100V/YKA2)





Photo 23 (140V/YKA2)



8. Removing LEV coil

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the LÉV coil by sliding the coil upward. (See Photo 25)
- (4) Disconnect the connectors, LEV-B (RD) on the controller circuit board in the electrical parts box.

9. Removing LEV

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 2 cover panel (front) fixing screws (5 × 12) and remove the cover panel (front). (See Photo 1)
- (4) Remove 4 cover panel (rear) fixing screws (5 × 12) and remove the cover panel (rear).
- (5) Remove 3 valve bed fixing screws (4 × 10) and 4 stop valve fixing screws (5 × 16, 2 for gas and 2 for liquid) then remove the valve bed.(See Photo 24)
- (6) Remove 2 right side panel fixing screws (5 × 12) in the rear of the unit then remove the right side panel. (See Photo 24)
- (7) Remove the LEV coil. (See Photo 25)
- (8) Recover refrigerant.
- (9) Remove the welded part of LEV.
- Note 1: Recover refrigerant without spreading it in the air. Note 2: The welded part can be removed easily by
- removing the right side panel.
- Note 3: When installing the LEV, cover it with a wet cloth to prevent it from heating (120°C or more), then braze the pipes so that the inside of pipes are not oxidized.

10. Removing the high pressure switch (63H)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 2 cover panel (front) fixing screws (5 × 12) and remove the cover panel (front). (See Photo 1)
- (4) Remove 4 cover panel (rear) fixing screws (5 × 12) and remove the cover panel (rear). (See Photo 1)
- (5) Remove 4 right side panel fixing screws (5 × 12) in the rear of the unit and remove the right side panel (See Photo 24)
- (6) Pull out the lead wire of high pressure switch. (See Photo 25)
- (7) Recover refrigerant.
- (8) Remove the welded part of high pressure switch.
- Note 1: Recover refrigerant without spreading it in the air.
- Note 2: The welded part can be removed easily by removing the right side panel.
- Note 3: When installing the high pressure switch, cover it with a wet cloth to prevent it from heating (100°C or more), then braze the pipes so that the inside of pipes are not oxidized.

PHOTOS/FIGURES





Photo 25



11. Removing the 4-way valve coil (21S4)

(1) Remove the service panel. (See Photo 1)

[Removing the 4-way valve coil]

- (2) Remove 4-way valve coil fixing screw (M5 × 6.5).
- (3) Remove the 4-way valve coil by sliding the coil toward you.
- (4) Disconnect the connector 21S4 (green) on the outdoor multi controller circuit board in the electrical parts box.

12. Removing the 4-way valve

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box (See Photo 4)
- (4) Remove 3 valve bed fixing screws (5 × 12) and 8 stop valve fixing screws (5 × 16) and then remove the valve bed. (See Photo 24)
- (5) Remove 4 right side panel fixing screw (5 × 12) in the rear of the unit and then remove the right side panel.
- (6) Remove the 4-way valve coil. (See Photo 25)
- (7) Recover refrigerant.
- (8) Remove the welded part of 4-way valve.
- Note 1: Recover refrigerant without spreading it in the air.
- Note 2: The welded part can be removed easily by removing the right side panel.
- Note 3: When installing the 4-way valve, cover it with a wet cloth to prevent it from heating (120°C or more), then braze the pipes so that the inside of pipes are not oxidized.


13. Removing the compressor (MC)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 2 cover panel (front) fixing screws (5 × 12) and remove the cover panel (front). (See Photo 1)
- (4) Remove 3 valve bed fixing screws (5 x 12) and 4 stop valve fixing screws (5 x 16, 2 for gas and 2 for liquid) and then remove the valve bed.
- (5) Remove the nut from the terminal cover. (See Photo 22)
- (6) Remove the terminal cover to disconnect the compressor lead wire.
- (7) Recover refrigerant.
- (8) Remove the 3 points of the compressor fixing nut using a spanner or an adjustable wrench.
- (9) Remove the welded pipe of compressor inlet and outlet and then remove the compressor.

Note: Recover refrigerant without spreading it in the air.

PHOTOS/FIGURES

Photo 26



(MC)


14

REMOTE CONTROLLER

14-1. REMOTE CONTROLLER FUNCTIONS

<PAR-41MAA>

Controller interface



① [ON/OFF] button

Press to turn ON/OFF the indoor unit.

② [SELECT] button

Press to save the setting

③ [RETURN] button

Press to return to the previous screen.

4 [MENU] button

Press to bring up the Main menu.

⑤ Backlit LCD

Operation settings will appear


When the backlight is off, pressing any button turns the backlight on and it will stay lit for a certain period of time depending on the screen.

When the backlight is off, pressing any button turns the backlight on and does not perform its function. (except for the [ON/OFF] button)

The functions of the function buttons change depending on the screen.

Refer to the button function guide that appears at the bottom of the LCD for the functions they serve on a given screen.

When the system is centrally controlled, the button function guide that corresponds to the locked button will not appear.



6 ON/OFF lamp

This lamp lights up in green while the unit is in operation. It blinks while the remote controller is starting up or when there is an error.

⑦ Function button [F1]

Main display: Press to change the operation mode.

Menu screen: The button function varies with the screen.

8 Function button [F2]

Main display: Press to decrease temperature. Main menu: Press to move the cursor left.

Menu screen: The button function varies with the screen.

9 Function button [F3]

Main display: Press to increase temperature. Main menu: Press to move the cursor right.

Menu screen: The button function varies with the screen.

® Function button [F4]


Main display: Press to change the fan speed.

Menu screen: The button function varies with the screen.

Display

The main display can be displayed in two different modes: "Full" and "Basic". The initial setting is "Full". To switch to the "Basic" mode, change the setting on the Main display setting. (Refer to operation manual included with remote controller.)

- <Full mode>
- * All icons are displayed for explanation.



- ① Operation mode
- 2 Preset temperature
- 3 Clock
- 4 Fan speed

■ ⑤ Button function guide

Functions of the corresponding buttons appear here.



Appears when the ON/OFF operation is centrally controlled.

7 6 %

Appears when the operation mode is centrally controlled.

8 P

Appears when the preset temperature is centrally controlled.



Appears when the filter reset function is centrally controlled.

0

Indicates when filter needs maintenance.


- **I** ⊕ Room temperature
- **I** @ 🗗

Appears when the buttons are locked

Appears when the On/Off timer, Night setback, or Auto-off timer function is enabled.

appears when the timer is disabled by the centralized control system.

<Basic mode>



14 **2**

Appears when the Weekly timer is enabled.



Appears while the units are operated in the energy saving mode. (Will not appear on some models of indoor units)



Appears while the outdoor units are operated in the silent mode.

Appears when the built-in thermistor on the remote controller is activated to monitor the room temperature (1).

appears when the thermistor on the indoor unit is activated to monitor the room temperature.

∎®©

Indicates the vane setting

19 🐷

Indicates the louver setting.

■ @ 💥

Indicates the ventilation setting.

Appears when the preset temperature range is restricted.

Appears when an energy saving operation is performed using a "3D isee Sensor" function.

3 Centrally controlled


Appears for a certain period of time when a centrally-controlled item is operated

■ ② Preliminary error display


A check code appears during the preliminary error.

Most settings (except ON/OFF, mode, fan speed, temperature) can be made from the Main menu.

Menu structure



Not all functions are available on all models of indoor units.



Not all functions are available on all models of indoor units.

Main menu list

Main menu	Setting and display items		Setting details	
Operation	Vane · 3D i-see · Vent. (Vane.Vent. (Lossnay))		Vane: Use to set the vertical air direction. Louver: Use to set the horizontal air direction. 3D i-see Sensor: This setting is available only for the air conditioners that support easy setting function of motion sensing air direction. Vent: Use to set the amount of ventilation.	
	High power *3		Use to reach the comfortable room temperature quickly. • Units can be operated in the High-power mode for up to 30 minutes.	
	Comfort	Manual vane angle	Vertical air direction • Sets the vertical airflow direction (vane) of each unit.	
			Horizontal air direction Sets the horizontal airflow direction (vane) of each unit.	
		3D i-see Sensor	Use to set the following functions for 3D i-see Sensor. • Air distribution • Energy saving option • Seasonal airflow	
Timer	Timer	ON/OFF timer *1	Use to set the operation ON/OFF times. • Time can be set in 5-minute increments.	
		Auto-OFF timer	Use to set the Auto-OFF time. • Time can be set to a value from 30 to 240 in 10-minute increments.	
	Weekly timer *1, *2		Use to set the weekly operation ON/OFF times. • Up to 8 operation patterns can be set for each day. (Not valid when the ON/OFF timer is enabled.)	
	OU silent mode *1, *3		Use to set the time periods in which priority is given to quiet operation of outdoor units over temperature control. Set the Start/Stop times for each day of the week. •Select the desired silent level from "Normal," "Middle," and "Quiet."	
	Night setback *1		Use to make Night setback settings. • Select "Yes" to enable the setting, and "No" to disable the setting. The temperature range and the start/stop times can be set.	
Energy saving	Restriction	Temp. range *2	Use to restrict the preset temperature range. • Different temperature ranges can be set for different operation modes.	
		Operation lock	Use to lock selected functions. • The locked functions cannot be operated.	
	Energy saving	Auto return *2	Use to get the units to operate at the preset temperature after performing energy saving operation for a specified time period. • Time can be set to a value from 30 and 120 in 10-minute increments. (This function will not be valid when the preset temperature ranges are restricted.)	
		Schedule *1, *3	Set the start/stop times to operate the units in the energy saving mode for each day of the week, and set the energy saving rate. • Up to 4 energy saving operation patterns can be set for each day. • Time can be set in 5-minute increments. • Energy saving rate can be set to a value from 0% or 50 to 90% in 10% increments.	
	Energy data (for unit time, month, and day)		 Displays the amount of power consumption during operation. Unit time data: Data for the last one-month period can be displayed in 30-minute units. Monthly/daily data: Data for the last 14-month period are displayed in day-and-month-units. * Data can be deleted. * Data are obtained based on the power consumption estimated from the operating state. 	

^{*1} Clock setting is required.

OCH773C 99


^{*2 1°}C increments.

^{*3} This function is available only when certain outdoor units are connected.

Main menu	Setting and display items		Setting details
Initial setting	Basic setting	Main/Sub	When connecting 2 remote controllers, one of them needs to be designated as a sub controller.
		Clock	Use to set the current time.
		Daylight saving time	Set the daylight saving time.
		Administrator password	The administrator password is required to make the settings for the following items. • Timer setting • Energy saving setting • Weekly timer setting • Restriction setting • Outdoor unit silent mode setting • Night set back
	Display setting	Main display	Use to switch between "Full" and "Basic" modes for the Main display, and use to change the background colors of the display to black.
		Display details	Make the settings for the remote controller related items as necessary. Clock: The initial settings are "Yes" and "24h" format. Temperature: Set either Celsius (°C) or Fahrenheit (°F). Room temp.: Set Show or Hide. Auto mode: Set Auto mode display or Only Auto display.
		Contrast • Bright- ness	Use to adjust screen contrast and brightness.
			Use to select the desired language.
	Operation setting	Auto mode	Whether or not to use Auto mode can be selected by using the button. This setting is valid only when indoor units with Auto mode function are connected.
Mainte- nance	Error information		Use to check error information when an error occurs. • Check code, error source, refrigerant address, model name, manufacturing number, contact information (dealer's phone number) can be displayed. (The model name, manufacturing number, and contact information need to be registered in advance to be displayed.)
	Filter information		Use to check the filter status. • The filter sign can be reset.
	Cleaning	Auto descending panel	Use to lift and lower the auto descending panel (Optional parts).
Service	Test run		Select "Test run" from the Service menu to bring up the Test run menu. • Test run • Drain pump test run
	Input maintenance info.		Select "Input maintenance Info." from the Service menu to bring up the Maintenance information screen. The following settings can be made from the Maintenance Information screen. Model name input Serial No. input Dealer information input Initialize maintenance info.
	Settings	Function setting	Make the settings for the indoor unit functions via the remote controller as necessary.
	Check	Error history	Display the error history and execute "delete error history".
		Diagnosis	Self check: Error history of each unit can be checked via the remote controller.
			Remote controller check: When the remote controller does not work properly, use the remote controller checking function to troubleshoot the problem.
		Smooth mainte- nance *3	Use to display the maintenance data of indoor/outdoor units.
		Request code *3	Use to check operation data such as thermistor temperature and error information.
	Others	Maintenance password	Use to change the maintenance password.
		Initialize remote controller	Use to initialize the remote controller to the factory shipment status.
		Remote control- ler information	Use to display the remote controller model name, software version, and serial number.

 $[\]ensuremath{^{\star_3}}$ This function is available only when certain outdoor units are connected.


<PAR-SL97A-E>



- When using the wireless remote controller, point it towards the receiver on the indoor unit.
- If the remote controller is operated within approximately two minutes after power is supplied to the indoor unit, the indoor unit may beep twice as the unit is performing the initial automatic check.
- The indoor unit beeps to confirm that the signal transmitted from the remote controller has been received.
 Signals can be received up to approximately 7 meters in a direct line from the indoor unit in an area 45 to the left and right of the unit.
 However, illumination such as fluorescent lights and strong light can affect the ability of the indoor unit to receive signals.
- If the operation lamp near the receiver on the indoor unit is blinking, the unit needs to be inspected. Consult your dealer for service.
- Handle the remote controller carefully. Do not drop the remote controller or subject it to strong shocks.
 In addition, do not get the remote controller wet or leave it in a location with high humidity.
- To avoid misplacing the remote controller, install the holder included with the remote controller on a wall
 and be sure to always place the remote controller in the holder after use.


<PAR-SL100A-E>

Controller interface



This button is enabled or disabled depending on the model of the indoor unit.

Display



14-2. ERROR INFORMATION

When an error occurs, the following screen will appear. Check the error status, stop the operation, and consult your dealer.


 Check code, error unit, refrigerant address, date and time of occurrence, model name, and serial number will appear.

The model name and serial number will appear only if the information have been registered.

Press the F1 or F2 button to go to the next page.




Contact information (dealer's phone number) will appear if the information has been registered.



2. Press the F4 button or the (b) button to reset the error that is occurring.

Errors cannot be reset while the ON/OFF operation is prohibited.






Navigating through the screens

• To go back to the Service menu [🗏] button

· Checking the error information

While no errors are occurring, page 2/2 of the error information can be viewed by selecting "Error information" from the Maintenance menu. Errors cannot be reset from this screen.



14-3. SERVICE MENU

Maintenance password is required

- 1. Select "Service" from the Main menu, and press the [✓] button.
 - *At the main display, the menu button and select "Service" to make the maintenance setting.



When the Service menu is selected, a window will appear asking for the password.

To enter the current maintenance password (4 numerical digits), move the cursor to the digit you want to change with the F1 or F2 button.



Set each number (0 through 9) with the F3 or F4 button.



Then, press the [

Note: The initial maintenance password is "9999". Change the default password as necessary to prevent unauthorized access. Have the password available for those who need it.

: If you forget your maintenance password, you can initialize the password to the default password "9999" by pressing and holding the F1 button for 10 seconds on the maintenance password setting screen.



3. If the password matches, the Service menu will appear.

The type of menu that appears depends on the connected indoor units' type.

Note: Air conditioning units may need to be stopped to make only at "Settings". There may be some settings that cannot be made when the system is centrally controlled.



A screen will appear that indicates the setting has been saved.

Navigating through the screens

- To go back to the Service menu[🗏] button






14-4. TEST RUN 14-4-1. PAR-41MAA


1. Select "Service" from the Main menu, and press the [\checkmark] button.



Select "Test run" with the F1 or F2 button, and press the [✓] button.



2. Select "Test run" with the F1 or F2 button, and press the [✓] button.



Test run operation


Press the F1 button to go through the operation modes in the order of "Cool and Heat".

Cool mode: Check the cold air blows out. Heat mode: Check the heat blows out.

Check the operation of the outdoor unit's fan.



Press the [\checkmark] button and open the Vane setting screen.



Auto vane check

Check the auto vane with the F1 F2 F3 buttons.



Press the [3] button to return to "Test run operation".



When the test run is completed, the "Test run menu" screen will appear.

The test run will automatically stop after 2 hours.

*The function is available only for the model with vanes.




14-4-2. PAR-SL97A-E

Measure an impedance between the power supply terminal block on the outdoor unit and ground with a 500 V Megger and check that it is equal to or greater than 1.0 $M\Omega$.

- 1. Turn on the main power to the unit.
- 2. Press the button twice continuously. (Start this operation from the status of remote controller display turned off.)
 - A and current operation mode are displayed.
- 3. Press the ☐ (����;) button to activate couls mode, then check whether cool air blows out from the unit.
- 4. Press the ☐ (❖◊♣❖⇨) button to activate HEAT ❖ mode, then check whether warm air blows out from the unit.
- 5. Press the 📆 button and check whether strong air blows out from the unit.
- 6. Press the button and check whether the auto vane operates properly.
- 7. Press the ON/OFF button to stop the test run.


Note:

- Point the remote controller towards the indoor unit receiver while following steps 2 to 7.
- · It is not possible to run in FAN, DRY or AUTO mode.



14-4-3. PAR-SL100A-E

- 1. Press the button to stop the air conditioner.
 - If the weekly timer is enabled (new is on), press the button ③ to disable it (new is off).
- Press the button @ for 5 seconds.
 - GREGIN comes on and the unit enters the service mode.
- 3. Press the www button @.
 - (IEST) (B) comes on and the unit enters the test run mode.
- 4. Press the following buttons to start the test run.
 - Switch the operation mode between cooling and heating and start the test run.
 - *: Switch the fan speed and start the test run.
 - Switch the airflow direction and start the test run.
 - : Switch the louver and start the test run.
 - Start the test run.
- 5. Stop the test run.
 - Press the ____ button ① to stop the test run.
 - · After 2 hours, the stop signal is transmitted.




14-5. FUNCTION SETTING 14-5-1. PAR-41MAA


1. Select "Service" from the Main menu, and press the [✓] button.

Select "Setting" from the Service menu, and press the [✓] button.

Select "Function setting", and press the [




- Set the indoor unit refrigerant addresses and unit numbers with the F1
 through F4 buttons, and then press the [✓] button to confirm the current setting.
- 3. When data collection from the indoor units is completed, the current settings appears highlighted. Non-highlighted items indicate that no function settings are made. Screen appearance varies depending on the "Unit No." setting.



<The display format and the setting method vary with indoor units.> Pattern 1

- 4. Use the F1 or F2 button to move the cursor to select the mode number, and change the setting number with the F3 or F4 button.
- 5. When the settings are completed, press the [
] button to send the setting data from the remote controller to the indoor units.
- When the transmission is successfully completed, the screen will return to the Function setting screen.







Pattern 2


- 4. Toggle through the pages with the F3 or F4 button.
- Select the mode number with the F1 or F2 button, and then press the [✓] button.
- 6. Select the setting number with the F1 or F2 button. Setting range for modes 1 through 28: 1 through 3 Setting range for modes 31 through 66: 1 through 15
- When the settings are completed, press the [ightharpoonup] button to send the setting data from the remote controller to the indoor units.
- 8. When the transmission is successfully completed, the screen will return to the Function setting screen.

Note:

- Make the function settings shown in Table 1 on Mr. SLIM units as necessary.
- Refer to the Instructions Book when it is necessary to set the settings for CITY MULTI units.
- Table 1 summarizes the setting options for each mode number. Refer to the indoor unit Installation
- Manual for the detailed information about initial settings, mode numbers, and setting numbers for the indoor units.
- Be sure to write down the settings for all functions if any of the initial settings has been changed after the completion of installation work.








14-5-2. PAR-SL97A-E

Functions can be selected with the wireless remote controller. Function selection using wireless remote controller is available only for refrigerant system with wireless function. Refrigerant address cannot be specified by the wireless remote controller.

[Flow of function selection procedure]



The procedure is given after the flow chart. Check the function selection setting. ② Switch to function selection mode. Check mode is the mode entered when (Enter address "50" in check mode, you press the CHECK button twice to display then press the ____ button.) "CHECK" 3 Specify unit No. "01" (since the function applies to unit 01). (Set address "01" while still in check mode, then press the button.) LYES Note: You cannot specify the refrigerant address. Change <unit № Select mode No. "24" (function that raises set temperature by 4 degrees during HEAT operation). (Set address "24" while still in check mode, then press the _____ button.) (S) Select setting No. "02" (OFF). (Set address "02" while still in check mode, then press the button.) NO. Finished

or longer

Note: When you switch to function selection mode

on the wireless remote controller's operation

area, the unit ends function selection mode automatically if nothing is input for 10 minutes

The flow of the function selection procedure is shown below. This example shows how to turn off the function that raises the set temperature by 4 degrees during HEAT operation. (Mode 24: 2)

[Operating instructions]

- 1. Check the function settings.
- 2. Press the button twice continuously. → CHECK is lit and "00" blinks.

Press the TEMP (b) button once to set "50". Direct the wireless remote controller toward the receiver of the indoor unit and press the indoor unit a

Ĭ YES

(End check mode.)

® End function selection mode.

Set the unit number.

Press the TEMP () button to set the unit number. (Press "01" to specify the indoor unit whose unit number is 01.)

Direct the wireless remote controller toward the receiver of the indoor unit and press the button.

By setting unit number with the _____ button, specified indoor unit starts performing fan operation.

Detect which unit is assigned to which number using this function. If unit number is set to AL, all the indoor units in same refrigerant system start performing fan operation simultaneously.

Notes

- 1. If a unit number that cannot be recognized by the unit is entered, 3 beeps of 0.4 seconds will be heard. Reenter the unit number setting.
- 2. If the signal was not received by the sensor, you will not hear a beep or a "double beep" may be heard. Reenter the unit number setting.
- 4. Select a mode.

Press the TEMP (a) button to set a mode. Press "24" to turn on the function that raises the set temperature by 4 degrees during heat operation. Direct the wireless remote controller toward the sensor of the indoor unit and press the button.

→ The sensor-operation indicator will blink and beeps will be heard to indicate the current setting number

Current setting number: 1 = 1 beep (1 second)

2 = 2 beeps (1 second each)

3 = 3 beeps (1 second each)

Notes:

- 1. If a mode number that cannot be recognized by the unit is entered, 3 beeps of 0.4 seconds will be heard. Reenter the mode number.
- 2. If the signal was not received by the sensor, you will not hear a beep or a "double beep" may be heard. Reenter the mode number.
- 5. Select the setting number.

Press the TEMP (1) button to select the setting number. (02: Not available)

Direct the wireless remote controller toward the receiver of the indoor unit and press the ____ button.

→ The sensor-operation indicator will blink and beeps will be heard to indicate the setting number.

Setting number: 1 = 2 beeps (0.4 seconds each)

2 = 2 beeps (0.4 seconds each, repeated twice)

3 = 2 beeps (0.4 seconds each, repeated 3 times)

Notes:

- 1. If a setting number that cannot be recognized by the unit is entered, the setting will turn back to the original setting.
- 2. If the signal was not received by the sensor, you will not hear a beep or a "double beep" may be heard. Reenter the setting number.
- 6. Repeat steps (4) and (5) to make an additional setting without changing unit number.
- 7. Repeat steps 3 to 5 to change unit number and make function settings on it.
- 8. Complete the function settings

Press (button.

Do not use the wireless remote controller for 30 seconds after completing the function setting.

14-5-3. PAR-SL100A-E



Fig. 1



Fig. 2



Fig. 3



Fig. 4

1. Going to the function select mode

Press the MENU button between of 5 seconds.

(Start this operation from the status of remote controller display turned off.)

[CHECK] is lit and "00" blinks. (Fig. 1) Press the button to set the "50".

Direct the wireless remote controller toward the receiver of the indoor unit and press the SET button.

2. Setting the unit number

Press the button to set unit number (a. (Fig. 2)

Direct the wireless remote controller toward the receiver of the indoor unit and press the SET button.

3. Selecting a mode

Press the button to set Mode number ®. (Fig. 3)

Direct the wireless remote controller toward the receiver of the indoor unit and

press the SET button. Current setting number:

1=1 beep (1 second) 2=2 beep (1 second each)

3=3 beep (1 second each)

4. Selecting the setting number

Use the button to change the Setting number ©. (Fig. 4)

Direct the wireless remote controller toward the receiver of the indoor unit and press the SET button.

5. To select multiple functions continuously

Repeat select ③ and ④ to change multiple function settings continuously.

6. Complete function selection

Direct the wireless remote controller toward the sensor of the indoor unit and press the OOFF/ON button.

Note: Be sure to write down the settings for all functions if any of the initial settings has been changed after the completion of installation work.

14-6. ERROR HISTORY


1. Select "Service" from the Main menu, and press the [✓] button.



Select "Check" with the $\boxed{\text{F1}}$ or $\boxed{\text{F2}}$ button, and press the [\checkmark] button.



Select "Error history" with the $\boxed{\text{F1}}$ or $\boxed{\text{F2}}$ button, and press the $\boxed{\checkmark}$ button.




 Select "Error history" from the Error history menu, and press the [✓] button.



3. 16 error history records will appear.

4 records are shown per page, and the top record on the first page indicates the latest error record.



4. Deleting the error history

To delete the error history, press the F4 button (Delete) on the screen that shows error history.

A confirmation screen will appear asking if you want to delete the error history.




Press the F4 button (OK) to delete the history.



"Error history deleted" will appear on the screen.

Press the [3] button to go back to the Error history menu screen.






5. Preliminary error history

Select "Preliminary error history" from the Error history menu, and press the [\checkmark] button.

32 preliminary error history records will appear.

4 records are shown per page, and the top record on the first page indicates the latest error record.



6. Deleting the preliminary error history

To delete the preliminary error history, press the F4 button (Delete) on the screen that shows preliminary error history.


A confirmation screen will appear asking if you want to delete the preliminary error history.



Press the F4 button (OK) to delete the preliminary error history.



"Preliminary error history deleted" will appear on the screen. Press the [3] button to go back to the Error history menu.



14-7. SELF-DIAGNOSIS


14-7-1. PAR-41MAA

 Select "Service" from the Main menu, and press the [) button.

Select "Check" from the Service menu, and press the [✓] button.

Select "Diagnosis" from the Check menu, and press the [\checkmark] button.


Select "Self check" with the F1 or F2 button, and press the [✓] button.



2. With the $\boxed{\texttt{F1}}$ or $\boxed{\texttt{F2}}$ button, enter the refrigerant address, and press the [\checkmark] button.



- 3. Check code, unit number, attribute will appear.
 - "-" will appear if no error history is available.



When there is no error history



4. Resetting the error history

Press the F4 button (Reset) on the screen that shows the error history.



A confirmation screen will appear asking if you want to delete the error history.




Press the F4 button (OK) to delete the error history.

If deletion fails, "Request rejected" will appear.

"Unit not exist" will appear if no indoor units that are correspond to the entered address are found.

Navigating through the screens

- To go back to the Service menu [] button






14-7-2. PAR-SL97A-E

When a malfunction occurs to air conditioner, both indoor unit and outdoor unit will stop and operation lamp blinks to inform unusual stop.


<Malfunction-diagnosis method at maintenance service>



[Procedure]

- 1. Press the CHECK button twice.
 - "CHECK" lights, and refrigerant address "00" blinks.
 - Check that the remote controller's display has stopped before continuing.
- 2. Press the TEMP (1) (a) buttons.
- Select the refrigerant address of the indoor unit for the self-diagnosis. Note: Set refrigerant address using the outdoor unit's DIP switch (SW1). (For more information, see the outdoor unit installation manual.)
- Point the remote controller at the sensor on the indoor unit and press the HOUR button.
 - If an air conditioner error occurs, the indoor unit's sensor emits an intermittent buzzer sound, the operation light blinks, and the check code is output.
- Point the remote controller at the sensor on the indoor unit and press the ON/OFF button.
 - · The check mode is cancelled.

14-7-3. PAR-SL100A-E



- 1. Press the button ① to stop the air conditioner.
 - If the weekly timer is enabled (is on), press the to disable it (is off).
- 2. Press the MENU button @ for 5 seconds.
 - CHECK (A) comes on and the unit enters the self-check mode.
- 3. Press the button to select the refrigerant address (M-NET address) to of the indoor unit for which you want to perform the self-check.
- 4. Press the stron 4.
 - If an error is detected, the check code is indicated by the number of beeps from the indoor unit and the number of blinks of the OPERATION INDICATOR lamp.
- 5. Press the ____ button ①.
 - IMEX (A) and the refrigerant address (M-NET address) (B) go off and the self-check is completed.

14-8. REMOTE CONTROLLER CHECK

If operations cannot be completed with the remote controller, diagnose the remote controller with this function.

 Select "Service" from the Main menu, and press the [✓] button.




Select "Check" from the Service menu, and press the [✓] button.



Select "Diagnosis" from the Check menu, and press the [✓] button.



Select "Remote controller check" with the $\boxed{\text{F1}}$ or $\boxed{\text{F2}}$ button, and press the $\boxed{\checkmark}$ button.




Select "Remote controller check" from the Diagnosis menu, and press the
 J button to start the remote controller check and see the check results.



To cancel the remote controller check and exit the "Remote controller check" menu screen, press the [] or the [] button.



The remote controller will not reboot itself.




3. OK: No problems are found with the remote controller. Check other parts for problems.

E3, 6832: There is noise on the transmission line, or the indoor unit or another remote controller is faulty. Check the transmission line and the other remote controllers.

NG (ALL0, ALL1): Send-receive circuit fault. The remote controller needs replacing. ERC:

The number of data errors is the discrepancy between the number of bits in the data transmitted from the remote controller and that of the data that was actually transmitted over the transmission line. If data errors are found, check the transmission line for external noise interference.

Remote controller check results screen



If the [\checkmark] button is pressed after the remote controller check results are displayed, remote controller check will end, and the remote controller will automatically reboot itself.

Check the remote controller display and see if anything is displayed (including lines). Nothing will appear on the remote controller display if the correct voltage (8.5–12 VDC) is not supplied to the remote controller. If this is the case, check the remote controller wiring and indoor units.

14-9. SMOOTH MAINTENANCE


1. Select "Service" from the Main menu, and press the [✓] button.



Select "Check" with the F1 or F2 button, and press the [✓] button.



Select "Smooth maintenance" with the $\boxed{\text{F1}}$ or $\boxed{\text{F2}}$ button, and press the $\boxed{\checkmark}$ button.



2. Set each item.

Select the item to be changed with the F1 or F2 button.

Select the required setting with the $\boxed{\text{F3}}$ or $\boxed{\text{F4}}$ button.


- <Ref.address>setting [0]-[15]
 <Stable mode>setting [Cool]/ [Heat]/ [Normal]
- Press the [✓] button, Fixed operation will start. Note: Stable mode will take approx. 20 minutes.







3. The operation data will appear.

The Compressor-Accumulated operating (COMP. run) time is 10-hour unit, and the Compressor-Number of operation times (COMP. ON/OFF) is a 100-time unit (fractions discarded).








Navigating through the screens

- To go back to the Service menu [🗏] button




14-10. REQUEST CODE

Details on the operation data including each thermistor temperature and error history can be confirmed with the remote controller.

1. Select "Service" from the Main menu, and press the [✓] button.

Select "Check" with the F1 or F2 button, and press the [✓] button.

Select "Request code" with the F1 or F2 button, and press the [




2. Set the Refrigerant address and Request code.

Select the item to be changed with the F1 or F2 button.

Select the required setting with the F3 or F4 button.

- ■<Ref.address>setting [0]-[15]
- ■<Request code>setting

Press the [✓] button, Data will be collected and displayed.



Request code

▶ Ref address

Request code: 004

Discharge temperature: 69°C



MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN