

**PUMY-P Series Branch Box Connection Compatibility Table for PUMY-P112/125/140/200**

Series	Type	Model Name	Capacity										
			15	18	20	22	25	35	42	50	60	71	100
M Series	Wall-Mounted	MSZ-LN-VG2					●	●		●			
		MSZ-AP-VG(K)	●		●		●	●	●	●			
		MSZ-FH+VE2					●	●		●			
		MSZ-EF+VE		●		●	●	●	●	●			
		MSZ-EF-VG(K)		●		●	●	●	●	●			
		MSZ-SF+VA	●		●								
		MSZ-AP+VF	●		●								
	Floor-Standing	MSZ-SF-VE3					●	●	●	●			
		MSZ-GF+VE2									●	●	
		MFZ-KT+VG					●	●		●			
1-way Cassette	MFZ-KJ+VE-E					●	●		●				
	MLZ-KP+VF					●	●		●				
S Series	Ceiling-Concealed	MLZ-KA+VA-E					●	●		●			
		SEZ-M+DA(L)2					●	●		●	●	●	
		SEZ-KD+VA-E					●	●		●	●	●	
	2x2 Cassette	SEZ-M+DA(L)2-E*1					●	●		●	●	●	
		SLZ-M+FA(2)	●				●	●		●			
P Series	Ceiling-Suspended	SLZ-KF+VA-E					●	●		●			
		PCA-M+KA(2)						●		●	●	●	
	4-way Cassette	PCA-RP+KAQ-E						●		●	●	●	
		PLA-M+EA(2)						●		●	●	●	
		PLA-RP+EA-E						●		●	●	●	
	Ceiling-Concealed	PEAD-M+JA(L)								●	●	●	
		PEAD-RP+JA(L)Q-E								●	●	●	
		PEAD-M+DA(L)2*1							●	●	●		

(1) Connectable outdoor units are PUMY-P112/125/140VKM6(YKM5) only.

**PUMY-P Series LEV Kit Connection Compatibility Table for PUMY-P112/125/140/200**

Series	I/U Type	Model Name	Capacity									
			15	18	20	22	25	35	42	50	60	71
M Series	Wall-mounted	MSZ-LN-VG2					●	●		●		
		MSZ-AP-VG(K)	●		●		●	●	●	●		
		MSZ-FH+VE2					●	●		●		
		MSZ-EF-VG(K)		●		●	●	●	●	●		
		MSZ-SF+VA	●		●							
	MSZ-SF-VE3					●	●	●	●			
Floor-Standing	MFZ-KT+VG					●	●		●			

**PUMY-P Series CITY MULTI Indoor Unit Compatibility Table for PUMY-P112/125/140**

Series	Type	Model Name	Capacity													
			P10	P15	P20	P25	P32	P40	P50	P63	P71	P80	P100	P125	P140	P200
CITY MULTI series	1-way cassette	PMFY-P+VBM-E			●	●	●	●								
	2-way cassette	PLFY-P+VLM-E			●	●	●	●	●	●		●	●	●		
	4-way cassette	PLFY-M+VEM-E			●	●	●	●	●	●		●	●	●		
		PLFY-M+VEM6-E			●	●	●	●	●	●	●	●	●	●		
		PLFY-P+VFM-E		●	●	●	●	●	●							
	Ceiling-concealed	PEFY-P+VMR-E-L/R			●	●	●									
		PEFY-P+VMS1-E		●	●	●	●	●	●							
		PEFY-M+VMA-A(1)			●	●	●	●	●	●	●	●	●	●	●	
		PEFY-P+VMHS-E						●	●	●	●	●	●	●	●	
		PEFY-P+VMHS-E-F												●	●	
	Ceiling-suspended	PCFY-P+VKM-E						●		●			●	●		
	Wall-mounted	PKFY-P+VLM-E	●	●		●	●	●	●							
		PKFY-P+VKM-E									●			●		
	Floor-standing	PFFY-P+VKM-E2			●	●	●	●								
		PFFY-P+VLE-E			●	●	●	●	●	●						
		PFFY-P+VLRM-E			●	●	●	●	●	●						
		PFFY-P+VLRMM-E			●	●	●	●	●	●						
		PFFY-P+VCM-E			●	●	●	●	●	●						
	ATW	PWFY-P+VM-E1*1													●	
	Lossnay *2															GUF-50/100RD(H)4

\*1 Note that connection is not allowed inside EU countries and UK.

PWFY can not connect to PUMY-P200YKM2.

\*2 Do not connect Lossnay remote controller(s). (PZ-61DR-E, PZ-60DR-E, PZ-52SF-E, PZ-43SMF-E)