

# VRV 5 heat pump Air Conditioning Technical Data RXYA-A



RXYA8A7Y1B  
RXYA10A7Y1B  
RXYA12A7Y1B  
RXYA14A7Y1B  
RXYA16A7Y1B  
RXYA18A7Y1B  
RXYA20A7Y1B  
RXYA10A7Y1B.  
RXYA13A7Y1B  
RXYA16A7Y1B.  
RXYA18A7Y1B.  
RXYA20A7Y1B.  
RYMA5A7Y1B



# TABLE OF CONTENTS

## RXYA-A

1	<b>Features</b>	5
	RXYA-A	5
2	<b>Specifications</b>	6
3	<b>Options</b>	12
4	<b>Combination table</b>	13
5	<b>Capacity tables</b>	15
	Capacity Table Legend	15
	Integrated Heating Capacity Correction Factor	16
	Capacity Correction Factor	17
6	<b>Dimensional drawings</b>	21
7	<b>Centre of gravity</b>	22
8	<b>Piping diagrams</b>	23
9	<b>Wiring diagrams</b>	24
	Wiring Diagrams - Three Phase	24
10	<b>External connection diagrams</b>	26
11	<b>Sound data</b>	27
	Sound Power Spectrum - Cooling	27
	Sound Power Spectrum - Heating	31
	Sound Pressure Spectrum - Cooling	35
	Sound Pressure Spectrum - Heating	39
	Sound level data Quiet mode	43
	Sound power level at high ESP	45
12	<b>Installation</b>	46
	Installation Method	46
	Fixation and Foundation of Units	47
	Refrigerant Pipe Selection	48
	Refrigerant Charge Information	50
13	<b>Operation range</b>	65

14 Appropriate Indoors

66

# 1 Features

## 1 - 1 RXYA-A

### The sustainability champion

- › Reduced CO2 equivalent thanks to the use of lower GWP R-32 refrigerant and lower refrigerant charge
- › Top sustainability over the entire lifecycle, thanks to market leading real-life seasonal efficiency
- › Tackle small room applications without any additional measures, thanks to Shirudo technology
- › Specially designed indoor units for R-32, ensuring low sound and maximum efficiency
- › Provides highly efficient heating or cooling
- › Incorporates VRV standards & technologies: Variable Refrigerant Temperature, continuous heating, VRV configurator, 7 segment display and full inverter compressors, 4-side heat exchanger, refrigerant cooled PCB, new DC fan motor



# 2 Specifications

## 2 - 1 Specifications

2

Technical Specifications				RXYA8A	RXYA10A	RXYA12A	RXYA14A	RXYA16A	RXYA18A	RXYA20A	
Recommended combination				4 x FXFA50A2VEB	4 x FXFA63A2VEB	6 x FXFA50A2VEB	1 x FXFA50A2VEB + 5 x FXFA63A2VEB	4 x FXFA63A2VEB + 2 x FXFA80A2VEB	3 x FXFA50A2VEB + 5 x FXFA63A2VEB	8 x FXFA63A2VEB	
Recommended combination 2				4 x FXSA50A2VEB	4 x FXSA63A2VEB	6 x FXSA50A2VEB	1 x FXSA50A2VEB + 5 x FXSA63A2VEB	4 x FXSA63A2VEB + 2 x FXSA80A2VEB	3 x FXSA50A2VEB + 5 x FXSA63A2VEB	8 x FXSA63A2VEB	
Cooling capacity	Prated,c		kW	22.4 (1)	28.0 (1)	33.5 (1)	40.0 (1)	45.0 (1)	50.4 (1)	56.0 (1)	
Heating capacity	Nom.	6°CWB	kW	22.4 (2)	28.0 (2)	33.5 (2)	40.0 (2)	45.0 (2)	50.4 (2)	56.0 (2)	
	Prated,h		kW	22.4 (2)	28.0 (2)	33.5 (2)	40.0 (2)	45.0 (2)	50.4 (2)	56.0 (2)	
	Max.	6°CWB	kW	25.0 (2)	31.5 (2)	37.5 (2)	45.0 (2)	50.0 (2)	56.5 (2)	63.0 (2)	
COP at nom. capacity 6°CWB				kW/kW	3.83 (2)	3.45 (2)	3.46 (2)	3.57 (2)	3.52 (2)	3.66 (2)	3.37 (2)
SCOP					4.11	4.33	4.49	4.28	4.26	4.39	4.14
SCOP recommended combination 2					4.10	4.34	4.56		4.33		4.11
SEER					7.26	7.06	7.04	7.63	6.99	6.87	6.52
SEER recommended combination 2					6.97	6.85	6.62	7.40	6.88	6.74	6.42
ηs,c				%	287.3	279.3	278.7	302.2	276.6	271.6	257.6
ηs,c recommended combination 2				%	275.9	270.9	261.9	292.9	272.0	266.7	254.0
ηs,h				%	161.5	170.2	176.4	168.3	167.5	172.5	162.7
ηs,h recommended combination 2				%	161.1	170.4	179.5		170.2		161.4
Space cooling	A Condition (35°C - 27/19)	EERd		3.09	3.06	3.05	3.11	2.97	2.52	2.36	
		Pdc	kW	22.4	28.0	33.5	40.0	45.0	50.4	56.0	
	B Condition (30°C - 27/19)	EERd		5.13	4.95	4.49	4.84	4.65	5.01	4.65	
		Pdc	kW	16.5	20.6	24.7	29.5	33.2	37.1	41.3	
	C Condition (25°C - 27/19)	EERd		9.12	8.51	8.34	8.74	8.15	7.92	7.20	
		Pdc	kW	10.6	13.3	15.9	18.9	21.3	23.9	26.5	
	D Condition (20°C - 27/19)	EERd		15.3	14.8	17.5	22.5	16.5	14.8	16.1	
		Pdc	kW	8.13	8.19	8.57	10.93	11.10	11.19	11.79	
Space cooling recom- mended combination 2	A Condition (35°C - 27/19)	EERd		3.02	2.93	2.89	3.02	2.88	2.44	2.28	
		Pdc	kW	22.4	28.0	33.5	40.0	45.0	50.4	56.0	
	B Condition (30°C - 27/19)	EERd		4.99	4.82	4.32	4.78	4.60	4.41	4.13	
		Pdc	kW	16.5	20.6	24.8	29.5	33.2	37.1	41.3	
	C Condition (25°C - 27/19)	EERd		8.58	8.23	7.64	8.33	7.98	7.83	7.41	
		Pdc	kW	10.6	13.3	15.9	18.9	21.3	23.9	26.5	
	D Condition (20°C - 27/19)	EERd		14.58	14.40	16.23	21.53	16.23	18.25	15.94	
		Pdc	kW	7.82	7.97	8.20	10.6	10.8	10.9	11.8	
Space heating (Average climate)	TBivalent	COPd (declared COP)		2.80	2.28	2.38	2.57	2.53	2.36	2.23	
		Pdh (declared heating cap)		kW	13.7	16.0	18.4	20.6	23.2	27.9	31.0
		Tbiv (bivalent temperature)		°C				-10			
	TOL	COPd (declared COP)		2.80	2.28	2.38	2.57	2.53	2.36	2.23	
		Pdh (declared heating cap)		kW	13.7	16.0	18.4	20.6	23.2	27.9	31.0
		Tol (temperature operating limit)		°C				-10			
Space heating (Average climate)	A Condition (-7°C)	COPd (declared COP)		3.06	2.67	2.84	2.94	2.87	2.70	2.60	
		Pdh (declared heating cap)		kW	12.1	14.2	16.3	18.2	20.5	24.7	27.4
	B Condition (2°C)	COPd (declared COP)		3.81	4.23	4.15	3.86	3.93	4.19	3.84	
		Pdh (declared heating cap)		kW	7.38	8.62	9.89	11.1	12.5	15.0	16.7
	C Condition (7°C)	COPd (declared COP)		5.27	5.70	6.32	6.31	6.21	6.22	5.92	
		Pdh (declared heating cap)		kW	4.76	5.54	6.36	7.14	8.03	9.66	10.7
	D Condition (12°C)	COPd (declared COP)		7.04	7.92	9.14	6.68	6.04	6.85	7.53	
		Pdh (declared heating cap)		kW	4.51	5.46	5.52	5.15	5.07	6.24	7.16
	Space heating (Average climate) recommended combination 2	A Condition (-7°C)	COPd (declared COP)		3.00	2.62	2.83	2.95	2.89	2.62	2.54
			Pdh (declared heating cap)		kW	12.1	14.2	16.3	18.2	20.5	24.7
		B Condition (2°C)	COPd (declared COP)		3.80	4.24	4.26	3.89	3.96	4.07	3.79
			Pdh (declared heating cap)		kW	7.45	8.61	9.89	11.1	12.5	15.0
C Condition (7°C)		COPd (declared COP)		5.35	5.79	6.39	6.45	6.41	6.19	5.98	
		Pdh (declared heating cap)		kW	4.76	5.54	6.36	7.14	8.04	9.65	10.7
D Condition (12°C)		COPd (declared COP)		7.04	7.91	9.39	6.94	6.47	8.15	7.81	
		Pdh (declared heating cap)		kW	4.71	5.60	5.80	5.33	5.36	7.68	7.62
TBivalent		COPd (declared COP)		2.73	2.32	2.38	2.58	2.54	2.28	2.18	
		Pdh (declared heating cap)		kW	13.7	16.0	18.4	20.6	23.2	27.9	31.0
		Tbiv (bivalent temperature)		°C				-10			
TOL		COPd (declared COP)		2.73	2.32	2.38	2.58	2.54	2.28	2.18	
	Pdh (declared heating cap)		kW	13.7	16.0	18.4	20.6	23.2	27.9	31.0	
	Tol (temperature operating limit)		°C				-10				
Capacity range				HP	8	10	12	14	16	18	20
PED	Category			Category III							
	Most critical part	Name		Liquid receiver							
		Ps*V	Bar*l	508			612			764	
Maximum number of connectable indoor units				64 (3)							
Indoor index connection	Min.			100	125	150	175	200	225	250	
	Max.			260	325	390	455	520	585	650	

## 2 Specifications

### 2 - 1 Specifications

Technical Specifications					RXYA8A	RXYA10A	RXYA12A	RXYA14A	RXYA16A	RXYA18A	RXYA20A
Dimensions	Unit	Height	mm		1,685						
		Width	mm		930			1,240			
		Depth	mm		765						
	Packed unit	Height	mm		1,820						
		Width	mm		995			1,305			
		Depth	mm		860						
		Weight	kg		214		297		320		
Weight	kg		225		310		333				
Packing	Material		Carton								
	Weight	kg		1.5			1.8				
Packing 2	Material		Wood								
	Weight	kg		8.9			11.0				
Packing 3	Material		Plastic								
	Weight	kg		0.6			0.7				
Casing	Colour		Daikin White								
	Material		Painted galvanized steel plate								
Heat exchanger	Type		Cross fin coil								
	Indoor side		Air								
	Outdoor side		Air								
	Air flow rate	Cooling	Rated	m <sup>3</sup> /h	9,145	9,709	10,823	11,576	14,315	12,351	14,893
Heating		Rated	m <sup>3</sup> /h	9,145	9,709	10,823	13,124	14,315	12,351	14,893	
Fan	Quantity				1			2			
	External static pressure	Max.	Pa	78							
Fan motor	Quantity				1			2			
	Type		DC motor								
	Output	W		550			750				
Compressor	Quantity				1						
	Type		Hermetically sealed scroll compressor								
	Crankcase heater		W		33						
Operation range	Cooling	Min.	°CDB		-5						
		Max.	°CDB		46						
	Heating	Min.	°CWB		-20						
		Max.	°CWB		16						
Sound power level	Cooling	Nom.	dBA	78.3 (4)	78.8 (4)	82.5 (4)	79.5 (4)	83.7 (4)	83.4 (4)	87.9 (4)	
	Heating	Nom.	dBA	79.4 (4)	80.7 (4)	83.3 (4)	82.9 (4)	86.3 (4)	85.1 (4)	89.6 (4)	
Sound pressure level	Cooling	Nom.	dBA	56.3 (5)	58.0 (5)	60.8 (5)	59.0 (5)	61.6 (5)	63.0 (5)	67.0 (5)	
	Heating	Nom.	dBA	58.1 (5)	58.8 (5)	61.9 (5)	61.3 (5)	64.5 (5)	64.0 (5)	68.0 (5)	
Refrigerant	Type		R-32								
	GWP		675.0								
	Charge	kg		9.00			10.6				
	Charge	tCO <sub>2</sub> Eq		6.08			7.16				
Refrigerant oil	Type		FW68DE								
Piping connections	Liquid	Type	Braze connection								
		OD	mm		9.52			12.70			
Piping connections	Gas	Type	Braze connection								
		OD	mm		19.1			22.2		28.6	
	Total piping length	System	Actual	m		1,000 (6)					
Defrost method			Reversed cycle								
Capacity control	Method		Inverter controlled								
Indication if the heater is equipped with a supplementary heater					No						
Supplementary heater	Back-up capacity	Heating	elbu	kW		0.0					
Power consumption in other than active mode	Crankcase heater mode	Cooling	PCK	kW		0.000					
		Heating	PCK	kW		0.053			0.058		
	Off mode	Cooling	POFF	kW		0.050			0.058		
		Heating	POFF	kW		0.053			0.058		
	Standby mode	Cooling	PSB	kW		0.050			0.058		
		Heating	PSB	kW		0.053			0.058		
	Thermo-stat-off mode	Cooling	PTO	kW		0.001					
		Heating	PTO	kW		0.053			0.058		
Cooling	Cdc (Degradation cooling)				0.25						
Heating	Cdh (Degradation heating)				0.25						
Safety devices	Item	01			High pressure switch						
		02			Fan driver overload protector						
		03			Inverter overload protector						

Standard accessories: Installation and operation manual;Quantity: 1;

Standard accessories: Connection pipes;Quantity: 1;

## 2 Specifications

### 2 - 1 Specifications

2

Electrical Specifications				RXYA8A	RXYA10A	RXYA12A	RXYA14A	RXYA16A	RXYA18A	RXYA20A
Power supply	Name			Y1						
	Phase			3N~						
	Frequency	Hz	50							
	Voltage	V	380-415							
Power supply intake				Both indoor and outdoor unit						
Voltage range	Min.	%		-10						
	Max.	%		10						
Current - 50Hz	Nominal running current (RLA)	Combina- tion A	Cooling	-						
		Combina- tion B	Cooling	-						
		Cooling	A	10.5 (7)	13.4 (7)	15.7 (7)	18.8 (7)	21.4 (7)	27.8 (7)	32.8 (7)
	Starting current (MSC) - remark			See note 9						
	Zmax List			No requirements						
	Minimum Ssc value	kVa		2,789 (8)	3,810 (8)	4,157 (8)	4,676 (8)	5,369 (8)	6,062 (8)	7,274 (8)
Minimum circuit amps (MCA)	A		16.1 (9)	22.0 (9)	24.0 (9)	27.0 (9)	31.0 (9)	35.0 (9)	42.0 (9)	
Maximum fuse amps (MFA)	A		20 (10)	25 (10)	32 (10)			40 (10)	50 (10)	
Power Performance	Power factor	Combina- tion B	35°C ISO - Full load	-						
			46°C ISO - Full load	-						
Wiring connections - 50Hz	For power supply	Quantity	5G							
	For connec- tion with indoor	Quantity	2							
		Remark	F1,F2							
Compressor	Crankcase heater	W	33							

(1)Cooling: indoor temp. 27°CDB, 19°CWB; outdoor temp. 35°CDB; equivalent piping length: 7.5m; level difference: 0m |

(2)Heating: indoor temp. 20°CDB; outdoor temp. 7°CDB, 6°CWB; equivalent refrigerant piping: 7.5m; level difference: 0m |

(3)The actual number of units depends on the connection ratio (CR) and the restrictions for the system. |

(4)Sound power level is an absolute value that a sound source generates. |

(5)Sound pressure level is a relative value, depending on the distance and acoustic environment. For more details, please refer to the sound level drawings. |

(6)Refer to refrigerant pipe selection or installation manual |

(7)RLA is based on following conditions: indoor temp. 27°CDB, 19°CWB; outdoor temp. 35°CDB |

(8)In accordance with EN/IEC 61000-3-12, it may be necessary to consult the distribution network operator to ensure that the equipment is connected only to a supply with Ssc ≥ minimum Ssc value |

(9)MCA must be used to select the correct field wiring size. The MCA can be regarded as the maximum running current. |

(10)MFA is used to select the circuit breaker and the ground fault circuit interrupter (earth leakage circuit breaker). |

(11)Air Flow Rate (AFR) of multi outdoor systems is sum of AFR of the individual systems it consists of |

MSC means the maximum current during start up of the compressor. This unit uses only inverter compressors. Starting current is always ≤ max. running current. |

Maximum allowable voltage range variation between phases is 2%. |

Voltage range: units are suitable for use on electrical systems where voltage supplied to unit terminal is not below or above listed range limits. |

Sound values are measured in a semi-anechoic room. |

EN/IEC 61000-3-12: European/international technical standard setting the limits for harmonic currents produced by equipment connected to public low-voltage system with input current > 16A and ≤ 75A per phase |

Ssc: Short-circuit power |

For detailed contents of standard accessories, see installation/operation manual |

Multi combination (10~20HP) data is corresponding with the standard multi combination

Technical specifications System				RXYA10A	RXYA13A	RXYA16A	RXYA18A	RXYA20A		
System	Outdoor unit module 1			RYMA5A			RXYA8A			
	Outdoor unit module 2			RYMA5A	RXYA8A		RXYA10A	RXYA12A		
Recommended combination	4 x FXFA63A2VEB			3 x FXFA50A2VEB + 3 x FXFA63A2VEB	4 x FXFA63A2VEB + 2 x FXFA80A2VEB	4 x FXFA50A2VEB + 4 x FXFA63A2VEB	10 x FXFA50A2VEB			
Recommended combination 2	4 x FXSA63A2VEB			3 x FXSA50A2VEB + 3 x FXSA63A2VEB	4 x FXSA63A2VEB + 2 x FXSA80A2VEB	4 x FXSA50A2VEB + 4 x FXSA63A2VEB	10 x FXSA50A2VEB			
Continuous heating				Yes						
Cooling capacity	Prated,c	kW	28.0 (1)	36.4 (1)	44.8 (1)	50.4 (1)	55.9 (1)			
Heating capacity	Nom.	6°CWB	kW	28.0 (2)	36.4 (2)	44.8 (2)	50.4 (2)	55.9 (2)		
		Prated,h	kW	28.0 (2)	36.4 (2)	44.8 (2)	50.4 (2)	55.9 (2)		
	Max.	6°CWB	kW	32.0 (2)	41.0 (2)	50.0 (2)	56.5 (2)	62.5 (2)		
		COP at nom. capacity	6°CWB	kW/kW	3.66 (2)	3.76 (2)	3.72 (2)	3.61 (2)	3.60 (2)	
SCOP				4.09	4.11	4.35	4.34	4.38		
SCOP recommended combination 2				4.13	4.19	4.38	4.40	4.48		
SEER				7.55	7.42	7.12	7.18	7.16		
SEER recommended combination 2				7.23	7.08	6.87	6.85	6.86		
ηs,c				299.1	293.8	281.9	284.1	283.2		
ηs,c recommended combination 2				286.1	280.1	271.8	270.9	271.2		
ηs,h				160.6	161.5	170.9	170.5	172.2		
ηs,h recommended combination 2				162.2	164.8	172.2	173.0	176.2		
Space cooling	A Condition	EERd	3.68	3.39	3.17	3.19		3.12		
		(35°C - 27/19) Pdc	kW	28.0	36.4	44.8	50.4		55.9	
	B Condition	EERd	7.57	5.94	5.18		4.88			
		(30°C - 27/19) Pdc	kW	20.6	26.8	33.0	37.1		41.2	
	C Condition	EERd	8.99	9.04	8.63	8.59		8.53		
		(25°C - 27/19) Pdc	kW	13.5	18.0	21.2	23.9		26.5	
D Condition	EERd	11.5	13.9	14.8	14.9		16.3			
	(20°C - 27/19) Pdc	kW	14.10	15.50	15.90	16.30		16.70		

## 2 Specifications

### 2 - 1 Specifications

Technical specifications System				RXYA10A	RXYA13A	RXYA16A	RXYA18A	RXYA20A	
Space cooling recom- mended combination 2	A Condition (35°C - 27/19)	EERd		3.53	3.27	3.05	3.17	3.02	
		Pdc	kW	28.0	36.4	44.8	50.4	55.9	
	B Condition (30°C - 27/19)	EERd		7.14	5.65	4.97	4.91	4.68	
		Pdc	kW	20.6	26.8	33.0	37.1	41.2	
	C Condition (25°C - 27/19)	EERd		8.53		8.32	8.11	8.09	
Pdc		kW	13.4	17.8	21.2	23.9	26.5		
D Condition (20°C - 27/19)	EERd		11.19	13.26	14.20	14.04	15.50		
	Pdc	kW	12.8	15.0	15.5	15.8	16.0		
Space heating (Average climate)	TBivalent	COPd (declared COP)		2.69	2.74	2.87	2.51	2.55	
		Pdh (declared heating cap)		kW	16.0	21.7	23.2	27.9	31.0
Space heating (Average climate)	TBivalent	Tbiv (bivalent temperature)		°C					
		TOL		°C					
		COPd (declared COP)		2.69	2.74	2.87	2.51	2.55	
		Pdh (declared heating cap)		kW	16.0	21.7	23.2	27.9	31.0
		Tol (temperature operating limit)		°C					
A Condition (-7°C)		COPd (declared COP)		3.00	3.03	3.18	2.87	2.95	
		Pdh (declared heating cap)		kW	14.2	19.2	20.5	24.7	27.4
B Condition (2°C)		COPd (declared COP)		4.37	4.02	4.17	4.20	4.09	
		Pdh (declared heating cap)		kW	8.60	11.7	12.5	15.0	16.7
C Condition (7°C)		COPd (declared COP)		4.70	5.11	5.45	5.60	5.90	
		Pdh (declared heating cap)		kW	7.17	8.40	8.05	9.66	10.7
D Condition (12°C)		COPd (declared COP)		5.57	6.47	6.93	7.49	8.06	
		Pdh (declared heating cap)		kW	8.74	8.93	9.04	9.97	10.0
Space heating (Average climate) recommended combination 2	A Condition (-7°C)	COPd (declared COP)		3.02	3.05	3.18	2.86	2.96	
		Pdh (declared heating cap)		kW	14.2	19.2	20.5	24.7	27.4
	B Condition (2°C)	COPd (declared COP)		4.42	4.12	4.18	4.27	4.21	
		Pdh (declared heating cap)		kW	8.64	11.7	12.5	15.0	16.7
	C Condition (7°C)	COPd (declared COP)		4.76	5.24	5.57	5.78	6.07	
		Pdh (declared heating cap)		kW	7.31	8.54	8.08	9.65	10.7
	D Condition (12°C)	COPd (declared COP)		5.62	6.58	6.97	7.59	8.30	
		Pdh (declared heating cap)		kW	8.87	9.17	9.24	10.3	10.5
	TBivalent	COPd (declared COP)		2.70	2.75	2.87	2.27	2.34	
		Pdh (declared heating cap)		kW	16.0	21.7	23.2	27.9	31.0
		Tbiv (bivalent temperature)		°C					
		TOL		°C					
		COPd (declared COP)		2.70	2.75	2.87	2.27	2.34	
		Pdh (declared heating cap)		kW	16.0	21.7	23.2	27.9	31.0
		Tol (temperature operating limit)		°C					
Capacity range		HP	10	13	16	18	20		
PED	Category	Category III							
Maximum number of connectable indoor units	64 (3)								
Indoor index connection	Min.			125	163	200	225	250	
	Max.			325	423	520	585	650	
Heat exchanger	Indoor side		Air						
	Outdoor side		Air						
	Air flow rate	Cooling	Rated	m <sup>3</sup> /h		18,290 (11)		18,854 (11)	19,968 (11)
		Heating	Rated	m <sup>3</sup> /h		18,290 (11)		18,854 (11)	19,968 (11)
Sound power level	Cooling	Nom.	dBA		81.3 (4)		81.6 (4)	83.9 (4)	
	Heating	Nom.	dBA		82.4 (4)		83.1 (4)	84.8 (4)	
Sound pressure level	Cooling	Nom.	dBA		59.3 (5)		60.2 (5)	62.1 (5)	
	Heating	Nom.	dBA		61.1 (5)		61.5 (5)	63.4 (5)	
Refrigerant	Type	R-32							
	GWP	675.0							
Refrigerant oil	Type	FW68DE							
Piping connections	Liquid	Type	Braze connection						
		OD	mm	9.50					
	Gas	Type	Braze connection						
		OD	mm	19.1	22.2				
	Equalizing	Type	Braze connection						
		OD	mm	19.1					
Total piping length	System	Actual	m		500 (6)				
Defrost method	Reversed cycle								
Capacity control	Method								
Indication if the heater is equipped with a supplementary heater						Inverter controlled			
						No			
Supplementary heater	Back-up capacity	Heating	elbu		kW				
					0.0				

## 2 Specifications

### 2 - 1 Specifications

2

Technical specifications System					RXYA10A	RXYA13A	RXYA16A	RXYA18A	RXYA20A
Power consumption in other than active mode	Crankcase heater mode	Cooling	PCK	kW	0.000				
		Heating	PCK	kW	0.106				
	Off mode	Cooling	POFF	kW	0.100				
		Heating	POFF	kW	0.106				
	Standby mode	Cooling	PSB	kW	0.100				
		Heating	PSB	kW	0.106				
	Thermo-stat-off mode	Cooling	PTO	kW	0.002				
		Heating	PTO	kW	0.106				
Cooling	Cdc (Degradation cooling)				0.25				
Heating	Cdh (Degradation heating)				0.25				

Electrical specifications System					RXYA10A	RXYA13A	RXYA16A	RXYA18A	RXYA20A
Power supply	Name				Y1				
	Phase				3N~				
	Frequency				50				
	Voltage				380-415				
Power supply intake					Both indoor and outdoor unit				
Voltage range	Min.				%				
	Max.				%				
Current - 50Hz	Nominal running current (RLA)	Combina-tion A	Cooling		-				
			Combina-tion B	Cooling		-			
	Cooling			A	11.2 (7)	16.1 (7)	21 (7)	23.9 (7)	26.2 (7)
	Starting current (MSC) - remark				See note 9				
Zmax List				No requirements					
Minimum Ssc value				kVa	5,196 (8)	5,387 (8)	5,577 (8)	6,599 (8)	6,945 (8)
Minimum circuit amps (MCA)				A	30.0 (9)	31.1 (9)	32.2 (9)	38.1 (9)	40.1 (9)
Maximum fuse amps (MFA)				A	40 (10)			50 (10)	
Power Performance	Power factor	Combina-tion B	35°C ISO - Full load		-				
			46°C ISO - Full load		-				
Wiring connections - 50Hz	For power supply		Quantity		5G				
	For connection with indoor		Quantity		2				
	Remark		Remark		F1,F2				

Technical specifications Module					RYMA5A				
Cooling capacity	Prated,c		kW		14.0 (1)				
Heating capacity	Max.		6°CWB		kW				
Capacity range					HP				
PED	Category				Category III				
	Most critical part	Name		Ps*V		Bar*l		Liquid receiver	
Maximum number of connectable indoor units				508					
Indoor index connection	Min.				64 (3)				
	Max.				63				
Dimensions	Unit	Height		mm		1,685			
		Width		mm		930			
		Depth		mm		765			
	Packed unit	Height		mm		1,820			
		Width		mm		995			
		Depth		mm		860			
Weight	Unit		kg		214				
	Packed unit		kg		225				
Packing	Material				Carton				
	Weight				kg				
Packing 2	Material				Wood				
	Weight				kg				
Packing 3	Material				Plastic				
	Weight				kg				
Casing	Colour				Daikin White				
	Material				Painted galvanized steel plate				
Heat exchanger	Type				Cross fin coil				
	Indoor side				Air				
	Outdoor side				Air				
	Air flow rate	Cooling	Rated	m <sup>3</sup> /h		9,145			
		Heating	Rated	m <sup>3</sup> /h		9,145			

## 2 Specifications

### 2 - 1 Specifications

Technical specifications Module				RYMA5A
Fan	Quantity			1
	External static pressure	Max.	Pa	78
Fan motor	Quantity			1
	Type			DC motor
	Output		W	550
Compressor	Quantity			1
Compressor	Type			Hermetically sealed scroll compressor
Operation range	Cooling	Min.	°CDB	-5
		Max.	°CDB	46
	Heating	Min.	°CWB	-20
		Max.	°CWB	16
Sound power level	Cooling	Nom.	dBA	78.3 (4)
	Heating	Nom.	dBA	79.4 (4)
Sound pressure level	Cooling	Nom.	dBA	56.3 (5)
	Heating		dBA	58.1 (5)
Refrigerant	Type			R-32
	GWP			675.0
	Charge		kg	9.00
	Charge		tCO <sub>2</sub> Eq	6.08
Refrigerant oil	Type			FW68DE
Piping connections	Liquid	Type		Braze connection
		OD	mm	9.52
	Gas	Type		Braze connection
		OD	mm	19.1
Defrost method				Reversed cycle
Capacity control	Method			Inverter controlled

Electrical specifications Module				RYMA5A	
Power supply	Name			Y1	
	Phase			3N~	
	Frequency		Hz	50	
	Voltage		V	380-415	
Power supply intake				Both indoor and outdoor unit	
Voltage range	Min.		%	-10	
	Max.		%	10	
Current -50Hz	Nominal running current (RLA)	Combina-tion A	Cooling	-	
			Cooling	-	
		Combina-tion B	Cooling	-	
	Starting current (MSC) - remark		A		5.6 (6)
	Z <sub>max</sub>	List			See note 9
	Minimum Ssc value		kVa		No requirements
	Minimum circuit amps (MCA)		A		2,598 (7)
Maximum fuse amps (MFA)		A		15.0 (8)	
Power Performance	Power factor	Combina-tion B	35°C ISO - Full load	-	
			46°C ISO - Full load	-	
Wiring connections -50Hz	For power supply	Quantity		5G	
	For connection with indoor	Quantity		2	
		Remark			F1,F2
Compressor	Crankcase heater		W	33	

(1)Cooling: indoor temp. 27°CDB, 19°CWB; outdoor temp. 35°CDB; equivalent piping length: 7.5m; level difference: 0m |

(2)Heating: indoor temp. 20°CDB; outdoor temp. 7°CDB, 6°CWB; equivalent refrigerant piping: 7.5m; level difference: 0m |

(3)The actual number of units depends on the connection ratio (CR) and the restrictions for the system. |

(4)Sound power level is an absolute value that a sound source generates. |

(5)Sound pressure level is a relative value, depending on the distance and acoustic environment. For more details, please refer to the sound level drawings. |

(6)RLA is based on following conditions: indoor temp. 27°CDB, 19°CWB; outdoor temp. 35°CDB |

(7)In accordance with EN/IEC 61000-3-12, it may be necessary to consult the distribution network operator to ensure that the equipment is connected only to a supply with Ssc ≥ minimum Ssc value |

(8)MCA must be used to select the correct field wiring size. The MCA can be regarded as the maximum running current. |

(9)MFA is used to select the circuit breaker and the ground fault circuit interrupter (earth leakage circuit breaker). |

Air Flow Rate (AFR) of multi outdoor systems is sum of AFR of the individual systems it consists of |

Refer to refrigerant pipe selection or installation manual |

MSC means the maximum current during start up of the compressor. This unit uses only inverter compressors. Starting current is always ≤ max. running current. |

Maximum allowable voltage range variation between phases is 2%. |

Voltage range: units are suitable for use on electrical systems where voltage supplied to unit terminal is not below or above listed range limits. |

Sound values are measured in a semi-anechoic room. |

EN/IEC 61000-3-12: European/international technical standard setting the limits for harmonic currents produced by equipment connected to public low-voltage system with input current > 16A and ≤ 75A per phase |

Ssc: Short-circuit power |

For detailed contents of standard accessories, see installation/operation manual |

Multi combination (10~20HP) data is corresponding with the standard multi combination

# 3 Options

## 3 - 1 Options

3

RXYA-A  
RYMA-A

VRV5	R32 models
Heat Pump	
Option list	

Nr.	Description	Option	RXYA*A*								RYMA*A*	Multi -2- unit
			8	10	12	14	16	18	20	5		
1	Bottom Plate heater	EKBPH0127A	0	0	0	-	-	-	-	0	0 (*1)	
	Bottom Plate heater	EKBPH020TA	-	-	-	0	0	0	0	-	-	
2	Demand adaptor kit	DTA104A61/62* (*2)	0	0	0	0 (*3)	0 (*3)	0 (*3)	0 (*3)	0	0	
3	External control adapter	DTA109A51 (*2)	0	0	0	0 (*3)	0 (*3)	0 (*3)	0 (*3)	0	0	
4	Demand PCB Mounting Plate	EKS26B2	-	-	-	0	0	0	0	-	-	
5	Cool/heat selector (switch)	KRC19-26	0 (*4)	0 (*4)	0 (*4)	0 (*4)	0 (*4)	0 (*4)	0 (*4)	0 (*4)	0 (*4) (*5)	
6	Cool/heat selector (PCB)	EKBRP2A81	0	0	0	0	0	0	0	0	0 (*5)	
7	Cool/heat selector (fixing box)	KJB111A	0	0	0	0	0	0	0	0	0 (*5)	
8a	Refnet header	KHRQ22M29H (*6)	0	0	0	0	0	0	0	0	0	
		KHRA22M65H	-	-	0	0	0	0	0	0	0	
	Refnet joint	KHRQ22M20TA (*6)	0	0	0	0	0	0	0	0	0	
		KHRQ22M29T9	0	0	0	0	0	0	0	0	0	
8b	Refnet header	KHRQM22M29H9 (*6)	0	0	0	0	0	0	0	0	0	
		KHRAM22M65H	-	-	0	0	0	0	0	0	0	
	Refnet joint	KHRQM22M20T (*6)	0	0	0	0	0	0	0	0	0	
		KHRQM22M29T	0	0	0	0	0	0	0	0	0	
9a	Refrigerant branch kit	BHFA22P1007 (*7)	-	-	-	-	-	-	-	-	0	
		BHFAM22P1007	-	-	-	-	-	-	-	-	0	
10	SV- units	SV1A25A	0	0	0	0	0	0	0	0	0	
		SV4A14A	0	0	0	0	0	0	0	0	0	
		SV6A14A	0	0	0	0	0	0	0	0	0	
		SV8A14A	0	0	0	0	0	0	0	0	0	

4D149888A

RXYA-A  
RYMA-A

- \*1 -1- option kits are required per unit.
- \*2 Because both adaptor PCBs have the same installation location, it is only possible to install either -DTA104A61/62\* or -DTA109A51-.
- \*3 These options require mounting plate -EKS26B2-.
- \*4 To mount option -KRC19-26-, option -KJB111A- is required.
- \*5 Connection only to the master unit
- \*6 -8a- is branch piping for imperial pipe sizes, -8b- for metric pipe sizes.
- \*7 -9a- is branch piping for imperial pipe sizes, -9b- for metric pipe sizes.

Remote controllers and centralised controllers with R32 safety system functionality

Nr.	Item	Sound pressure level of built-in alarm	Mode			
			Fully functional	Alarm only	Supervisor	
			Built-in alarm	Built-in alarm	Built-in alarm	External alarm connection
1	BRC1H52/82*	-65- dBA at ·1- m	0	0	0	-
2	DCM601A51 (*8)	NA	-	-	-	0 (*10)
3	DCM601B51 (*9)	-65- dBA at ·1- m	-	-	0	0 (*10)

- \*8 From software version ·1.28.00- onwards.
- \*9 From software version ·1.32.00- onwards.
- \*10 via WAGO module

4D149888A

# 4 Combination table

## 4 - 1 Combination Table

**RXYA-A**  
**RYMA5A**

**VRV5**  
**Heat pump**  
**Multi-unit standard combinations table**

		5HP	8HP	10HP	12HP	14HP	16HP	18HP	20HP
Non-continuous heating	RYMA5* (*1)	1							
	RXYA8*		1						
	RXYA10*			1					
	RXYA12*				1				
	RXYA14*					1			
	RXYA16*						1		
	RXYA18*							1	
Continuous heating ·2· outdoor units	RXYA10*	2							
	RXYA13*	1	1						
	RXYA16*		2						
	RXYA18*		1	1					
	RXYA20*		1		1				1

Notes

1. The ·RYMA5\*· unit cannot be used as a standalone unit and may only be used in standard combinations.
2. Never combine more than ·2· units to create a multi-combination.
3. The total capacity of the system must never exceed ·20 HP·.

**4D149887**

**RXYA-A**  
**RYMA-A**

**Unit combination restrictions: ·VRV5· outdoor units (all models) + ·10 / 15·-class indoor units**

Indoor unit in the system	
FXDA10A	FXZA15A and/or FXAA15A
Yes	Yes

1. In case the system contains the indoor unit situation as shown in the table above, and the total connection ratio (·CR·) ≤ ·85·%: no special restrictions.  
Follow the restrictions that apply to regular ·VRV DX· indoor units.
2. In case the system contains the indoor unit situation as shown in the table above, and the total connection ratio (·CR·) > ·85·%: special restrictions apply.
  - A. When the connection ratio (·CR1·) of the sum of all ·FXDA10A· units in the system ≤ ·65·%, and ALL other ·VRV DX· indoor units have an individual capacity class > ·50·: no special restrictions.
  - B. When the connection ratio (·CR1·) of the sum of all ·FXDA10A· units in the system ≤ ·65·%, and NOT ALL other ·VRV DX· indoor units have an individual capacity class > ·50·: the restrictions below apply.
    - ° 85% < CR ≤ 95% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·65·%.
    - ° 95% < CR ≤ 100% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·55·%.
    - ° 100% < CR ≤ 105% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·40·%.
    - ° 105% < CR ≤ 130% -> ·FXDA10A· cannot be used

Remark

Only the ·10 / 15·-class indoor units explicitly mentioned on this page are in scope. Other indoor units follow the rules that apply to regular ·VRV DX· indoor units.

**4D141206A**

# 4 Combination table

## 4 - 1 Combination Table

4

RXYA-A  
RYMA-A

### Unit combination restrictions: ·VRV5· outdoor units (all models) + ·10 / 15·-class indoor units

Indoor unit in the system	
FXDA10A	FXZA15A and/or FXAA15A
Yes	No

1. In case the system contains the indoor unit situation as shown in the table above, and the total connection ratio (-CR-) ≤ ·85·%: no special restrictions. Follow the restrictions that apply to regular ·VRV DX· indoor units.
2. In case the system contains the indoor unit situation as shown in the table above, and the total connection ratio (-CR-) > ·85·%: special restrictions apply.
  - A. When the connection ratio (-CR1-) of the sum of all ·FXDA10A· units in the system ≤ ·65·%, and ALL other ·VRV DX· indoor units have an individual capacity class > ·50·: no special restrictions.
  - B. When the connection ratio (-CR1-) of the sum of all ·FXDA10A· units in the system ≤ ·65·%, and NOT ALL other ·VRV DX· indoor units have an individual capacity class > ·50·: the restrictions below apply.
    - ° 85% < CR ≤ 95% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·65·%.
    - ° 95% < CR ≤ 100% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·55·%.
    - ° 100% < CR ≤ 105% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·40·%.
    - ° 105% < CR ≤ 110% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·30·%.
    - ° 110% < CR ≤ 115% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·20·%.
    - ° 115% < CR ≤ 120% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·10·%.
    - ° 120% < CR ≤ 125% -> ·CR1· of the sum of all ·FXDA10A· indoor units in the system must be ≤ ·5·%.
    - ° 125% < CR ≤ 130% -> ·FXDA10A· cannot be used

Remark  
Only the ·10 / 15·-class indoor units explicitly mentioned on this page are in scope. Other indoor units follow the rules that apply to regular ·VRV DX· indoor units.

4D141206A

RXYA-A  
RYMA-A

### Unit combination restrictions: ·VRV5· outdoor units (all models) + ·10 / 15·-class indoor units

Indoor unit in the system	
FXDA10A	FXZA15A and/or FXAA15A
No	Yes

1. In case the system contains the indoor units situation which as shown in the table above, and the total connection ratio (-CR-) ≤ ·100·%: no special restrictions. Follow the restrictions that apply to regular ·VRV DX· indoor units.
2. In case the system contains the indoor units situation which as shown in the table above, and the total connection ratio (-CR-) > ·100·%: special restrictions apply.
  - A. When the connection ratio (-CR1-) of the sum of all ·FXZA15A· and/or ·FXAA15A· units in the system ≤ ·70·%, and ALL other ·VRV DX· indoor units have an individual capacity class > ·50·: no special restrictions.
  - B. When the connection ratio (-CR1-) of the sum of all ·FXZA15A· and/or ·FXAA15A· units in the system ≤ ·70·%, and NOT ALL other ·VRV DX· indoor units have an individual capacity class > ·50·: the restrictions below apply.
    - ° 100% < CR ≤ 105% -> ·CR1· of the sum of all ·FXZA15A· and/or ·FXAA15A· indoor units in the system must be ≤ ·70·%.
    - ° 105% < CR ≤ 110% -> ·CR1· of the sum of all ·FXZA15A· and/or ·FXAA15A· indoor units in the system must be ≤ ·60·%.
    - ° 110% < CR ≤ 115% -> ·CR1· of the sum of all ·FXZA15A· and/or ·FXAA15A· indoor units in the system must be ≤ ·40·%.
    - ° 115% < CR ≤ 120% -> ·CR1· of the sum of all ·FXZA15A· and/or ·FXAA15A· indoor units in the system must be ≤ ·25·%.
    - ° 120% < CR ≤ 125% -> ·CR1· of the sum of all ·FXZA15A· and/or ·FXAA15A· indoor units in the system must be ≤ ·10·%.
    - ° 125% < CR ≤ 130% -> ·FXZA15A· and ·FXAA15A· cannot be used.

Remark  
Only the ·10 / 15·-class indoor units explicitly mentioned on this page are in scope. Other indoor units follow the rules that apply to regular ·VRV DX· indoor units.

4D141206A

## 5 Capacity tables

### 5 - 1 Capacity Table Legend

In order to fulfill more your requirements on quick access of data in the format you require, we have developed a tool to consult capacity tables.

Below you can find the link to the capacity table database and an overview of all the tools we have to help you select the correct product:

- **Capacity table database:** lets you find back and export quickly the capacity information you are looking for based upon unit model, refrigerant temperature and connection ratio.
- You can access the capacity table viewer here:  
[https://my.daikin.eu/content/denv/en\\_US/home/applications/software-finder/capacity-table-viewer.html](https://my.daikin.eu/content/denv/en_US/home/applications/software-finder/capacity-table-viewer.html)



- An overview of **all software tools** that we offer can be found here:  
[https://my.daikin.eu/denv/en\\_US/home/applications/software-finder.html](https://my.daikin.eu/denv/en_US/home/applications/software-finder.html)



# 5 Capacity tables

## 5 - 2 Integrated Heating Capacity Correction Factor

5

RXYA-A  
RYMA5A

VRV5

Heat pump

Integrated heating capacity coefficient

Inlet air temperature of heat exchanger

[°CDB/°CWB] -7/-7.6 -5/-5.6 -3/-3.7 0/-0.7 3/2.2 5/4.1 7/6  
Integrated correction factor for frost accumulation (C)

	-7/-7.6	-5/-5.6	-3/-3.7	0/-0.7	3/2.2	5/4.1	7/6
8HP	0,90	0,88	0,83	0,80	0,81	0,85	1,00
10HP	0,90	0,88	0,82	0,75	0,76	0,83	1,00
12HP	0,90	0,87	0,82	0,71	0,72	0,81	1,00
14HP	0,90	0,87	0,81	0,68	0,69	0,80	1,00
16HP	0,90	0,87	0,81	0,68	0,68	0,79	1,00
18HP	0,90	0,88	0,83	0,80	0,81	0,85	1,00
20HP	0,90	0,88	0,83	0,80	0,81	0,85	1,00
10HP	0,90	0,88	0,83	0,80	0,81	0,85	1,00
13HP	0,90	0,88	0,83	0,80	0,81	0,85	1,00
16HP	0,90	0,88	0,83	0,80	0,81	0,85	1,00
18HP	0,90	0,88	0,83	0,77	0,78	0,84	1,00
20HP	0,90	0,88	0,83	0,75	0,76	0,83	1,00

For single unit installation

For multi-unit installation

The heating capacity tables do not take into account the capacity reduction in case of frost accumulation or defrost operation.

The capacity values that take these factors into account, or in other words, the integrated heating capacity values, can be calculated as follows:


Formula

$$A = B * C$$

A= Integrated heating capacity

B= Capacity characteristics value

C= Integrated correction factor for frost accumulation (see table)



Notes

1. The figure shows the integrated heating capacity for a single cycle (from one defrost operation to the next).
2. When there is an accumulation of snow against the outdoor unit heat exchanger, there will always be a temporary reduction in capacity depending on the outdoor temperature (°C DB), relative humidity (RH) and the amount of frosting which occurs.
3. The multi-combination data -VRV5- corresponds with the standard multi-combination of drawing -4D149887-.

4D149885

# 5 Capacity tables

## 5 - 3 Capacity Correction Factor

**RXYA8A**

**Correction ratio for cooling capacity**

**Correction ratio for heating capacity**

**Legend**

Hp: Maximum level difference (m) between outdoor and indoor units when the outdoor unit is positioned higher than the indoor units.

Hm: Maximum level difference (m) between outdoor and indoor units when the outdoor unit is positioned lower than the indoor units.

L: Equivalent piping length [m]

**Notes**

- These figures illustrate the capacity correction factor due to the piping length for a standard indoor unit system at maximum load (with the thermostat set to maximum), under standard conditions. Moreover, under partial load conditions, there is only a minor deviation for the capacity correction ratio, as shown in the above figures.
- Method of calculating the capacity of the outdoor units.**  
The maximum capacity of the system will be either the total capacity of the indoor units or the maximum capacity of the outdoor units as mentioned below, whichever is less.
 

**Indoor connection ratio ≤ 100%.**  
 $\text{Maximum capacity of outdoor units} = \text{Capacity of outdoor units from capacity table at 100\% connection ratio} \times \text{Correction ratio of piping to furthest indoor unit}$

**Indoor connection ratio > 100%.**  
 $\text{Maximum capacity of outdoor units} = \text{Capacity of outdoor units from capacity table at installed connection ratio} \times \text{Correction ratio of piping to furthest indoor unit}$
- If the equivalent piping length is >90- m, size up the main liquid and gas piping.
 

Model	Standard liquid side Ø	Increased liquid side Ø	Standard gas side Ø	Increased gas side Ø
8HP	9,5	12,7	19,1	22,2
- Overall equivalent length**  
 $\text{Overall equivalent length} = \text{Equivalent length of the main pipe} \times \text{Correction factor} + \text{Equivalent length of the branch pipes}$   
 Choose the correction factor from the following table.
 

Model	Correction ratio for cooling capacity		Correction ratio for heating capacity	
	Standard size	Size increase	Standard size	Size increase
8HP	1	0,5	1	0,2
- Example -8HP:**  

**Overall equivalent length**

  - Cooling mode = 80 m x 0,5 + 40 m = 80 m
  - Heating mode = 80 m x 0,2 + 40 m = 56 m

**Capacity correction ratio (height difference = 0)**

  - Cooling mode = 0,86
  - Heating mode = 1,00

**4D150023**

**RXYA10A**

**Correction ratio for cooling capacity**

**Correction ratio for heating capacity**

**Legend**

Hp: Maximum level difference (m) between outdoor and indoor units when the outdoor unit is positioned higher than the indoor units.

Hm: Maximum level difference (m) between outdoor and indoor units when the outdoor unit is positioned lower than the indoor units.

L: Equivalent piping length [m]

**Notes**

- These figures illustrate the capacity correction factor due to the piping length for a standard indoor unit system at maximum load (with the thermostat set to maximum), under standard conditions. Moreover, under partial load conditions, there is only a minor deviation for the capacity correction ratio, as shown in the above figures.
- Method of calculating the capacity of the outdoor units.**  
The maximum capacity of the system will be either the total capacity of the indoor units or the maximum capacity of the outdoor units as mentioned below, whichever is less.
 

**Indoor connection ratio ≤ 100%.**  
 $\text{Maximum capacity of outdoor units} = \text{Capacity of outdoor units from capacity table at 100\% connection ratio} \times \text{Correction ratio of piping to furthest indoor unit}$

**Indoor connection ratio > 100%.**  
 $\text{Maximum capacity of outdoor units} = \text{Capacity of outdoor units from capacity table at installed connection ratio} \times \text{Correction ratio of piping to furthest indoor unit}$
- If the equivalent piping length is >90- m, size up the main liquid and gas piping.
 

Model	Standard liquid side Ø	Increased liquid side Ø	Standard gas side Ø	Increased gas side Ø
10HP	9,5	12,7	19,1	22,2
- Overall equivalent length**  
 $\text{Overall equivalent length} = \text{Equivalent length of the main pipe} \times \text{Correction factor} + \text{Equivalent length of the branch pipes}$   
 Choose the correction factor from the following table.
 

Model	Correction ratio for cooling capacity		Correction ratio for heating capacity	
	Standard size	Size increase	Standard size	Size increase
10HP	1	0,5	1	0,2
- Example -10HP:**  

**Overall equivalent length**

  - Cooling mode = 80 m x 0,5 + 40 m = 80 m
  - Heating mode = 80 m x 0,2 + 40 m = 56 m

**Capacity correction ratio (height difference = 0)**

  - Cooling mode = 0,87
  - Heating mode = 1,00


**4D150023**

# 5 Capacity tables

## 5 - 3 Capacity Correction Factor

5

RXYA12A



Notes

1. These figures illustrate the capacity correction factor due to the piping length for a standard indoor unit system at maximum load (with the thermostat set to maximum), under standard conditions. Moreover, under partial load conditions, there is only a minor deviation for the capacity correction ratio, as shown in the above figures.

2. Method of calculating the capacity of the outdoor units.

The maximum capacity of the system will be either the total capacity of the indoor units or the maximum capacity of the outdoor units as mentioned below, whichever is less.

Indoor connection ratio ≤ 100%.

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at 100% connection ratio. × Correction ratio of piping to furthest indoor unit

Indoor connection ratio > 100%.

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at installed connection ratio. × Correction ratio of piping to furthest indoor unit

3. If the equivalent piping length is >90- m, size up the main liquid and gas piping.

Model	Standard liquid side Ø	Increased liquid side Ø	Standard gas side Ø	Increased gas side Ø
12HP	12,7	15,9	22,2	28,6


4. Overall equivalent length

Overall equivalent length = Equivalent length of the main pipe × Correction factor + Equivalent length of the branch pipes

Choose the correction factor from the following table.

Model	Correction ratio for cooling capacity		Correction ratio for heating capacity	
	Standard size	Size increase	Standard size	Size increase
12HP	1	0,5	1	0,3

5. Example -12HP:



Overall equivalent length

- Cooling mode = 80 m × 0,5 + 40 m = 80 m
- Heating mode = 80 m × 0,3 + 40 m = 64 m


Capacity correction ratio (height difference = 0)

- Cooling mode = 0,92
- Heating mode = 1,00

4D150023

RXYA13A

RXYA14A



Notes

1. These figures illustrate the capacity correction factor due to the piping length for a standard indoor unit system at maximum load (with the thermostat set to maximum), under standard conditions. Moreover, under partial load conditions, there is only a minor deviation for the capacity correction ratio, as shown in the above figures.

2. Method of calculating the capacity of the outdoor units.

The maximum capacity of the system will be either the total capacity of the indoor units or the maximum capacity of the outdoor units as mentioned below, whichever is less.

Indoor connection ratio ≤ 100%.

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at 100% connection ratio. × Correction ratio of piping to furthest indoor unit

Indoor connection ratio > 100%.

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at installed connection ratio. × Correction ratio of piping to furthest indoor unit

3. If the equivalent piping length is >90- m, size up the main liquid and gas piping.

Model	Standard liquid side Ø	Increased liquid side Ø	Standard gas side Ø	Increased gas side Ø
13+14HP	12,7	15,9	22,2	28,6


4. Overall equivalent length

Overall equivalent length = Equivalent length of the main pipe × Correction factor + Equivalent length of the branch pipes

Choose the correction factor from the following table.

Model	Correction ratio for cooling capacity		Correction ratio for heating capacity	
	Standard size	Size increase	Standard size	Size increase
13+14HP	1	0,5	1	0,3

5. Example -14HP:



Overall equivalent length

- Cooling mode = 80 m × 0,5 + 40 m = 80 m
- Heating mode = 80 m × 0,3 + 40 m = 64 m

Capacity correction ratio (height difference = 0)


- Cooling mode = 0,91
- Heating mode = 1,00

4D150023

# 5 Capacity tables

## 5 - 3 Capacity Correction Factor

### RXYA16A



**Notes**

- These figures illustrate the capacity correction factor due to the piping length for a standard indoor unit system at maximum load (with the thermostat set to maximum), under standard conditions. Moreover, under partial load conditions, there is only a minor deviation for the capacity correction ratio, as shown in the above figures.
- Method of calculating the capacity of the outdoor units.**  
The maximum capacity of the system will be either the total capacity of the indoor units or the maximum capacity of the outdoor units as mentioned below, whichever is less.

**Indoor connection ratio ≤ 100%.**

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at 100% connection ratio. X Correction ratio of piping to furthest indoor unit

**Indoor connection ratio > 100%.**

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at installed connection ratio. X Correction ratio of piping to furthest indoor unit

- If the equivalent piping is > 90-m, size up the main liquid piping.

Model	Standard liquid side Ø	Increased liquid side Ø	Standard gas side Ø	Increased gas side Ø
16HP	12,7	15,9	28,6	-


- Overall equivalent length

Overall equivalent length = Equivalent length of the main pipe X Correction factor + Equivalent length of the branch pipes

Choose the correction factor from the following table.

Model	Correction ratio for cooling capacity		Correction ratio for heating capacity	
	Standard size	Size increase	Standard size	Size increase
16HP	1	-	1	0,3

- Example -16HP-



**Overall equivalent length**


- Cooling mode = 80 m x 1 + 40 m = 120 m
- Heating mode = 80 m x 0,3 + 40 m = 64 m

**Capacity correction ratio (height difference = 0)**

- Cooling mode = 0,83
- Heating mode = 1,00

4D150023

### RXYA18A



**Notes**

- These figures illustrate the capacity correction factor due to the piping length for a standard indoor unit system at maximum load (with the thermostat set to maximum), under standard conditions. Moreover, under partial load conditions, there is only a minor deviation for the capacity correction ratio, as shown in the above figures.
- Method of calculating the capacity of the outdoor units.**  
The maximum capacity of the system will be either the total capacity of the indoor units or the maximum capacity of the outdoor units as mentioned below, whichever is less.

**Indoor connection ratio ≤ 100%.**

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at 100% connection ratio. X Correction ratio of piping to furthest indoor unit

**Indoor connection ratio > 100%.**

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at installed connection ratio. X Correction ratio of piping to furthest indoor unit

- If the equivalent piping is > 90-m, size up the main liquid piping.

Model	Standard liquid side Ø	Increased liquid side Ø	Standard gas side Ø	Increased gas side Ø
18HP	12,7	15,9	28,6	-


- Overall equivalent length

Overall equivalent length = Equivalent length of the main pipe X Correction factor + Equivalent length of the branch pipes

Choose the correction factor from the following table.

Model	Correction ratio for cooling capacity		Correction ratio for heating capacity	
	Standard size	Size increase	Standard size	Size increase
18HP	1	-	1	0,3

- Example -18HP-



**Overall equivalent length**

- Cooling mode = 80 m x 1 + 40 m = 120 m
- Heating mode = 80 m x 0,3 + 40 m = 64 m

**Capacity correction ratio (height difference = 0)**

- Cooling mode = 0,81
- Heating mode = 1,00


4D150023

# 5 Capacity tables

## 5 - 3 Capacity Correction Factor

5

RXYA20A



**Notes**

1. These figures illustrate the capacity correction factor due to the piping length for a standard indoor unit system at maximum load (with the thermostat set to maximum), under standard conditions. Moreover, under partial load conditions, there is only a minor deviation for the capacity correction ratio, as shown in the above figures.

**2. Method of calculating the capacity of the outdoor units.**

The maximum capacity of the system will be either the total capacity of the indoor units or the maximum capacity of the outdoor units as mentioned below, whichever is less.

**Indoor connection ratio ≤ 100%.**

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at 100% connection ratio. X Correction ratio of piping to furthest indoor unit

**Indoor connection ratio > 100%.**

Maximum capacity of outdoor units = Capacity of outdoor units from capacity table at installed connection ratio. X Correction ratio of piping to furthest indoor unit

3. If the equivalent piping is > 90-m, size up the main liquid piping.

Model	Standard liquid side Ø	Increased liquid side Ø	Standard gas side Ø	Increased gas side Ø
20HP	12,7	15,9	28,6	-


**4. Overall equivalent length**

Overall equivalent length = Equivalent length of the main pipe X Correction factor + Equivalent length of the branch pipes

Choose the correction factor from the following table.

Model	Correction ratio for cooling capacity		Correction ratio for heating capacity	
	Standard size	Size increase	Standard size	Size increase
20HP	1	-	1	0,3

**5. Example -20HP:**



**Overall equivalent length**

- Cooling mode = 80 m x 1 + 40 m = 120 m
- Heating mode = 80 m x 0,3 + 40 m = 64 m

**Capacity correction ratio (height difference = 0)**


- Cooling mode = 0,80
- Heating mode = 1,00

4D150023

# 6 Dimensional drawings

## 6 - 1 Dimensional Drawings

RXYA8-12A  
RYMA-A




- Notes**
- Detail A and detail B indicate the dimensions after fixing the attached piping.
  - Items 4 - 10: Knockout hole.
  - Gas pipe**  
RYMA5A, RXYA8-10A : Ø 19.1 brazing connection  
RXYA12A : Ø 22.2 brazing connection
  - Liquid pipe**  
RYMA5A, RXYA8-10A : Ø 9.5 brazing connection  
RXYA12A : Ø 12.7 brazing connection
  - Equalizing pipe**  
RYMA5A, RXYA8-12A : Ø 19.1 brazing connection

No.	Part name	Remark
1	Liquid pipe connection port	See note 3.
2	Equalizing pipe connection port	See note 3.
3	Gas pipe connection port	See note 3.
4	Power cord routing hole (side)	∅65
5	Power cord routing hole (front)	∅80
6	Power cord routing hole (front)	∅65
7	Power cord routing hole (front)	∅27
8	Power cord routing hole (bottom)	∅65
9	Pipe routing hole (front)	
10	Pipe routing hole (bottom)	
11	Grounding terminal	Inside of the switch box (MB)

2D152667

RXYA14-20A



- Notes**
- Detail A and detail B indicate the dimensions after fixing the attached piping.
  - Items 4 - 10: Knockout hole.
  - Gas pipe**  
RXYA14A : Ø 22.2 brazing connection  
RXYA16-20A : Ø 28.6 brazing connection
  - Liquid pipe**  
RXYA14-20A : Ø 12.7 brazing connection

No.	Part name	Remark
1	Liquid pipe connection port	See note 3.
2	Equalizing pipe connection port	Not required
3	Gas pipe connection port	See note 3.
4	Power cord routing hole (side)	∅65
5	Power cord routing hole (front)	∅80
6	Power cord routing hole (front)	∅65
7	Power cord routing hole (front)	∅27
8	Power cord routing hole (bottom)	∅65
9	Pipe routing hole (front)	
10	Pipe routing hole (bottom)	
11	Grounding terminal	Inside of the switch box (MB)


2D152666

# 7 Centre of gravity

## 7 - 1 Centre of Gravity


7

RXYA8-12A  
RYMA5-A



3D119703B

RXYA14-20A




3D119704B

# 8 Piping diagrams

## 8 - 1 Piping Diagrams


RXYA8-12A  
RYMA-A



- . Charge port / Service port
- . Stop valve
- . Filter
- . Check valve
- . Pressure relief valve
- . Thermistor
- . Solenoid valve
- . Heat sink (PCB)
- . Capillary tube
- . Expansion valve
- . 4-way valve
- . Propeller fan
- . High pressure switch
- . Low pressure sensor
- . High pressure sensor
- . Oil separator
- . Accumulator
- . Heat exchanger
- . Compressor
- . Plate heat exchanger
- . Distributor
- . Liquid receiver
- . Muffler

4D149875A

RXYA14-20A



- . Charge port / Service port
- . Stop valve
- . Filter
- . Check valve
- . Pressure relief valve
- . Thermistor
- . Solenoid valve
- . Heat sink (PCB)
- . Capillary tube
- . Expansion valve
- . 4-way valve
- . Propeller fan
- . High pressure switch
- . Low pressure sensor
- . High pressure sensor
- . Oil separator
- . Accumulator
- . Heat exchanger
- . Compressor
- . Double tube heat exchanger
- . Distributor
- . Liquid receiver

3D149874A

# 9 Wiring diagrams

## 9 - 1 Wiring Diagrams - Three Phase

9

### RYMA5A / RXYA8-12A

#### NOTES to go through before starting the unit


1. Symbols:
  - X1M : Main terminal
  - : Earth wiring
  - - - : Field wire
  - ▬▬▬ : Field cable
  - ⊕ : Screened conductor
  - ① : Several wiring possibilities
  - [ ] : Option
  - [ ] : Wiring depending on model
  - [ ] : Not mounted in switch box
  - [ ] : PCB
2. Refer to the installation or service manual on how to use BS1 ~ BS3 push buttons and DS1 ~ DS2 DIP switches.
3. Do not operate the unit by short-circuiting protection device(s) S\*PH.
4. Refer to the installation manual for indoor-outdoor transmission F1-F2 and outdoor-multi transmission Q1-Q2 wiring.
5. When using the central control system, connect outdoor-outdoor transmission F1-F2.
6. The capacity of the contact is 220~240V AC - 0.5A (Rush current needs 3A or less).
7. Use dry contact for micro-current (10mA or less, 15V DC).
8. When using the optional adapter, refer to the installation manual of the optional adapter.

#### LEGEND


Part n°	Description	Part n°	Description
A1P	Printed circuit board (main)	R13T	Thermistor (Receiver gas)
A2P	Printed circuit board (noise filter)	R15T	Thermistor (M1C body)
A3P	Printed circuit board (inverter)	R16T	Thermistor (Gas injection)
A4P	Printed circuit board (fan)	R21T	Thermistor (M1C discharge pipe)
BS* (A1P)	Push button switch	S1NPH	High pressure sensor
DS* (A1P)	Dipswitch	S1NPL	Low pressure sensor
E1HC	Crank case heater	S*PH	High pressure switch
E3H	* Bottom plate heater	SEG* (A1P)	7-segment display
F1U (A1P)	Fuse T 10 A 250 V	SFB	# Mechanical ventilation error input
F1U, F2U	Fuse T 1 A 250 V	T1A	Current sensor
F3U	# Field fuse	X*A	Connector
HAP (A1P)	Running LED (service monitor-green)	X*M	Terminal strip
K*R (A*P)	Relay on PCB	Y1E	Electronic exp. valve (Heat exch. upper)
L1R	Reactor	Y2E	Electronic exp. valve (Subc. heat exch.)
M1C	Motor (compressor)	Y3E	Electronic exp. valve (Heat exch. lower)
M1F	Motor (fan)	Y4E	Electronic exp. valve (Receiver gas)
Q1DI	# Earth leakage circuit breaker	Y5E	Electronic exp. valve (Inverter cooling)
R1T	Thermistor (Air)	Y2S	Solenoid valve (Liquid pipe)
R3T	Thermistor (Liquid main)	Y3S	Solenoid valve (HP/LP gas pipe)
R4T	Thermistor (Heat exch. liquid upper)	Y4S	Solenoid valve (Heat exchanger lower)
R5T	Thermistor (Heat exch. liquid lower)	Y5S	Solenoid valve (Heat exchanger upper)
R6T	Thermistor (Subcool heat exch. gas)	Y8S	Solenoid valve (Gas injection)
R7T	Thermistor (Subcool heat exch. liquid)	Y10S	Solenoid valve (Accu oil return)
R8T	Thermistor (Heat exch. gas upper)	Y11S	Solenoid valve (M1C oil return)
R9T	Thermistor (Heat exch. gas lower)	Y13S	# Error operation output (SVEO)
R10T	Thermistor (Suction)	Y14S	# Leak sensor output (SVS)
R11T	Thermistor (Heat exch. de-icer)	Z*C	Noise filter (ferrite core)
R12T	Thermistor (Suction compressor)		

\* : optional # : field supply

#### LAYOUT OF M1C, M1F



#### POSITION IN SWITCH BOX




#### TERMINAL OF M1C



4D148982

### RYMA5A RXYA8-12A



4D148982




# 10 External connection diagrams

## 10 - 1 External Connection Diagrams

10


**RXYA-A**  
**RYMA5A** VRV5 Heat pump  
External connection diagram



1. All wiring, components and materials to be procured on-site must comply with the applicable legislation.
  2. Use copper conductors only
  3. For more details, refer to the wiring diagram of the unit.
  4. Install a circuit breaker for safety.
  5. All field wiring and components must be provided by an authorised electrician.
  6. Unit has to be grounded in compliance with the applicable legislation.
  7. The wiring shown is a general points-of-connection guide and is not intended to include all details for a specific installation.
  8. Make sure to install the switch and the fuse to the power line of each equipment.
  9. Install a main to switch to (if necessary) immediately interrupt all the system's power sources.
  10. If there exists the possibility of reversed phase, loose phase or momentary blackout, or if the power goes on and off while the product is operating, attach a reversed phase protection circuit locally.
- Running the product in reversed phase may break the compressor and other parts.
11. Install an earth leakage circuit breaker.
  12. The capacity of UNIT1 must be larger than that of UNIT2 when the power source is connected in series between the units.
  13. See outdoor unit manual for shielding the -F1F2- wire

3D149883

**RXYA-A**  
**RYMA5A** VRV5 Heat pump  
External connection diagram





1. All wiring, components and materials to be procured on-site must comply with the applicable legislation.
  2. Use copper conductors only
  3. For more details, refer to the wiring diagram of the unit.
  4. Install a circuit breaker for safety.
  5. All field wiring and components must be provided by an authorised electrician.
  6. Unit has to be grounded in compliance with the applicable legislation.
  7. The wiring shown is a general points-of-connection guide and is not intended to include all details for a specific installation.
  8. Make sure to install the switch and the fuse to the power line of each equipment.
  9. Install a main to switch to (if necessary) immediately interrupt all the system's power sources.
  10. If there exists the possibility of reversed phase, loose phase or momentary blackout, or if the power goes on and off while the product is operating, attach a reversed phase protection circuit locally.
- Running the product in reversed phase may break the compressor and other parts.
11. Install an earth leakage circuit breaker.
  12. See outdoor unit manual for shielding the -F1F2- wire

3D149884

# 11 Sound data



## 11 - 1 Sound Power Spectrum - Cooling



# 11 Sound data

## 11 - 1 Sound Power Spectrum - Cooling


11



# 11 Sound data

## 11 - 1 Sound Power Spectrum - Cooling

RXYA16A




**Notes**

- dBA = A-weighted sound power level (A scale according to IEC).
- Reference acoustic intensity  $0\text{dB} = 10^{-12}\text{ W}$ .
- Measured according to ISO 3744

4D150008

RXYA18A



**Notes**


- dBA = A-weighted sound power level (A scale according to IEC).
- Reference acoustic intensity  $0\text{dB} = 10^{-12}\text{ W}$ .
- Measured according to ISO 3744

4D150009

# 11 Sound data

## 11 - 1 Sound Power Spectrum - Cooling


11



# 11 Sound data

## 11 - 2 Sound Power Spectrum - Heating

RXYA8A  
RYMA5A




**Notes**

- dBA = A-weighted sound power level (A scale according to IEC).
- Reference acoustic intensity 0dB =  $10^{-12}$  W
- Measured according to ISO 3744

4D150004

RXYA10A



**Notes**



- dBA = A-weighted sound power level (A scale according to IEC).
- Reference acoustic intensity 0dB =  $10^{-12}$  W
- Measured according to ISO 3744

4D150005

# 11 Sound data

## 11 - 2 Sound Power Spectrum - Heating


11



# 11 Sound data

## 11 - 2 Sound Power Spectrum - Heating

RXYA16A




**Notes**

- dBA = A-weighted sound power level (A scale according to IEC).
- Reference acoustic intensity  $0\text{dB} = 10^{-12} \text{ W}$ .
- Measured according to ISO 3744

4D150008

RXYA18A



**Notes**


- dBA = A-weighted sound power level (A scale according to IEC).
- Reference acoustic intensity  $0\text{dB} = 10^{-12} \text{ W}$ .
- Measured according to ISO 3744

4D150009

# 11 Sound data

## 11 - 2 Sound Power Spectrum - Heating


11



# 11 Sound data


## 11 - 3 Sound Pressure Spectrum - Cooling

RXYA8A  
RYMA5A




**Notes**

- Data is valid at free field condition.
- Data is valid at nominal operation condition.
- dBA = A-weighted sound pressure level (A scale according to IE)
- Reference acoustic pressure 0 dB = 20 μPa




4D150004

RXYA10A



**Notes**

- Data is valid at free field condition.
- Data is valid at nominal operation condition.
- dBA = A-weighted sound pressure level (A scale according to IEC).
- Reference acoustic pressure 0 dB = 20 μPa





4D150005

# 11 Sound data

## 11 - 3 Sound Pressure Spectrum - Cooling


11



# 11 Sound data


## 11 - 3 Sound Pressure Spectrum - Cooling

RXYA16A




**Notes**

- Data is valid at free field condition.
- Data is valid at nominal operation condition.
- dBA = A-weighted sound pressure level (A scale according to IEC).
- Reference acoustic pressure 0 dB = 20 μPa




4D150008

RXYA18A



**Notes**

- Data is valid at free field condition.
- Data is valid at nominal operation condition.
- dBA = A-weighted sound pressure level (A scale according to IEC).
- Reference acoustic pressure 0 dB = 20 μPa




4D150009

# 11 Sound data

## 11 - 3 Sound Pressure Spectrum - Cooling


11



# 11 Sound data

## 11 - 4 Sound Pressure Spectrum - Heating

RXYA8A  
RYMA5A




**Notes**

- Data is valid at free field condition.
- Data is valid at nominal operation condition.
- dBA = A-weighted sound pressure level (A scale according to IEC).
- Reference acoustic pressure 0 dB = 20 μPa

4D150004

RXYA10A



**Notes**



- Data is valid at free field condition.
- Data is valid at nominal operation condition.
- dBA = A-weighted sound pressure level (A scale according to IEC).
- Reference acoustic pressure 0 dB = 20 μPa

4D150005

# 11 Sound data



## 11 - 4 Sound Pressure Spectrum - Heating

11



# 11 Sound data


## 11 - 4 Sound Pressure Spectrum - Heating



# 11 Sound data

## 11 - 4 Sound Pressure Spectrum - Heating

11



# 11 Sound data

## 11 - 5 Sound level data Quiet mode

 RXYA-A  
 RYMA5A

**VRV-5 Heat pump**  
**Low noise data (level ·1-5·)**

	Capacity ratio
LN1	90%
LN2	75%
LN3	60%
LN4	45%
LN5	30%

5HP/ 8HP	Cooling		Heating	
	Sound power [dBA]	Sound pressure [dBA]	Sound power [dBA]	Sound pressure [dBA]
LN1	75	53	76	55
LN2	72	50	73	52
LN3	69	47	70	49
LN4	66	44	67	46
LN5	63	41	64	43

10HP	Cooling		Heating	
	Sound power [dBA]	Sound pressure [dBA]	Sound power [dBA]	Sound pressure [dBA]
LN1	76	55	78	56
LN2	73	52	75	53
LN3	70	49	72	50
LN4	67	46	69	47
LN5	64	43	66	44

12HP	Cooling		Heating	
	Sound power [dBA]	Sound pressure [dBA]	Sound power [dBA]	Sound pressure [dBA]
LN1	79	58	80	58
LN2	76	55	77	55
LN3	73	52	74	52
LN4	70	49	71	49
LN5	67	46	68	46

14HP	Cooling		Heating	
	Sound power [dBA]	Sound pressure [dBA]	Sound power [dBA]	Sound pressure [dBA]
LN1	76	54	81	58
LN2	73	51	78	55
LN3	70	48	75	52
LN4	67	45	72	49
LN5	64	42	69	46

16HP	Cooling		Heating	
	Sound power [dBA]	Sound pressure [dBA]	Sound power [dBA]	Sound pressure [dBA]
LN1	81	58	84	62
LN2	78	55	82	59
LN3	75	52	80	56
LN4	72	49	77	53
LN5	69	46	74	50

4D150022

# 11 Sound data

## 11 - 5 Sound level data Quiet mode

RXYA-A  
RYMA5A

11

18HP	Cooling		Heating	
	Sound power [dBA]	Sound pressure [dBA]	Sound power [dBA]	Sound pressure [dBA]
LN1	81	60	83	61
LN2	78	57	81	58
LN3	76	54	78	55
LN4	74	51	75	52
LN5	71	48	72	49

20HP	Cooling		Heating	
	Sound power [dBA]	Sound pressure [dBA]	Sound power [dBA]	Sound pressure [dBA]
LN1	85	64	87	65
LN2	82	61	84	62
LN3	80	58	81	59
LN4	77	55	79	56
LN5	74	52	77	53

- LN1: Low noise level ·1·
- LN2: Low noise level ·2·
- LN3: Low noise level ·3·
- LN4: Low noise level ·4·
- LN5: Low noise level ·5·


Notes

Sound power

dBA = A-weighted sound power level (A scale according to IEC).  
 Reference acoustic intensity 0dB =  $10^{-12}$  W  
 Measured according to ISO 3744

sound pressure

Data is valid at free field condition.  
 Data is valid at nominal operation condition.  
 dBA = A-weighted sound pressure level (A scale according to IEC).  
 Reference acoustic pressure 0 dB = 20  $\mu$ Pa



4D150022

# 11 Sound data

## 11 - 6 Sound power level at high ESP

RXYA-A  
RYMA5A

**VRV-5  
High ESP**      **Heat pump**

	Cooling	Heating
	Sound power [dBA]	Sound power [dBA]
<b>5HP</b>	81	84
<b>8HP</b>	81	84
<b>10HP</b>	81	84
<b>12HP</b>	81	84
<b>14HP</b>	83	85
<b>16HP</b>	87	89
<b>18HP</b>	87	89
<b>20HP</b>	88	90

Sound power is measured on a freestanding unit.  
Actual sound is depending on the installation of the duct.

4D149959


# 12 Installation

## 12 - 1 Installation Method



12

RXYA-A  
RYMA5A

For single unit installation For installation in rows



For centralised group layout



**Notes**

1. Height of the walls in case of patterns 1 and 2:

Front: •1500•mm

Suction side: •500•mm

Side: height unrestricted

The installation space shown on this drawing is based on cooling operation at +35°C (outdoor temperature).

When the design outdoor ambient temperature exceeds 35°C or the load exceeds maximum ability of much generation load of heat in all outdoor unit, make sure the suction-side space is broader than the space shown on this drawing.

2. If the walls are higher than mentioned above, then additional service space is needed:

- suction side: service space + h1/2

- front side: service space + h2/2

3. When installing the units, select the pattern that best fits the available space.

Always keep in mind to leave sufficient space for a person to pass between unit and wall and for the air to circulate freely.

Provide sufficient space at the front to connect refrigerant piping (comfortably).

4. If more units are to be installed than are catered for in the above patterns, your layout should take into account of the possibility of short circuits.

3D118467A





# 12 Installation

## 12 - 3 Refrigerant Pipe Selection

**VRV5  
Heat pump  
Piping restrictions**

	Maximum piping length			Maximum height difference			Total piping length
	Longest pipe from the outdoor unit to the last multi-outdoor piping branch	Longest pipe after first branch or multi SV unit	Longest pipe from the outdoor unit to the last multi-outdoor piping branch	Indoor-to-outdoor	Indoor-to-indoor	Outdoor-to-outdoor	
	Actual / Equivalent Maximum: (A)(B)×(C), (A)(D)×(E), (A)(F)×(G), (A)(H)×(I) Minimum: (A)(J)×(K), (A)(L)×(M), (A)(N)×(O)	Actual Maximum: (B)×(C), (B)×(D), (B)×(E), (B)×(F) Minimum: (B)×(G), (B)×(H), (B)×(I), (B)×(J)	Actual / Equivalent Maximum: (E) Minimum: (E)	Outdoor unit higher than indoor unit / Indoor unit higher than outdoor unit Maximum: (H) Minimum: (H)	Maximum: (K) Minimum: (K)	Maximum: (L) Minimum: (L)	
VRV R32 DX indoor units only	35/250 m(*3)	40 m (**)(*4)	-	50/60 m(*2)	50 m	-	1000 m
Multi-outdoor unit connections	35/250 m(*3)	40 m (**)(*4)	10/13 m	50/60 m(*2)	50m	5 m	500 m
AHRJ connection	Pair (*5)	50/55 m(*7)	40 m	10/13 m	-	5 m	150m(*8)
	Multi (*6)	35/250 m(*3)	40 m	10/13 m	40/60 m	5 m	1000 m
	Mix (*9)	35/250 m(*3)	40 m	10/13 m	40/60 m	5 m	1000 m

Maximum piping length	Maximum height difference
AHRJ connection	ERX/A to AHRJ
	II
Pair (*5)	5 m
Multi (*6)	5 m
Mix (*9)	5 m

Notes

- If all conditions below are met, the installation can be extended up to 90 m
  - The piping length between all indoor units and the nearest branch hit or SV unit is ≤ 40 m
  - It is required to size up gas and liquid piping between the first branch hit or SV unit and the last branch hit or last SV unit
    - If the longest pipe size is larger than the pipe size of the main pipe, also increase the size of the main pipe.
  - When the piping size is increased, the piping length has to be counted as double. The total piping length has to be within limitations.
- The piping length difference between the nearest indoor unit to the outdoor unit and the farthest indoor unit to the outdoor unit is ≤ 40 m. The total piping length can be extended up to 90 m
  - Indoor units are VRV R32 DX only
  - If the outdoor units are positioned higher than the indoor units
    - Size up the liquid piping
    - A dedicated setting on the outdoor unit is required. For more information, refer to the service manual.
  - If the outdoor units are positioned lower than the indoor units
    - Size up the liquid piping
    - A dedicated setting on the outdoor unit is required. For more information, refer to the service manual.
- If the equivalent piping length is > 90 m, size up the main liquid and gas piping
- Limit of 40 m between SV unit and indoor unit is dependent on room size (R-Safety system).
- For AHRJ system with LHV handling unit connected to one outdoor unit system
- Multiple air handling units (AHRJ) 1 ERX/A + 100A/200A/300A
- The allowable maximum length is 5 m.
- Max of air handling units (ERX/A/100A/200A/300A) and VRV R32 DX indoor units
- Up to 3 piping branches are possible in case of an AHRJ with an interfacial heat exchanger.

40149858

# 12 Installation

## 12 - 4 Refrigerant Charge Information

RXYA-A  
RYMA-A

### Requirements for R32 units

To comply with the requirements of enhanced tightness refrigerating systems of the IEC 60335-2-40:2022, this system is equipped with an alarm in the remote controller and shut-off valves in the ·SV· unit.

These safety measures are installation specific and can be determined using the requirements mentioned in the outdoor unit manual.

The ·SV· unit is prearranged for a ventilated enclosure as countermeasure.

### Outdoor unit installation

The outdoor unit has to be installed outside. For indoor installation of the outdoor unit, additional measures can be necessary to comply with the applicable legislation.

### Indoor unit installation

The total amount of refrigerant in the system shall be less than or equal to the maximum allowed total refrigerant amount.

The maximum allowed total refrigerant amount depends on the area of the rooms being served by the system and the rooms in the lowest underground floor.

Note: The total refrigerant charge amount in the system MUST always be lower than ·79.8· [kg].

Depending on the smallest room size in which the indoor unit is installed/conditioning and the total amount of refrigerant in the system, different safety measures can be applied.

Follow the flowchart. Details are described in the manual of the outdoor unit.

Use the graph or table ·1· to determine the required safety measures for the indoor unit.

Note: If the installation height is more than ·2.2· m, different boundaries for the applicable safety measures can apply.

To know which safety measure is required in case the installation height is more than ·2.2· m, refer to VRV Xpress (<https://vrvxpress.daikin.eu/>).


4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

RXYA-A  
RYMA-A

**Indoor unit installation**



4D149568A

# 12 Installation


## 12 - 4 Refrigerant Charge Information

12

RXYA-A  
RYMA-A

### Indoor unit installation

Table ·1·



4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

 RXYA-A  
 RYMA-A

### Indoor unit installation

m [kg]	Amin [m <sup>2</sup> ]			m [kg]	Amin [m <sup>2</sup> ]		
	Lowest underground floor (-a-)		All other floors (-b-)		Lowest underground floor (-a-)		All other floors (-b-)
	No safety measure (-c-)	Safety alarm OR Natural ventilation (-d-)	No safety measure (-c-)		No safety measure (-c-)	Safety alarm OR Natural ventilation (-d-)	No safety measure (-c-)
5	15	10	10	43	128	85	85
6	18	12	12	44	131	87	87
7	21	14	14	45	134	89	89
8	24	16	16	46	137	91	91
9	27	18	18	47	140	93	93
10	30	20	20	48	143	95	95
11	33	22	22	49	146	97	97
12	36	24	24	50	149	99	99
13	39	26	26	51	152	101	101
14	42	28	28	52	154	103	103
15	45	30	30	53	157	105	105
16	48	32	32	54	160	107	107
17	51	34	34	55	163	109	109
18	54	36	36	56	166	111	111
19	57	38	38	57	169	113	113
20	60	40	40	58	172	115	115
21	63	42	42	59	175	117	117
22	66	44	44	60	178	119	119
23	69	46	46	61	181	121	121
24	72	48	48	62	184	123	123
25	75	50	50	63	187	125	125
26	77	52	52	64	190	127	127
27	80	54	54	65	193	129	129
28	83	56	56	66	196	131	131
29	86	58	58	67	199	133	133
30	89	60	60	68	202	135	135
31	92	62	62	69	205	137	137
32	95	64	64	70	208	139	139
33	98	66	66	71	211	141	141
34	101	68	68	72	214	143	143
35	104	70	70	73	217	145	145
36	107	72	72	74	220	147	147
37	110	74	74	75	223	149	149
38	113	76	76	76	226	151	151
39	116	77	77	77	229	153	153
40	119	79	79	78	231	154	154
41	122	81	81	79	234	156	156
42	125	83	83	80	237	158	158

4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

12

RXYA-A  
RYMA-A

### Indoor unit installation

Safety measures include:

#### No safety measure

When the room area is sufficiently large, no safety measures are required.

#### Safety alarm

Do not use the safety alarm as the only safety measure in case the indoor unit is installed in an occupied space where people are restricted in their movement.

When the R32 sensor in the indoor unit detects a refrigerant leak, it will activate the alarm that will warn the user visually and audibly.

Each indoor unit must be connected with an R32 safety system compatible remote controller (e.g. ·BRC1H52/82\*· or later type).

Each indoor unit must be connected to a separate remote controller. In case indoor units are operating under group control, it is possible to only use one remote controller per room.

In case the indoor unit is serving a different room than where it is installed, a remote controller is required in both the installed and the served room.

For buildings where sleeping facilities are offered (e.g. hotel), where persons are restricted in their movements (e.g. hospital), where an uncontrolled number of persons is present or buildings where people are not aware of the safety precautions:

It is mandatory to install one of the following devices at a location with 24-hour monitoring.

- a supervisor remote controller
- or a centralised controller, e.g. iTM with external alarm via WAGO module,
- iTM with built-in alarm, ...

The alarm should always be ·15· dB louder than the background noise of the room.

For details, see the manual of the ·outdoor· unit.

#### Natural ventilation

Natural ventilation is a safety measure where ventilation is made to a place where sufficient air is available to dilute the leaked refrigerant such as a large space.

Step ·1·

Determine total room area, which is the total area of the space that has natural ventilation and the space in which the indoor unit is installed.

Step ·2·

Use the graph or table to determine the total refrigerant charge limit in the system.

See table ·2·.

If the installation height is more than ·2.2· m, a higher total refrigerant charge limit of the system can apply.

To know the total refrigerant charge limit of the system in case the installation height is more than ·2.2· m, refer to the online tool (VRV Xpress).

4D149568A


# 12 Installation

## 12 - 4 Refrigerant Charge Information

RXYA-A  
RYMA-A

### Indoor unit installation

Table ·2·



$A_1 + A_{min}$ [m <sup>2</sup> ]	m [kg]
0	0
10	3.3
20	6.7
30	10.1
40	13.5
50	16.8
60	20.2
70	23.6
80	27.0
90	30.3
100	33.7
110	37.1
120	40.5
130	43.9
140	47.2
150	50.6
160	54.0
170	57.4
180	60.7
190	64.1
200	67.5
210	70.9
220	74.2
230	77.6
236	79.6
237	79.8
240	79.8
250	79.8

**Step ·3·**

The total amount of refrigerant in the system shall be less than or equal to the maximum allowed total refrigerant amount.

If NOT, natural ventilation safety measure is not allowed.

**Step ·4·**

The partition between two rooms on the same floor MUST meet one of the two requirements for natural ventilation.

For details, see the manual of the ·outdoor· unit.

**Shut-off valves**

·SV· unit which has shut-off valves needs to be installed to reduce the amount of refrigerant leakage in to the room where the indoor unit is installed.

When the R32 sensor in the indoor unit detects a refrigerant leak, the corresponding shut-off valves in the ·SV· unit close.

Follow the flowchart. Details are described in the manual of the outdoor unit.

4D149568A

# 12 Installation


## 12 - 4 Refrigerant Charge Information

12

RXYA-A  
RYMA-A

### Indoor unit installation

Flowchart (for EACH ·SV· unit branch pipe port)



4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

RXYA-A  
RYMA-A

**Indoor unit installation**

Table 3

Area of installed/conditioned room [m <sup>2</sup> ]	Maximum total indoor unit capacity class		
	1 indoor unit per branch pipe port (a)	2-5 units per branch pipe port	
		40 m after first branch (b)	90 m after first branch (c)
< 5	-	-	-
5	10	-	-
6	25	-	-
7	32	-	-
8	40	-	-
9	71	-	-
10	80	-	-
11	80	20	-
12	80	25	-
13	80	32	-
14	80	32	-
15	125	40	-
20	200	50	40
25	250	71	71
30	250	125	125
35	250	200	200
40	250	200	200
≥ 45	250	250	250

- (a) 1 indoor unit connected to a single branch pipe port.
- (b) 2 to 5 indoor units connected to a single branch pipe port, 40 m after first refrigerant branch.
- (c) 2 to 5 indoor units connected to a single branch pipe port, 90 m after first refrigerant branch.

Note: In case the indoor unit capacity class allowed per branch pipe port exceeds 140, use SV1A unit or combine two ports while using SV4~8A unit.

Note: The values in Table 3 are under the assumption of worst case indoor unit volume and 40 m piping between indoor and SV unit.

In VRV Xpress (<https://vrvxpress.daikin.eu/>) it is possible to add custom piping lengths and indoor units, which can lead to lower minimum room area requirements.

4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

12

RXYA-A  
RYMA-A


**·SV· unit installation**

Depending on the room size in which the ·SV· unit is installed and the total amount of refrigerant in the system, different safety measures can be applied.

Follow the flowchart. Details are described in the manual of ·SV· unit.

Note: If the installation height is more than ·2.2· m, different boundaries for the applicable safety measures can apply.

To know which safety measure is required in case the installation height is more than ·2.2· m, refer to VRV Xpress (<https://vrvxpress.daikin.eu/>).



\* Do NOT use the external safety alarm if the ·SV· unit is installed in an occupied space where people are restricted in their movement.

4D149568A


# 12 Installation

## 12 - 4 Refrigerant Charge Information

RXYA-A  
RYMA-A

•SV• unit installation

Table 4-



4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

12

RXYA-A  
RYMA-A

•SV• unit installation

m [kg]	Amin [m <sup>2</sup> ]			m [kg]	Amin [m <sup>2</sup> ]		
	Lowest underground floor (-a-)		All other floors (-b-)		Lowest underground floor (-a-)		All other floors (-b-)
	No safety measure (-c-)	Safety alarm OR Natural ventilation (-d-)	No safety measure (-c-)		No safety measure (-c-)	Safety alarm OR Natural ventilation (-d-)	No safety measure (-c-)
5	15	10	10	43	128	85	85
6	18	12	12	44	131	87	87
7	21	14	14	45	134	89	89
8	24	16	16	46	137	91	91
9	27	18	18	47	140	93	93
10	30	20	20	48	143	95	95
11	33	22	22	49	146	97	97
12	36	24	24	50	149	99	99
13	39	26	26	51	152	101	101
14	42	28	28	52	154	103	103
15	45	30	30	53	157	105	105
16	48	32	32	54	160	107	107
17	51	34	34	55	163	109	109
18	54	36	36	56	166	111	111
19	57	38	38	57	169	113	113
20	60	40	40	58	172	115	115
21	63	42	42	59	175	117	117
22	66	44	44	60	178	119	119
23	69	46	46	61	181	121	121
24	72	48	48	62	184	123	123
25	75	50	50	63	187	125	125
26	77	52	52	64	190	127	127
27	80	54	54	65	193	129	129
28	83	56	56	66	196	131	131
29	86	58	58	67	199	133	133
30	89	60	60	68	202	135	135
31	92	62	62	69	205	137	137
32	95	64	64	70	208	139	139
33	98	66	66	71	211	141	141
34	101	68	68	72	214	143	143
35	104	70	70	73	217	145	145
36	107	72	72	74	220	147	147
37	110	74	74	75	223	149	149
38	113	76	76	76	226	151	151
39	116	77	77	77	229	153	153
40	119	79	79	78	231	154	154
41	122	81	81	79	234	156	156
42	125	83	83	80	237	158	158

4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

RXYA-A  
RYMA-A

### ·SV· unit installation

Safety measures include:

#### No safety measure

When the room area is sufficiently large, no safety measures are required.

#### Safety alarm

An external alarm circuit (field supply) must be connected to the SVS output of the ·SV· unit.

When the R32 sensor in the ·SV· unit detects a refrigerant leak, the SVS output closes and activates the alarm. An error message is displayed on the remote controllers of the connected indoor units.

- This alarm system must warn audibly AND visibly (e.g. a loud buzzer AND a flashing light). The audible alarm must be ·15· dBA above the background sound level at all times.
- At least one alarm must be installed in the occupied space in which the ·SV· unit is installed.
- For the occupancy listed below, the alarm system must additionally warn at a supervised location with 24-hour monitoring. To warn at a supervised location, connect a supervisor remote controller (e.g. ·BRC1H52\*·) to the system
  - with sleeping facilities.
  - where an uncontrolled number of people are present.
  - accessible for persons not familiar with the necessary safety precautions.
  - where people are restricted in their movement
- Do NOT use the external safety alarm as the only safety measure if the ·SV· unit is installed in an occupied space where people are restricted in their movement.

For details, see the manual of the ·SV· unit.

#### Natural ventilation

Natural ventilation is a safety measure where ventilation is made to a place where sufficient air is available to dilute the leaked refrigerant such as a large space.

##### Step ·1·

Determine total room area, which is the total area of the space that has natural ventilation and the space in which the indoor unit is installed.

##### Step ·2·

Use the graph or table to determine the total refrigerant charge limit in the system.

See table ·5·.

Note: If the installation height is more than ·2.2· m, different boundaries for the applicable safety measures can apply.

To know the total refrigerant charge limit of the system in case the installation height is more than ·2.2· m, refer to the online tool (VRV Xpress).

4D149568A

# 12 Installation


## 12 - 4 Refrigerant Charge Information

12

RXYA-A  
RYMA-A

·SV· unit installation

Table ·5·



$A_i + A_o$ [m <sup>2</sup> ]	m [kg]
0	0
10	3.3
20	6.7
30	10.1
40	13.5
50	16.8
60	20.2
70	23.6
80	27.0
90	30.3
100	33.7
110	37.1
120	40.5
130	43.9
140	47.2
150	50.6
160	54.0
170	57.4
180	60.7
190	64.1
200	67.5
210	70.9
220	74.2
230	77.6
236	79.6
237	79.8
240	79.8
250	79.8

Step ·3·

The total amount of refrigerant in the system shall be less than or equal to the maximum allowed total refrigerant amount.

If NOT, natural ventilation safety measure is not allowed.

Step ·4·

The partition between two rooms on the same floor MUST meet one of the two requirements for natural ventilation.

For details, see the manual of the ·SV· unit.

### Ventilated enclosure

For the ventilated enclosure safety measure, ductwork and an extraction fan are installed.

When the R32 sensor in the ·SV· unit detects a refrigerant leak, it will activate the safety measures.

This includes:

- opening the damper of the unit to allow air to enter and evacuate the refrigerant leak.
- activating the fan output signal to trigger an extraction fan to operate.
- displaying an error message on the remote controllers of the connected indoor units.

4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

RXYA-A  
RYMA-A


**·SV· unit installation**

The information in the table below must be taken into account in case a ventilated enclosure is used as a safety measure.

Ductwork	The evacuation ductwork <b>MUST</b> vent outside the building or to another room with minimum room area requirements. Refer to the installation and operation manual of ·SV· unit· for details.  Avoid that dirt and small animals can enter the ductwork and lead to an obstruction. Example: install a non-return valve, grille, filter or other component in the evacuation duct.
Extraction fan	The extraction fan must have a CE marking and cannot act as an ignition source during normal operation. This requirement is met if the fan motor has an IP4X rating or better.
Replacement air	Make sure that sufficient air is available for the extraction of a refrigerant leak. The extraction airflow rate must be maintained for at least ·8· hours.  This is achieved by providing a sufficiently large air volume around the ·SV· unit, or by providing sufficient replacement air around the ·SV· unit (e.g. natural openings or a dedicated opening in the false ceiling).
Maintenance	Maintain the evacuation channel to avoid dust and dirt from building up and obstructing the flow path.

A damper at the air inlet of the ·SV· unit enables a choice between 3 types of configurations (see below).

The damper opens when a refrigerant leak has been detected in the ·SV· unit. This creates an airflow path from the leaking ·SV· unit to the extraction fan.



**a** Damper

When a ventilated enclosure is required, the following requirements apply.

- Pressure inside the ·SV· unit has to be more than ·20· Pa below the ambient pressure.
- Minimum airflow rate

Model	Minimum airflow rate [m <sup>3</sup> /h]
SV1A	82
SV4A	82
SV6-8A	84

4D149568A

# 12 Installation

## 12 - 4 Refrigerant Charge Information

12


RXYA-A  
RYMA-A

**·SV· unit installation**

External fan needs to be selected in order to meet these requirements. The available calculation method depends on the configuration.

**Possible configurations**

One ·SV· unit – one extraction fan




- a** SV unit
- b** Ductwork
- c** Extraction fan

**Calculation method for selection of external fan**

- Manual calculation: see ·SV· unit manual for details
- VRV Xpress: see <https://vrvxpress.daikin.eu/>


Multiple ·SV· units in parallel – one extraction fan



- a<sub>#</sub>** SV unit #
- b** Ductwork
- c** Extraction fan

- VRV Xpress: see <https://vrvxpress.daikin.eu/>

Multiple ·SV· units in series – one extraction fan



- a** SV unit
- b** Ductwork
- c** EKBSDCK
- d** Extraction fan


- VRV Xpress: see <https://vrvxpress.daikin.eu/>

4D149568A

# 13 Operation range

## 13 - 1 Operation Range

RXYA-A  
RYMA5A



3D141186

# 14 Appropriate Indoors

## 14 - 1 Appropriate Indoors

14

### RXYA-A

### RYMA-A

Recommended indoor units for -RXYA\*A\* + RYMA\*A\*- outdoor units

.. HP	8	10	12	13	14	16	18	20
	4xFXSA50	4xFXSA63	6xFXSA50	3xFXSA50 3xFXSA63	1xFXSA50 5xFXSA63	4xFXSA63 2xFXSA80	3xFXSA50 5xFXSA63	8xFXSA63

For multi outdoor units ->16HP-, the recommended amount of indoor units is the sum of the indoor units defined for a single outdoor unit.  
For details about the allowed combinations, see the engineering databook.

Appropriate indoor units for -RXYA\*A\* + RYMA\*A\*- outdoor units


#### Covered by -ENER LOT21-

FXFA20-25-32-40-50-63-80-100-125  
FXZA15-20-25-32-40-50  
FXSA15-20-25-32-40-50-63-80-100-125-140  
FXDA10-15-20-25-32-40-50-63  
FXAA15-20-25-32-40-50-63  
FXMA50-63-80-100-125-200-250  
FXHA32-50-63-100  
FXUA50-71-100  
FXKA20-25-32-40-50-63  
FXNA20-25-32-40-50-63

#### Outside the scope of -ENER LOT21-

EKVDX32-50-80-100  
EKEXVA50-63-80-100-125-140-200-250-300-350-400-450-500 + EKEACBVE  
CYAS100\*80, CYAS150\*80, CYAS200\*100, CYAS250\*140  
CYAM100\*80, CYAM150\*80, CYAM200\*100, CYAM250\*140  
CYAL100\*125, CYAL150\*200, CYAL200\*250, CYAL250\*250

**4D149890B**



EEDEN24

12/2024



The present leaflet is drawn up by way of information only and does not constitute an offer binding upon Daikin Europe N.V. Daikin Europe N.V. has compiled the content of this leaflet to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein. Specifications are subject to change without prior notice. Daikin Europe N.V. explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this leaflet. All content is copyrighted by Daikin Europe N.V.